

# Par Light User's Manual

Model:LP001/LP003/LP001-H/LP003-H/LP010/LP010-H

#### Attention

- 1.Please read these operating instructions carefully to familiarize you with basic operations of this unit BEFORE USE.
- 2. Without permitted, it is prohibited to spread the contents of this manual to others.
- 3. This manual is only to provide related information, and the contents of this manual will be changed at any time without notice.
- 4. Unless the instructions have already stated, please do not freely modified the unit.

### Safety Tips

- 1. Before installation and maintenance, please confirm the power is OFF, make sure that the ventilation around the unit is good.
- The lighting is designed for indoor demonstration, please do not use this product in a wet environment for long-term.
- 3.The use and maintenance of this unit should avoid contact with water. when using it outdoor, please take waterproofing measures.
- 4.Personnel, who to take the installation, operation and maintenance, must be familiar with the lighting performance. Most of the damage is resulted from unfamiliar with its performance.
- 5. Please do not face up to the luminous unit for a long time, so as not to cause discomfort to your eyes.
- 6.Please often wipe the unit with a clean cloth.

## Operation Instructions

| MENU      | Numerical | Description  |
|-----------|-----------|--|
| СС        | 0-99      | Colors transition, change speed by UP and Down                   |
| CP        |           | Colors shade, change speed by UP and Down                        |
| DE        | 0-99      | Auto-play mode, change speed by UP and Down                      |
| BEBE      |           | Sound control mode   |
| R000-255  |           | Red color brightness setting, change brightness by UP and Down   |
| G000-255  |           | Green color brightness setting, change brightness by UP and Down |
| B000-255  |           | Blue color brightness setting, change brightness by UP and Down  |
| W000-255  |           | White color brightness setting, change brightness by UP and Down |
| D001-D512 |           | DMX mode, change numerical value by UP and Down                  |

Note: "MENU" is the Function Transforming Button, "UP & Down" is the No. Transforming Button,

| Technical Parameters |                             |         |       |         |       |         |  |  |
|----------------------|-----------------------------|---------|-------|---------|-------|---------|--|--|
| Model                | LP001                       | LP001-H | LP010 | LP010-H | LP003 | LP003-H |  |  |
| Light source         | 54x3W                       |         | 54x2W |         | 54x1W |         |  |  |
| Source lifetime      | Rated 50,000 hours          |         |       |         |       |         |  |  |
| Power supply         | 100-240V/50-60HZ            |         |       |         |       |         |  |  |
| Rating power         | 180W                        |         | 115W  |         | 60W   |         |  |  |
| Play mode            | Auto/Sound/DMX/Master-slave |         |       |         |       |         |  |  |
| DMX channel          | 8                           |         |       |         |       |         |  |  |
| Effect               | Color change, Strobe        |         |       |         |       |         |  |  |
| Dimensions           | 235*235*295mm               |         |       |         |       |         |  |  |
| N.W.                 | 2.8KG                       | 2.88KG  | 2.7   | 7KG     | 2.8KG | 2.88KG  |  |  |
| Standard             | Power cable                 |         |       |         |       |         |  |  |
| configuration        |                             |         |       |         |       |         |  |  |

#### DMX C ontrol

(Last radix point flickers on digital display board when has DMX signal)

| Channels | Function   |  |  |  |  |
|----------|--|--|--|--|--|
| 0-255    | R. G. B or mixed color brightness control (This channel should use                                   |  |  |  |  |
|          | together with CH5, CH6, Ch7orCH8)  |  |  |  |  |
|          | Strobe flash, speed adjustable. (This channel should use together                                    |  |  |  |  |
| 0-255    | with CH5, CH6, Ch7orCH8)   |  |  |  |  |
| 0-10     | All light off  |  |  |  |  |
| 11-49    | Select colors by manual  |  |  |  |  |
| 50-100   | Colors transition automatically  |  |  |  |  |
| 101-149  | Colors shade automatically   |  |  |  |  |
| 150-199  | Colors pulse transform automatically   |  |  |  |  |
| 200-255  | Sound mode   |  |  |  |  |
| 1-255    | Select colors when CH3 at 11-50  |  |  |  |  |
| 0        | Red light off  |  |  |  |  |
| 1-255    | Red brightness from dark to bright   |  |  |  |  |
| 0        | Green light off  |  |  |  |  |
| 1-255    | Green brightness from dark to bright   |  |  |  |  |
| 0        | Blue light off   |  |  |  |  |
| 1-255    | Blue brightness from dark to bright)   |  |  |  |  |
| 0        | White light off  |  |  |  |  |
| 1-255    | White brightness from dark to bright)  |  |  |  |  |
|          | 0-255  0-255  0-10  11-49  50-100  101-149  150-199  200-255  1-255  0  1-255  0  1-255  0  1-255  0 |  |  |  |  |

 $Master\ slave\ mode: connect\ by\ DMX\ cable,\ D001\ mode\ is\ slave\ light\ while\ the\ first\ light\ is\ master\ one.$ 

Big Dipper Laser Science And Technology Co., Ltd

All products made from Big Dipper Laser Company have anti - fake identification. please verify the anti-counterfeit label at the bottom of the case to ensure the interests of consumers.

<sup>&</sup>quot;ENTER" is the Confirming Button.