



## Modulation Control Bus Table

	MODE	AMOUNT	SENS	FREQ
	Envelope UP	Mod DEPTH	Picking Dynamic Sensitivity	Starting point of sweep
	Envelope DOWN	Mod DEPTH	Picking Dynamic Sensitivity	Ending point of sweep
	LFO - Triangle wave	Mod SPEED	Dynamic LFO SPEED modulation	Starting point of sweep
	LFO - Ramp UP wave	Mod SPEED	Dynamic LFO SPEED modulation	Starting point of sweep
	LFO - Ramp DOWN wave	Mod SPEED	Dynamic LFO SPEED modulation	Starting point of sweep
	LFO - Random wave	Mod SPEED	Dynamic LFO SPEED modulation	Starting point of sweep
	Static	Disconnected	Disconnected	Manual Sweep

