ACURA_V01.10 Daig Function	List (Note:For	reference on	ly)	
NOTES:				
• This function is supported.				
X This function may be supported, which depends €	on the actual c	ondition of th	ne vehicle.	
O This function is not supported.				
▲ This function is the new feature in this version Vehicle	Model Year			
ACURA CL				
ACURA CSX	2000 -			
ACURA EL	2000 - 2000 -			
ACURA MDX				
ACURA RDX	2000 -			
ACURA RSX	2000 - 2000 -			
ACURA TL	2000 -			
ACURA TSX	2001 -			
Systemlist	EcuInfo.	ReadCodes	EraseCodes	LiveData
ECM (Engine Control Module)	• Dearmio.	Neaucoues	• El asecoues	•
AT (Automatic Transmission)	•	•	•	
ABS(Anti-lock Braking System)	•	•	•	•
SRS(Supplemental Inflatable Restraint System)	•	•	•	•
BCM(Body Electrical System)	•	•	•	•
METER	•	•	•	•
EPS(Electric Power Steering)	•	•	•	•
PAWS(Precision All Wheel Steer)	•	•	•	•
EPB(Electric Parking Brake)	•	•	•	•
HONDA SMART PARKING	•	•	•	•
ESB(Electric Servo Brake System)	•	•	•	•
CMBS(Collision Mitigation Brake System)	•	•	•	•
EVPS(Electric Vacuum Pump System)	•	•	•	•
IMMOBILIZER	•	•	•	•
AVAS (Acoustic Vehicle Alerting System)	•	•	•	•
IMA_BATTERY(Integrated Motor Assist)	•	•	•	•
IMA_MOTOR(Integrated Motor Assist)	•	•	•	•
ACM(Active Control Engine Mount System)	•	•	•	•
HONDA SMART KEY SYSTEM	•	•	•	•
TPMS(Tire Pressure Monitoring System)	•	•	•	•
VTM-4(Variable Torque Management 4WD)	•	•	•	•
SH-AWD(Super Handling-All Wheel Driving)	•	•	•	•
E-DPS(Real Time AWD/AWD with Intelligent Control)	•	•	•	•
ACC(Adaptive Cruise Control)	•	•	•	•
I-SHIFT	•	•	•	•
HYDRAULIC BOOSTER	•	•	•	•
LKAS CAMERA ECU	•	•	•	•
LKAS CONTROL ECU	•	•	•	•
ACTIVE DAMPER SYSTEM	•	•	•	•
POPUP HOOD	•	•	•	•
PCU			•	

•

•

lacktriangle

•

lacktriangle

•

•

•

•

•

•

•

•

•

•

•

•

•

•

lacktrian

SVT

NIGHT VISION

MVCS(Multiple-View Camera System)

EDLC(Electric Double-Layer Capacitor)

BSI(Blind Spot Information)

SWS(Seat Weight Sensor)