

CITROEN_V11.20 ETC Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	ETC
BERLINGO	●
BERLINGO (B9)	●
BERLINGO 2	●
BERLINGO 2 (M69)	●
BERLINGO Electric (B9e)	●
C1	●
C2 (CAN)	●
C2 (CHINA)	●
C3 (A51)	●
C3 (Ai51)	●
C3 (AIRCROSS) (Ai58)	●
C3 (AIRCROSS) (A88)	●
C3 (B618)	●
C3 (PICASSO) (A58)	●
C3 (PICASSO) (Ai58)	●
C3 (PLURIEL)	●
C3 (R)	●
C3 (XR)	●
C4	●
C4 (Sedan) (B7)	●
C4 (PICASSO)	●
C4 (PICASSO) (B78)	●
C4 (BZ3) (CHINA)	●
C4 (CACTUS)	●
C4 (AIRCROSS)	●
C5	●
C5 (X7)	●
C5 (AIRCROSS)	●
C5 (New)	●
C6	●
C6 (CHINA)	●
C8 (CAN)	●
C-ELYSEE	●
C-QUATRE	●
C-TRIOMPHE	●
DS3	●
DS4	●
DS4 (S)	●
DS5	●
DS5 LS	●
DS5 (Hybrid 4)	●
DS6	●
DS7	●
ELYSEE	●
ELYSEE (R3)	●
EVASION (SYNERGIE)	●

FUKANG	●
FUKANG (988)	●
JUMPY (DISPATCH)	●
JUMPER (RELAY)	●
SAXO	●
SPACETOURER	●
XSARA	●
ZX	●