

FORD BMS Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	BMS
C-MAX	2013-2018	●
Edge	2011-2019	●
Escape	2013-2019	●
Expedition	2005-2019	●
Explorer	2011-2019	●
F-Series	2011-2019	●
Flex	2013-2019	●
Focus	2012-2016	●
Focus	2017-2018	●
Focus C-MAX	2015-2019	●
Ford GT	2017-2018	●
Galaxy	2015-2019	●
Kuga	2013-2019	●
Mondeo	2013-2019	●
Mustang	2011-2019	●
S-Max	2015-2019	●
Taurus	2013-2019	●
Troller	2011-2015	●
Continental	2000-2017	●
Escort	2005-2015	●
Everest	1999-2016	●
F-150	2003-2019	●
Fiesta	2005-2015	●
Fusion	2002-2017	●
MKC	2005-2019	●
MKS	2005-2018	●
MKT	2007-2019	●
MKX	2003-2016	●
MKZ	2006-2017	●
Mariner	2009-2019	●
Milan	2005-2015	●
Navigator	2001-2014	●
Ranger	1998-2012	●
Transit	2007-2019	●
Transit Connect	1997-2012	●
Tribute	2005-2015	●
Zephyr	2000-2010	●

BMS Function List

R-mode Rebalance

BMS(Battery Monitoring System) Resetting