

FORD ETC Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	ETC
B-Max	ALL	●
C-MAX	2013-2018	●
Crown Victoria	2002-2011	●
E-Series	2004-2016	●
EcoSport	2003-2012	●
Edge	2007-2019	●
Escape	2001-2019	●
Expedition	2005-2019	●
Expedition EL	2007-2014	●
Explorer	2001-2019	●
Explorer SportTrac	2007-2010	●
F-Series	2003-2019	●
Fairlane/LTD	2006-	●
Fairmont	2006-	●
Falcon	2003-2014	●
Fiesta	1996-2007	●
FIGO	2010-2017	●
Five Hundred	2005-2007	●
Flex	2009-2019	●
Focus	2003-2011	●
Focus Cabriolet	2006-2008	●
Focus C-MAX	2011-2014	●
Ford GT	2017-2018	●
Freestar	2004-2007	●
Freestyle	2005-2007	●
Fusion	2006-2019	●
Galaxy	2006-2015	●
KA	2008-2017	●
Kuga	2008-2019	●
Maverick	2005-2007	●
Mondeo	2017-2019	●
Motorhome	2006-2019	●
Mustang	2005-2019	●
V6 SOHC	2003-2011	●
S-Max	2006-2015	●
Scorpio	1995-1996	●
Step Van	2006-2019	●
Stripped Chassis	2006-2019	●
Taurus	2003-2019	●
Taurus X	2008-2009	●
Territory	2004-2013	●
Thunderbird	2002-2005	●
Transit	2010-2013	●
Transit Courier	ALL	●
Troller	2011-2015	●
Bantam	2003-2019	●

Blue Bird C-Class Vision	2003-2019	●
Continental	2003-2018	●
Courier	2003-2019	●
Escape	2006-2019	●
Escort	2004-2016	●
Everest	2003-2019	●
Excursion	2005-2019	●
F-150	2003-2017	●
F-650	2003-2019	●
F-750	2007-2015	●
Fiesta	2003-2019	●
Five Hundred	2003-2019	●
Freestar	2005-2019	●
Granada	2003-2015	●
Grand Marquis	2005-2017	●
Ikon	2003-2019	●
Ka	2003-2019	●
Kuga	2007-2019	●
LS	2003-2016	●
MKC	2003-2011	●
MKS	2009-2019	●
MKT	2003-2019	●
MKX	2003-2015	●
MKX/Nautilus	2003-2012	●
MKZ	2001-2019	●
Mariner	2002-2019	●
Mark LT	2003-2014	●
Milan	2006-2019	●
Montego	2003-2012	●
Mountaineer	2000-2019	●
NOVO KA	2003-2019	●
Navigator	2003-2018	●
Navigator L	2003-2019	●
Ranger	2003-2014	●
S-Max	2000-2019	●
Sable	2003-2019	●
Scorpio	2003-2010	●
Street Ka	2001-2019	●
Town Car	2003-2019	●
Transit Connect	2003-2018	●
i-MAX	2003-2019	●

ETC Function List

Reset the intake Air Throttle Valve Learned Values
Reset the Throttle Body Learned Values
Reset KAM(Keep Alive Memory)
Reset KAM(Keep Alive Memory) - PCM
ETB / EGR Initialization
ETB Check
Electronic Throttle Control
Reset KAM(Keep Alive Memory) - TCM
Reset KAM(Keep Alive Memory) - SOBDM-C