GTR TPM Function List (Note: For reference only) NOTES: • This function is supported. * This function may be supported, which depends on the actual condition of the vehicle. O This function is not supported. ▲ This function is the new feature in this version. Vehicle Model Year NISSAN GT-R ALL Europe NISSAN GT-R NISMO ALL Europe NISSAN GT-R ALL Japan NISSAN GT-R NISMO ALL Japan NISSAN GT-R ALL Middle and Near East NISSAN GT-R NISMO ALL Middle and Near East NISSAN GT-R (GCC) ALL Middle and Near East NISSAN GT-R(US) ALL Middle and Near East North America NISSAN GT-R ALL NISSAN GT-R NISMO North America ALL NISSAN GT-R ALL Latin America NISSAN GT-R NISMO ALL Latin America NISSAN GT-R ALL Far East NISSAN GT-R NISMO ALL Far East NISSAN GT-R Oceania ALL NISSAN GT-R NISMO Oceania ALL NISSAN GT-R ALL Africa Function Type Support **※** TPM

		1		
-				
	 		·	