

HYUNDAI_V01.15 INJ Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Disdriect	Vehicle	INJ
General	Accent (MC)	●
General	Accent (RB)	●
General	Azera (TG)	●
General	Elantra Neos (FD)	●
General	Elantra (HD)	●
General	Elantra (MDI)	●
General	Elantra (XD)	●
General	Getz (TB)	●
General	Grand i10 (BA)	●
General	Grand Santafe (NC)	●
General	Grandeur (TG)	●
General	H-1 (A1)	●
General	H-1 (TQ)	●
General	H-100 Truck (HR)	●
General	i10 (PA)	●
General	i20 (GB)	●
General	i20 (IB)	●
General	i20 (PB)	●
General	i30 (FD)	●
General	i30 (FDe)	●
General	i30 (GD)	●
General	i30 (GDe)	●
General	i40 (VF)	●
General	Iload (TQ)	●
General	Imax (TQ)	●
General	ix20 (JC)	●
General	ix35 (EL)	●
General	ix35 (LM)	●
General	ix55 (EN)	●
General	Matrix (FC)	●
General	Santafe (CM)	●
General	Santafe (DM)	●
General	Santafe (DMI)	●
General	Sonata (NF)	●
General	Terracan (HP)	●
General	Tucson (JM)	●
General	Tucson (LM)	●
General	Veracruz (EN)	●
General	Verna (RBI)	●
General	Xcent (BA)	●