

## INFINITI\_V01.15 BMS Function List (Note:For reference only)

NOTES:

- This function is supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported.

▲ This function is the new feature in this version.

Vehicle	BMS
ESQ	●
EX25/EX35	●
EX25/EX37	●
EX35	●
EX37	●
FX35/FX45	●
FX35/FX50	●
FX35/FX50/FX30d	●
FX37	●
FX37/FX50	●
FX37/FX50/FX30d	●
G20	●
G25/G37 Sedan	●
G35	●
G37	●
I30	●
I35	●
Infiniti M35/M45	●
Infiniti Q70L	●
JX35	●
M25/M37	●
M25/M37/M56	●
M35h	●
M37	●
M37/M30d	●
M37/M56	●
M37/M56/M30d	●
M45	●
Q40 Sedan	●
Q45	●
Q50	●
Q60	●
Q70	●
QX4	●
QX50	●
QX56	●
QX60	●
QX70	●
QX80	●