

Jaguar BMS Fuction List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

VehicleType	ModelYear	Engine	BMS
XE	2016	GTDI 2.0L	●
XE	2016	Diese I4 2.0L	●
XE	2016	Supercharged V6 3.0L	●
XE	2017	GTDI 2.0L	●
XE	2017	Diese I4 2.0L	●
XE	2017	Supercharged V6 3.0L	●
XE	2018-	V8 5.0L Petrol	●
XE	2018-	GTDI 2.0L Petrol	●
XE	2018-	V6 3.0L Diesel	●
XE	2018-	AJ200D 2.0L Diesel	●
XE	2018-	V6 3.0L Petrol	●
XE	2018-	AJ200D 2.0L Petrol	●
XF	2008-2009	Normally aspirated V6	●
XF	2008-2009	Normally aspirated V8	●
XF	2008-2009	Diese V6	●
XF	2008-2009	Supercharged V8	●
XF	2010-2011	Normally aspirated V6	●
XF	2010-2011	Diese V6	●
XF	2010-2011	Normally aspirated V8 5.0L	●
XF	2010-2011	Supercharged V8 5.0L	●
XF	2010-2011	Normally aspirated V8 4.2L	●
XF	2012	Normally aspirated V6	●
XF	2012	Diese V6	●
XF	2012	Normally aspirated V8 5.0L	●
XF	2012	Supercharged V8 5.0L	●
XF	2012	Diese I4 2.2L	●
XF	2013-2015	Diese V6	●
XF	2013-2015	Supercharged V8 5.0L	●
XF	2013-2015	Diese I4 2.2L	●
XF	2013-2015	GTDI 2.0L	●
XF	2013-2015	Supercharged V6	●
XF	2016-2017	Diese V6	●
XF	2016-2017	GTDI 2.0L	●
XF	2016-2017	Diese I4 2.0L	●
XF	2016-2017	Supercharged V6 3.0L	●
XF	2018-	V8 5.0L Petrol	●
XF	2018-	GTDI 2.0L	●
XF	2018-	V6 3.0L Diesel	●
XF	2018-	AJ200D 2.0L Diesel	●
XF	2018-	V6 3.0L Petrol	●
XF	2018-	AJ200P 2.0L Petrol	●
XJ	2010-2012	Diese V6	●
XJ	2010-2012	Normally aspirated V8 5.0L	●
XJ	2010-2012	Supercharged V8 5.0L	●

XJ	2010-2012	Normally aspirated V6 3.0L	●
XJ	2013-2015	Diese V6	●
XJ	2013-2015	Normally aspirated V8 5.0L	●
XJ	2013-2015	Supercharged V8 5.0L	●
XJ	2013-2015	GTDI 2.0L	●
XJ	2013-2015	Supercharged V6	●
XJ	2016-	Diese V6	●
XJ	2016-	Supercharged V8 5.0L	●
XJ	2016-	GTDI 2.0L	●
XJ	2016-	Supercharged V6	●
XK	2010-2015	Normally aspirated V8	●
XK	2010-2015	Supercharged V8	●
F_Type	2014-2015	Supercharged V8 5.0L	●
F_Type	2014-2015	Supercharged V6 3.0L	●
F_Type	2016-2017	Supercharged V8 5.0L	●
F_Type	2016-2017	Supercharged V6 3.0L	●
F_Type	2018-	V8 5.0L Petrol	●
F_Type	2018-	V6 3.0L Petrol	●
F_Type	2018-	AJ200P 2.0L Petrol	●
E-Pace	2018	204PT 2.0L Petrol	●
E-Pace	2018	204PT 2.0L Diese	●
E-Pace	2018	204DT 2.0L Diese	●
E-Pace	2018	1.5L Petrol	●
E-Pace	2018	AJ200P 2.0L Petrol	●
F Pace	2017	Diese V6	●
F Pace	2017	GTDI 2.0L	●
F Pace	2017	Diesel I4 2.0L	●
F Pace	2017	Supercharged V6 3.0L	●
F Pace	2018	V8 5.0L Petrol	●
F Pace	2018	GTDI 2.0L Petrol	●
F Pace	2018	V6 3.0L Diesel	●
F Pace	2018	AJ200D 2.0L Diesel	●
F Pace	2018	V6 3.0L Petrol	●
F Pace	2018	AJ200P 2.0L Petrol	●
I Pace	2019-	NONE	●

### BMS Function List

Battery Replacement
Quiescent Current Control Module Internal Check
Test Dual Battery System
Verify Secondary Battery Charging
Hybrid Electric Vehicle Battery Pack Coolant Pump Replacement
Telematics Control Module Battery Replacement Reset
Test Internal Backup Battery