

Jaguar ECM Fuction List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

VehicleType	ModelYear	Engine	ECM
XE	2016	GTDI 2.0L	●
XE	2016	Diese I4 2.0L	●
XE	2016	Supercharged V6 3.0L	●
XE	2017	GTDI 2.0L	●
XE	2017	Diese I4 2.0L	●
XE	2017	Supercharged V6 3.0L	●
XE	2018-	V8 5.0L Petrol	●
XE	2018-	GTDI 2.0L Petrol	●
XE	2018-	V6 3.0L Diesel	●
XE	2018-	AJ200D 2.0L Diesel	●
XE	2018-	V6 3.0L Petrol	●
XE	2018-	AJ200D 2.0L Petrol	●
XF	2008-2009	Normally aspirated V6	●
XF	2008-2009	Normally aspirated V8	●
XF	2008-2009	Diese V6	●
XF	2008-2009	Supercharged V8	●
XF	2010-2011	Normally aspirated V6	●
XF	2010-2011	Diese V6	●
XF	2010-2011	Normally aspirated V8 5.0L	●
XF	2010-2011	Supercharged V8 5.0L	●
XF	2010-2011	Normally aspirated V8 4.2L	●
XF	2012	Normally aspirated V6	●
XF	2012	Diese V6	●
XF	2012	Normally aspirated V8 5.0L	●
XF	2012	Supercharged V8 5.0L	●
XF	2012	Diese I4 2.2L	●
XF	2013-2015	Diese V6	●
XF	2013-2015	Supercharged V8 5.0L	●
XF	2013-2015	Diese I4 2.2L	●
XF	2013-2015	GTDI 2.0L	●
XF	2013-2015	Supercharged V6	●
XF	2016-2017	Diese V6	●
XF	2016-2017	GTDI 2.0L	●
XF	2016-2017	Diese I4 2.0L	●
XF	2016-2017	Supercharged V6 3.0L	●
XF	2018-	V8 5.0L Petrol	●
XF	2018-	GTDI 2.0L	●
XF	2018-	V6 3.0L Diesel	●
XF	2018-	AJ200D 2.0L Diesel	●
XF	2018-	V6 3.0L Petrol	●
XF	2018-	AJ200P 2.0L Petrol	●
XJ	2006-2007	Normally aspirated V6	●
XJ	2006-2007	Diese V6	●
XJ	2006-2007	Supercharged V8	●

XJ	2006-2007	Normally aspirated V8 3.5L	●
XJ	2006-2007	Normally aspirated V8 4.2L	●
XJ	2008-2009	Normally aspirated V6	●
XJ	2008-2009	Diese V6	●
XJ	2008-2009	Supercharged V8	●
XJ	2008-2009	Normally aspirated V8 3.5L	●
XJ	2008-2009	Normally aspirated V8 4.2L	●
XJ	2010-2012	Diese V6	●
XJ	2010-2012	Normally aspirated V8 5.0L	●
XJ	2010-2012	Supercharged V8 5.0L	●
XJ	2010-2012	Normally aspirated V6 3.0L	●
XJ	2013-2015	Diese V6	●
XJ	2013-2015	Normally aspirated V8 5.0L	●
XJ	2013-2015	Supercharged V8 5.0L	●
XJ	2013-2015	GTDI 2.0L	●
XJ	2013-2015	Supercharged V6	●
XJ	2016-	Diese V6	●
XJ	2016-	Supercharged V8 5.0L	●
XJ	2016-	GTDI 2.0L	●
XJ	2016-	Supercharged V6	●
XK	2006-2009	Supercharged V8	●
XK	2006-2009	Normally aspirated V8 3.5L	●
XK	2006-2009	Normally aspirated V8 4.2L	●
XK	2010-2015	Normally aspirated V8	●
XK	2010-2015	Supercharged V8	●
F_Type	2014-2015	Supercharged V8 5.0L	●
F_Type	2014-2015	Supercharged V6 3.0L	●
F_Type	2016-2017	Supercharged V8 5.0L	●
F_Type	2016-2017	Supercharged V6 3.0L	●
F_Type	2018-	V8 5.0L Petrol	●
F_Type	2018-	V6 3.0L Petrol	●
F_Type	2018-	AJ200P 2.0L Petrol	●
S_Type	2004-2005	Diese V6	●
S_Type	2004-2005	AJ61 2.5L	●
S_Type	2004-2005	AJ61 3.0L	●
S_Type	2004-2005	AJ61 4.2L	●
S_Type	2006-2008	Normally aspirated V8	●
S_Type	2006-2008	Diese V6	●
S_Type	2006-2008	Supercharged V8	●
S_Type	2006-2008	Normally aspirated V6 3.0L	●
S_Type	2006-2008	Normally aspirated V6 2.5L	●
E-Pace	2018	204PT 2.0L Petrol	●
E-Pace	2018	204PT 2.0L Diese	●
E-Pace	2018	204DT 2.0L Diese	●
E-Pace	2018	1.5L Petrol	●
E-Pace	2018	AJ200P 2.0L Petrol	●
F Pace	2017	Diese V6	●
F Pace	2017	GTDI 2.0L	●
F Pace	2017	Diesel I4 2.0L	●
F Pace	2017	Supercharged V6 3.0L	●
F Pace	2018	V8 5.0L Petrol	●
F Pace	2018	GTDI 2.0L Petrol	●

F_Pace	2018	V6 3.0L Diesel	●
F_Pace	2018	AJ200D 2.0L Diesel	●
F_Pace	2018	V6 3.0L Petrol	●
F_Pace	2018	AJ200P 2.0L Petrol	●
I_Pace	2019-	NONE	●

ECM Function List

Fuel Prime Routine
Oxidation Catalyst
Boost Pressure Actuator Replacement
Speed Limitation
Exhaust Gas Recirculation Replacement
Diesel Lambda Sensor Replacement
Oxygen Sensor
Turbine Shut-off Valve
Activate Glow Plug Control
Adaptive Fuel Trim Display
Diesel Exhaust Fluid Injection Pump Replacement
Diesel Exhaust Fluid Prime And Pressure Test
Diesel Exhaust Fluid Tank Level Sensor Replacement
Enable/disable Glow Plugs
Engine Control Module Reset Crank Case Pressure Sensor
Engine Control Module Reset Fuel Pump Adaption
Evaporative System Diagnostic Test
Evaporative System Leak Check
Exhaust Gas Recirculation Valve Replacement Reset
Fuel Lift Pump
Fuel Pump Supply - Enable/disable
High Pressure Fuel Pump Replacement Reset
High Pressure Injection Pump Replacement
Lambda Sensor Gain Adjustment Reset
Pilot Correction Learning
Purge Valve Self Test
Reset Selective Catalyst Reduction Start Inhibit
Reset Selective Catalyst Reduction Start Inhibit
Turbocharger Replacement Reset
Diesel Fueling Adaption Re-initialization
Exhaust Gas Recirculation Valve
Reset Water In Fuel Detection
Engine Fuel Priming Routine
Exhaust Gas Recirculation Throttle Replacement Reset
Throttle Valve Actuator Replacement
Check Engine Oil Level
Low Pressure Egr Adaption Clear
Swirl Valve Adaption Clear