

Jaguar_V11.20 BMS Fuction List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

VehicleType	ModelYear	Engine Type	BMS
XJ	2016	2.0L GTDi (P)	●
XJ	2016	Diesel V6	●
XJ	2016	Supercharged V6	●
XJ	2016	Supercharged V8	●
XJ	2013-2015	2.0L GTDi (P)	●
XJ	2013-2015	Supercharged V6	●
XJ	2013-2015	Normally aspirated V8	●
XJ	2013-2015	Supercharged V8	●
XJ	2013-2015	Diesel V6	●
XJ	2010-2012	Normally aspirated V6	●
XJ	2010-2012	Normally aspirated V8	●
XJ	2010-2012	Supercharged V8	●
XJ	2010-2012	Diesel V6	●
XE	2017-	2.0L GTDi (P)	●
XE	2017-	Diesel I4	●
XE	2017-	Supercharged V6	●
XE	2016	2.0L GTDi (P)	●
XE	2016	Diesel I4	●
XE	2016	Supercharged V6	●
XF	2016	2.0L GTDi (P)	●
XF	2016	Diesel I4	●
XF	2016	Diesel V6	●
XF	2016	Supercharged V6	●
XF	2013-2015	Diesel I4	●
XF	2013-2015	Diesel V6	●
XF	2012	Normally aspirated V6	●
XF	2012	Normally aspirated V8	●
XF	2012	Supercharged V8	●
XF	2012	Diesel I4	●
XF	2012	Diesel V6	●
XF	2010-2011	Normally aspirated V6	●
XF	2010-2011	Normally aspirated V8 (4.2L)	●
XF	2010-2011	Normally aspirated V8 (5.0L)	●
XF	2010-2011	Supercharged V8	●
XF	2010-2011	Diesel V6	●
XF	2008-2009	Normally aspirated V6	●
XF	2008-2009	Normally aspirated V8	●
XF	2008-2009	Supercharged V8	●
XF	2008-2009	Diesel V6	●
XK	2010-2015	Normally aspirated V8	●
XK	2010-2015	Supercharged V8	●
F-PACE	2017-	2.0L GTDi (P)	●
F-PACE	2017-	Diesel I4	●
F-PACE	2017-	Diesel V6	●
F-PACE	2017-	Supercharged V6	●
F-TYPE	2016-	Supercharged V6	●
F-TYPE	2016-	Supercharged V8	●
F TYPE	2014-2015	Supercharged V6	●
F TYPE	2014-2015	Supercharged V8	●