

OPEL BMS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	BMS
2012	Ampera	●
2012	Combo-D	●
2013	Ampera	●
2013	Combo-D	●
2014	Ampera	●
2014	Combo-D	●
2015	Ampera	●
2015	Combo-D	●
2016	Combo-D	●
2017	Ampera-E	●
2017	Combo-D	●
2017	Crossland-X	●
2018	Ampera-E	●
2018	Combo-D	●
2018	Crossland-X	●
2018	Grandland-X	●
2019	Ampera-E	●
2019	Crossland-X	●
2019	Grandland-X	●
2020	Crossland-X	●
2020	Grandland-X	●

BMS Function List

Battery Learn

Battery Learned Values Reset

Battery Saver Mode

Battery Sensor Module Learn

Battery State of Charge Reset

Hybrid/EV Battery Contactor Open Reasons Reset

Hybrid/EV Battery Pack Capacity Learn

Hybrid/EV Battery Pack Charging Adaptive Learn Reset

Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn

Hybrid/EV Battery Pack Data Reset