

OPEL Diagnostic Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData	Actuation Test
1997	Astra-F	ECM (Engine Control Module)	●	●	●	●	※
1997	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
1997	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1997	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1997	Calibra	ECM (Engine Control Module)	※	●	●	●	※
1997	Calibra	IMMO (Immobiliser)	※	●	●	●	※
1997	Corsa-B	ECM (Engine Control Module)	※	●	●	●	※
1997	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
1997	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
1997	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1997	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1997	Frontera	IMMO (Immobiliser)	※	●	●	●	※
1997	Monterey	IMMO (Immobiliser)	※	●	●	●	※
1997	Omega-B	AR 25/35	※	●	●	●	※
1997	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
1997	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
1997	Sintra	BCM (Body Control Module)	※	●	●	●	※
1997	Sintra	IMMO (Immobiliser)	※	●	●	●	※
1997	Tigra	ECM (Engine Control Module)	※	●	●	●	※
1997	Tigra	IMMO (Immobiliser)	※	●	●	●	※
1997	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
1997	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
1998	Arena	IMMO (Immobiliser)	※	●	●	●	※
1998	Astra-F	ECM (Engine Control Module)	●	●	●	●	※
1998	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
1998	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
1998	Astra-G	Cruise Control	●	●	●	●	※
1998	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
1998	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1998	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1998	Corsa-B	ECM (Engine Control Module)	※	●	●	●	●
1998	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
1998	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
1998	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1998	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1998	Frontera	IMMO (Immobiliser)	※	●	●	●	※
1998	Monterey	4L30-E	●	●	●	●	※
1998	Monterey	BCM (Body Control Module)	※	●	●	●	※
1998	Monterey	ECM (Engine Control Module)	●	●	●	●	※
1998	Monterey	IMMO (Immobiliser)	※	●	●	●	※
1998	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1998	Omega-B	AOH (Add On Heater)	※	●	●	●	●
1998	Omega-B	AR 25/35	※	●	●	●	※
1998	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
1998	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
1998	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
1998	Sintra	BCM (Body Control Module)	※	●	●	●	※
1998	Sintra	ECM (Engine Control Module)	※	●	●	●	※
1998	Sintra	IMMO (Immobiliser)	※	●	●	●	※
1998	Tigra	ECM (Engine Control Module)	※	●	●	●	※

1998	Tigra	IMMO (Immobiliser)	※	●	●	●	※
1998	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
1998	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1998	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
1998	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
1998	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
1999	Arena	IMMO (Immobiliser)	※	●	●	●	※
1999	Astra-F	ECM (Engine Control Module)	●	●	●	●	●
1999	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
1999	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
1999	Astra-G	Cruise Control	●	●	●	●	※
1999	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
1999	Astra-G	Info Display CART/CCRT	●	●	●	●	※
1999	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1999	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1999	Corsa-B	ECM (Engine Control Module)	※	●	●	●	●
1999	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
1999	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
1999	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1999	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1999	Frontera-B	4L30-E	●	●	●	●	※
1999	Frontera-B	ABS	●	●	●	●	※
1999	Frontera-B	AR 25/35	※	●	●	●	※
1999	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
1999	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
1999	Monterey	4L30-E	●	●	●	●	※
1999	Monterey	ECM (Engine Control Module)	●	●	●	●	※
1999	Monterey	IMMO (Immobiliser)	※	●	●	●	※
1999	Movano	IMMO (Immobiliser)	※	●	●	●	※
1999	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1999	Omega-B	AOH (Add On Heater)	※	●	●	●	●
1999	Omega-B	AR 25/35	※	●	●	●	※
1999	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
1999	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
1999	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
1999	Sintra	BCM (Body Control Module)	※	●	●	●	※
1999	Sintra	ECM (Engine Control Module)	※	●	●	●	※
1999	Sintra	IMMO (Immobiliser)	※	●	●	●	※
1999	Tigra	ECM (Engine Control Module)	※	●	●	●	※
1999	Tigra	IMMO (Immobiliser)	※	●	●	●	※
1999	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
1999	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1999	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
1999	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
1999	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
1999	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1999	Zafira	AF 13-II/17/20/22	※	●	●	●	※
1999	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
1999	Zafira	ECM (Engine Control Module)	※	●	●	●	※
1999	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
1999	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2000	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2000	Agila	ECM (Engine Control Module)	※	●	●	●	●
2000	Agila	IMMO (Immobiliser)	※	●	●	●	※
2000	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2000	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2000	Arena	IMMO (Immobiliser)	※	●	●	●	※
2000	Astra-F	ECM (Engine Control Module)	※	●	●	●	※

2000	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
2000	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2000	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2000	Astra-G	Cruise Control	●	●	●	●	※
2000	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2000	Astra-G	ESP (Electronic Stability Program)	※	●	●	●	※
2000	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2000	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2000	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2000	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2000	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2000	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2000	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2000	Corsa-B	ECM (Engine Control Module)	●	●	●	●	●
2000	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2000	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2000	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2000	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2000	Frontera-B	4L30-E	●	●	●	●	※
2000	Frontera-B	ABS	●	●	●	●	※
2000	Frontera-B	AR 25/35	※	●	●	●	※
2000	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2000	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2000	Movano	IMMO (Immobiliser)	※	●	●	●	※
2000	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2000	Omega-B	AR 25/35	※	●	●	●	※
2000	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2000	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2000	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2000	Tigra	ECM (Engine Control Module)	※	●	●	●	※
2000	Tigra	IMMO (Immobiliser)	※	●	●	●	※
2000	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2000	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
2000	Vectra-B	AF 13-II/17/20/22 CAN	※	●	●	●	●
2000	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
2000	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
2000	Vectra-B	Headlamp Adjustment(Left)	※	●	●	●	※
2000	Vectra-B	Headlamp Adjustment(Right)	※	●	●	●	※
2000	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Zafira	AF 13-II/17/20/22	※	●	●	●	※
2000	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2000	Zafira	ECM (Engine Control Module)	※	●	●	●	※
2000	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2000	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2000	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2000	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2001	Agila	ECM (Engine Control Module)	※	●	●	●	●
2001	Agila	IMMO (Immobiliser)	※	●	●	●	※
2001	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2001	Astra-F	ECM (Engine Control Module)	※	●	●	●	●
2001	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
2001	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2001	Astra-G	CDL (Central Door Lock)	※	●	●	※	●

2001	Astra-G	Cruise Control	●	●	●	●	※
2001	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2001	Astra-G	ESP (Electronic Stability Program)	※	●	●	●	※
2001	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2001	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2001	Astra-G	TU (Telematic unit)	●	●	●	※	※
2001	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2001	Astra-G-GMSA	ECM (Engine Control Module)	●	●	●	●	※
2001	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2001	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2001	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Campo	IMMO (Immobiliser)	※	●	●	●	※
2001	Corsa-B	ECM (Engine Control Module)	●	●	●	●	※
2001	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2001	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2001	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2001	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2001	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2001	Corsa-C	ECM (Engine Control Module)	※	●	●	●	●
2001	Frontera-B	ABS	●	●	●	●	※
2001	Frontera-B	AR 25/35	※	●	●	●	※
2001	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2001	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2001	Movano	IMMO (Immobiliser)	※	●	●	●	※
2001	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2001	Omega-B	AR 25/35	※	●	●	●	※
2001	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2001	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2001	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2001	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2001	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2001	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2001	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2001	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
2001	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
2001	Vectra-B	ECM (Engine Control Module)	●	●	●	●	※
2001	Vectra-B	Headlamp Adjustment(Left)	※	●	●	●	※
2001	Vectra-B	Headlamp Adjustment(Right)	※	●	●	●	※
2001	Vivaro	ABS (Anti-lock Braking System)	※	●	●	●	※
2001	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2001	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2001	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2001	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2001	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2001	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2001	Zafira	ECM (Engine Control Module)	●	●	●	●	※
2001	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2001	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2001	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2001	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2002	Agila	ECM (Engine Control Module)	※	●	●	●	●
2002	Agila	IMMO (Immobiliser)	※	●	●	●	※

2002	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2002	Astra-F	ECM (Engine Control Module)	※	●	●	●	●
2002	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
2002	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2002	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2002	Astra-G	Cruise Control	●	●	●	●	※
2002	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2002	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2002	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2002	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2002	Astra-G	TU (Telematic unit)	●	●	●	※	※
2002	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2002	Astra-G-GMSA	ECM (Engine Control Module)	●	●	●	●	※
2002	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2002	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2002	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Campo	IMMO (Immobiliser)	※	●	●	●	※
2002	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Combo	BCM (Body Control Module)	※	●	●	●	※
2002	Combo	ECM (Engine Control Module)	※	●	●	●	●
2002	Combo	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-B	ECM (Engine Control Module)	●	●	●	●	※
2002	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2002	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2002	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2002	Corsa-C	BCM (Body Control Module)	※	●	●	●	※
2002	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2002	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2002	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2002	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2002	Frontera-B	ABS	●	●	●	●	※
2002	Frontera-B	AR 25/35	※	●	●	●	※
2002	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2002	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2002	Movano	IMMO (Immobiliser)	※	●	●	●	※
2002	Omega-B	5L40-E	※	●	●	●	※
2002	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2002	Omega-B	AR 25/35	※	●	●	●	※
2002	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2002	Omega-B	ESP (Electronic Stability Program)	※	●	●	●	※
2002	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2002	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2002	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2002	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2002	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2002	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2002	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2002	Vectra-C-Signum	Driver information display	●	●	●	●	※
2002	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●

2002	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2002	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2002	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2002	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2002	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2002	Vivaro	ABS (Anti-lock Braking System)	※	●	●	●	※
2002	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2002	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2002	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2002	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2002	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2002	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2002	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2002	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2002	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2002	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2002	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2003	Agila	ECM (Engine Control Module)	※	●	●	●	●
2003	Agila	IMMO (Immobiliser)	※	●	●	●	※
2003	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2003	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2003	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2003	Astra-G	Cruise Control	●	●	●	●	※
2003	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2003	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2003	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2003	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2003	Astra-G	TU (Telematic unit)	●	●	●	※	※
2003	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2003	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2003	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2003	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2003	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Combo	AF 13-II/17/20/22	※	●	●	●	※
2003	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2003	Combo	AOH (Add On Heater)	※	●	●	●	●
2003	Combo	BCM (Body Control Module)	※	●	●	●	※
2003	Combo	ECM (Engine Control Module)	※	●	●	●	●
2003	Combo	IMMO (Immobiliser)	※	●	●	●	※
2003	Corsa-B	ECM (Engine Control Module)	●	●	●	●	※
2003	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2003	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2003	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2003	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2003	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2003	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2003	Corsa-C	BCM (Body Control Module)	※	●	●	●	※
2003	Corsa-C	ECM (Engine Control Module)	※	●	●	●	●
2003	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2003	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2003	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※

2003	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2003	Frontera-B	ABS	●	●	●	●	※
2003	Frontera-B	AR 25/35	※	●	●	●	※
2003	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2003	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2003	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2003	Meriva	ESP (Electronic Stability Program)	※	●	●	●	※
2003	Meriva	Easytronic (MTA)	●	●	●	●	※
2003	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2003	Movano	IMMO (Immobiliser)	※	●	●	●	※
2003	Omega-B	5L40-E	※	●	●	●	※
2003	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2003	Omega-B	AR 25/35	※	●	●	●	※
2003	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2003	Omega-B	ESP (Electronic Stability Program)	※	●	●	●	※
2003	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2003	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2003	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2003	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2003	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2003	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2003	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2003	Vectra-C-Signum	Driver information display	●	●	●	●	※
2003	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2003	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2003	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2003	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2003	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2003	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2003	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2003	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2003	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2003	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2003	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2003	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2003	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2003	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2003	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2003	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2003	Zafira	Headlamp Adjustment (Left)	※	●	●	●	※
2003	Zafira	Headlamp Adjustment (Right)	※	●	●	●	※
2003	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2003	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2004	Agila	ECM (Engine Control Module)	※	●	●	●	●
2004	Agila	IMMO (Immobiliser)	※	●	●	●	※
2004	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2004	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2004	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2004	Astra-G	Cruise Control	●	●	●	●	※
2004	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2004	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2004	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2004	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●

2004	Astra-G	TU (Telematic unit)	●	●	●	※	※
2004	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2004	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2004	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2004	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2004	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Astra-H	AF17-4	●	●	●	●	●
2004	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2004	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2004	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2004	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2004	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2004	Astra-H	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2004	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2004	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2004	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2004	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2004	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2004	Astra-H	PAS (Park pilot)	●	●	●	●	●
2004	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2004	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2004	Astra-H	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2004	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2004	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2004	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2004	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2004	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Combo	AF 13-II/17/20/22	※	●	●	●	※
2004	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2004	Combo	AOH (Add On Heater)	※	●	●	●	●
2004	Combo	BCM (Body Control Module)	※	●	●	●	※
2004	Combo	ECM (Engine Control Module)	●	●	●	●	●
2004	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2004	Combo	IMMO (Immobiliser)	※	●	●	●	※
2004	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2004	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2004	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2004	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2004	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2004	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2004	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2004	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2004	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2004	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2004	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2004	Meriva	AOH (Add On Heater)	※	●	●	●	●
2004	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2004	Meriva	ESP (Electronic Stability Program)	※	●	●	●	※
2004	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2004	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2004	Movano	ECM (Engine Control Module)	●	●	●	●	※
2004	Movano	IMMO (Immobiliser)	※	●	●	●	※
2004	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2004	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2004	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※

2004	Vauxhall-Monaro	ABS/ETC	●	●	●	●	※
2004	Vauxhall-Monaro	Audio system	●	●	●	●	※
2004	Vauxhall-Monaro	BCM (Body Control Module)	●	●	●	●	※
2004	Vauxhall-Monaro	ECM (Engine Control Module)	●	●	●	●	※
2004	Vauxhall-Monaro	GEN III automatic transmission	●	●	●	●	※
2004	Vauxhall-Monaro	IC (Instrument Cluster)	●	●	●	●	※
2004	Vauxhall-Monaro	OCC (Occupant climate control)	●	●	●	●	※
2004	Vauxhall-Monaro	PIM (Powertrain interface module)	●	●	●	●	●
2004	Vauxhall-Monaro	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2004	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2004	Vectra-C-Signum	CVTronic	●	●	●	※	●
2004	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2004	Vectra-C-Signum	Driver information display	●	●	●	●	※
2004	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2004	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2004	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2004	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2004	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2004	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2004	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2004	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2004	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2004	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2004	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2004	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2004	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2004	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2004	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2004	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2004	Zafira	Headlamp Adjustment(Left)	※	●	●	●	※
2004	Zafira	Headlamp Adjustment(Right)	※	●	●	●	※
2004	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2004	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2005	Agila	ECM (Engine Control Module)	●	●	●	●	●
2005	Agila	IMMO (Immobiliser)	※	●	●	●	※
2005	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2005	Astra-G	Cruise Control	●	●	●	●	※
2005	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2005	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2005	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2005	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2005	Astra-G	TU (Telematic unit)	●	●	●	※	※
2005	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2005	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2005	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2005	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2005	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Astra-H	AF17-4	●	●	●	●	●
2005	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2005	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2005	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2005	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Astra-H	ECM (Engine Control Module)	●	●	●	●	●

2005	Astra-H	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2005	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2005	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2005	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2005	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2005	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2005	Astra-H	PAS (Park pilot)	●	●	●	●	●
2005	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2005	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2005	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2005	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2005	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2005	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2005	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Combo	AF 13-II/17/20/22	※	●	●	●	※
2005	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2005	Combo	AOH (Add On Heater)	※	●	●	●	●
2005	Combo	BCM (Body Control Module)	※	●	●	●	※
2005	Combo	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Combo	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2005	Combo	ECM (Engine Control Module)	●	●	●	●	●
2005	Combo	EHU (Entertainment Head Unit)	●	●	●	※	※
2005	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2005	Combo	IMMO (Immobiliser)	※	●	●	●	※
2005	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2005	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2005	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2005	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2005	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2005	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2005	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2005	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2005	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2005	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2005	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2005	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2005	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Meriva	AOH (Add On Heater)	※	●	●	●	●
2005	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Meriva	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2005	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2005	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2005	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2005	Meriva	IMMO (Immobiliser)	※	●	●	●	※
2005	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2005	Movano	BCM (Body Control Module)	※	●	●	●	※
2005	Movano	ECM (Engine Control Module)	●	●	●	●	※
2005	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2005	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2005	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2005	Tigra-B	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2005	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2005	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2005	Tigra-B	Easytronic (MTA)	●	●	●	●	※

2005	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2005	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Vauxhall-Monaro	ABS/ETC	●	●	●	●	※
2005	Vauxhall-Monaro	Audio system	●	●	●	●	※
2005	Vauxhall-Monaro	Auxiliary gauges	●	●	●	●	※
2005	Vauxhall-Monaro	BCM (Body Control Module)	●	●	●	●	※
2005	Vauxhall-Monaro	ECM (Engine Control Module)	●	●	●	●	●
2005	Vauxhall-Monaro	GEN III automatic transmission	●	●	●	●	※
2005	Vauxhall-Monaro	Instrument	●	●	●	●	※
2005	Vauxhall-Monaro	OCC (Occupant climate control)	●	●	●	●	※
2005	Vauxhall-Monaro	PIM (Powertrain interface module)	●	●	●	●	※
2005	Vauxhall-Monaro	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2005	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2005	Vectra-C-Signum	CVTronic	●	●	●	※	●
2005	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2005	Vectra-C-Signum	Driver information display	●	●	●	●	※
2005	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2005	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2005	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2005	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2005	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2005	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2005	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2005	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2005	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2005	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2005	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2005	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2005	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2005	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2005	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2005	Zafira	Headlamp Adjustment(Left)	※	●	●	●	※
2005	Zafira	Headlamp Adjustment(Right)	※	●	●	●	※
2005	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2005	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2005	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2005	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2005	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2005	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2005	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2005	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2005	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2005	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2005	Zafira-B	PAS (Park pilot)	●	●	●	●	●
2005	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2005	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2005	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2005	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2005	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2005	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2005	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2006	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※

2006	Agila	ECM (Engine Control Module)	●	●	●	●	●
2006	Agila	IMMO (Immobiliser)	※	●	●	●	※
2006	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2006	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2006	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2006	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2006	Astra-G	Cruise Control	●	●	●	●	※
2006	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2006	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2006	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2006	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2006	Astra-G	TU (Telematic unit)	●	●	●	※	※
2006	Astra-H	AF 40-6	●	●	●	●	●
2006	Astra-H	AF17-4	●	●	●	●	●
2006	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2006	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2006	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2006	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2006	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2006	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2006	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2006	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2006	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2006	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2006	Astra-H	PAS (Park pilot)	●	●	●	●	●
2006	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2006	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2006	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2006	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2006	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2006	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2006	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2006	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2006	Combo	AF 13-II/17/20/22	※	●	●	●	※
2006	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2006	Combo	AOH (Add On Heater)	※	●	●	●	●
2006	Combo	BCM (Body Control Module)	※	●	●	●	※
2006	Combo	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Combo	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2006	Combo	ECM (Engine Control Module)	●	●	●	●	●
2006	Combo	EHU (Entertainment Head Unit)	●	●	●	※	※
2006	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2006	Combo	IMMO (Immobiliser)	※	●	●	●	※
2006	Combo	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2006	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2006	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2006	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2006	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2006	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2006	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2006	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2006	Meriva	AOH (Add On Heater)	※	●	●	●	●
2006	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※

2006	Meriva	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2006	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2006	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2006	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2006	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2006	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2006	Movano	BCM (Body Control Module)	※	●	●	●	※
2006	Movano	G9U 750 (2.5l)	●	●	●	●	※
2006	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2006	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2006	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2006	Tigra-B	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2006	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2006	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2006	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2006	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2006	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2006	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2006	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2006	Vauxhall-Monaro	ABS/ETC	●	●	●	●	※
2006	Vauxhall-Monaro	Audio system	●	●	●	●	※
2006	Vauxhall-Monaro	Auxiliary gauges	●	●	●	●	※
2006	Vauxhall-Monaro	Body Control Module	●	●	●	●	※
2006	Vauxhall-Monaro	ECM (Engine Control Module)	●	●	●	●	●
2006	Vauxhall-Monaro	GEN III automatic transmission	●	●	●	●	※
2006	Vauxhall-Monaro	Instrument	●	●	●	●	※
2006	Vauxhall-Monaro	OCC (Occupant climate control)	●	●	●	●	※
2006	Vauxhall-Monaro	PIM (Powertrain interface module)	●	●	●	●	※
2006	Vauxhall-Monaro	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2006	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2006	Vectra-C-Signum	CVTronic	●	●	●	※	●
2006	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2006	Vectra-C-Signum	Driver information display	●	●	●	●	※
2006	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2006	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2006	Vectra-C-Signum	EHS (Electrical Heater System)	●	●	●	●	●
2006	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2006	Vectra-C-Signum	IL (Interior Lighting)	●	●	●	●	●
2006	Vectra-C-Signum	MTA (Easytronic)	●	●	●	●	●
2006	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2006	Vectra-C-Signum	SAC (Automatic Climate Control)	●	●	●	●	●
2006	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2006	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2006	Vectra-C-Signum	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2006	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2006	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2006	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2006	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2006	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2006	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2006	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2006	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2006	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※

2006	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2006	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2006	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2006	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2006	Zafira-B	IPC (Instrument Control Unit)	●	●	●	●	●
2006	Zafira-B	PAS (Park pilot)	●	●	●	●	●
2006	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2006	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2006	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2006	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2006	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2006	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2006	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2007	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2007	Agila	ECM (Engine Control Module)	●	●	●	●	●
2007	Agila	IMMO (Immobiliser)	※	●	●	●	※
2007	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2007	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2007	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2007	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2007	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2007	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2007	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2007	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2007	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2007	Astra-G	Cruise Control	●	●	●	●	※
2007	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2007	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2007	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2007	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2007	Astra-G	TU (Telematic unit)	●	●	●	※	※
2007	Astra-H	AF 40-6	●	●	●	●	●
2007	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2007	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2007	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2007	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2007	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2007	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2007	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2007	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2007	Astra-H	IMMO (Immobiliser)	●	●	●	●	●

2007	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2007	Astra-H	PAS (Park pilot)	●	●	●	●	●
2007	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2007	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2007	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2007	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2007	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2007	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2007	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2007	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2007	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2007	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2007	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2007	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2007	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2007	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2007	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2007	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2007	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2007	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2007	Combo	AOH (Add On Heater)	※	●	●	●	●
2007	Combo	BCM (Body Control Module)	※	●	●	●	※
2007	Combo	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Combo	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2007	Combo	ECM (Engine Control Module)	●	●	●	●	●
2007	Combo	EHU (Entertainment Head Unit)	●	●	●	※	※
2007	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2007	Combo	IMMO (Immobiliser)	※	●	●	●	※
2007	Combo	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2007	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2007	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2007	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2007	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2007	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2007	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Corsa-D	AF 13-4	●	●	●	●	●
2007	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2007	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2007	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2007	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2007	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2007	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2007	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2007	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2007	Meriva	AOH (Add On Heater)	※	●	●	●	●
2007	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Meriva	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2007	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2007	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2007	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2007	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2007	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2007	Movano	BCM (Body Control Module)	※	●	●	●	※

2007	Movano	ECM (Engine Control Module)	●	●	●	●	※
2007	Movano	MTA (Tecshift)	●	●	●	●	●
2007	Movano	PP (Park Pilot)	※	●	●	●	※
2007	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2007	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2007	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2007	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2007	Tigra-B	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2007	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2007	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2007	Tigra-B	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2007	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2007	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2007	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2007	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2007	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2007	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2007	Vauxhall-VXR8	Audio system	●	●	●	●	※
2007	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2007	Vauxhall-VXR8	Driver information display	●	●	●	●	※
2007	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2007	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2007	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2007	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2007	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2007	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2007	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2007	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2007	Vauxhall-VXR8	Telematics	●	●	●	●	※
2007	Vauxhall-VXR8	V8 GEN IV	●	●	●	●	●
2007	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2007	Vectra-C-Signum	CVTronic	●	●	●	※	●
2007	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2007	Vectra-C-Signum	Driver information display	●	●	●	●	※
2007	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2007	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2007	Vectra-C-Signum	EHS (Electrical Heater System)	●	●	●	●	●
2007	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2007	Vectra-C-Signum	IL (Interior Lighting)	●	●	●	●	●
2007	Vectra-C-Signum	MTA (Easytronic)	●	●	●	●	●
2007	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2007	Vectra-C-Signum	SAC (Automatic Climate Control)	●	●	●	●	●
2007	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2007	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2007	Vectra-C-Signum	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2007	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2007	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2007	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2007	Vivaro	MTA (Tecshift)	●	●	●	●	●
2007	Vivaro	PP (Park Pilot)	※	●	●	●	※
2007	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2007	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2007	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●

2007	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2007	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2007	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2007	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2007	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2007	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2007	Zafira-B	PAS (Park pilot)	●	●	●	●	●
2007	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2007	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2007	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2007	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2007	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2007	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2007	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2008	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2008	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2008	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2008	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2008	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2008	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2008	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2008	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2008	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2008	Astra-G	Cruise Control	●	●	●	●	※
2008	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2008	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2008	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2008	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2008	Astra-G	TU (Telematic unit)	●	●	●	※	※
2008	Astra-H	AF 40-6	●	●	●	●	●
2008	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2008	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2008	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2008	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2008	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2008	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2008	Astra-H	IC (Instrument Cluster)	●	●	●	●	●

2008	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2008	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2008	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2008	Astra-H	PAS (Park pilot)	●	●	●	●	●
2008	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2008	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2008	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2008	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2008	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2008	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2008	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2008	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2008	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2008	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2008	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2008	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2008	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2008	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2008	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2008	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2008	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2008	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2008	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2008	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2008	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2008	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2008	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Corsa-D	AF 13-4	●	●	●	●	●
2008	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2008	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2008	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2008	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2008	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2008	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2008	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2008	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2008	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2008	Meriva	AOH (Add On Heater)	※	●	●	●	●
2008	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Meriva	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2008	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2008	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2008	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2008	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2008	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2008	Movano	BCM (Body Control Module)	※	●	●	●	※
2008	Movano	ECM (Engine Control Module)	●	●	●	●	※
2008	Movano	MTA (Tecshift)	●	●	●	●	●
2008	Movano	PP (Park Pilot)	※	●	●	●	※
2008	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2008	Tigra-B	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2008	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2008	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●

2008	Tigra-B	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2008	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2008	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2008	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2008	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2008	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2008	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2008	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2008	Vauxhall-VXR8	Audio system	●	●	●	●	※
2008	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2008	Vauxhall-VXR8	Driver information display	●	●	●	●	※
2008	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2008	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2008	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2008	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2008	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2008	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2008	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2008	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2008	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2008	Vauxhall-VXR8	Telematics	●	●	●	●	※
2008	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2008	Vectra-C-Signum	CVTronic	●	●	●	※	●
2008	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2008	Vectra-C-Signum	Driver information display	●	●	●	●	※
2008	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2008	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2008	Vectra-C-Signum	EHS (Electrical Heater System)	●	●	●	●	●
2008	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2008	Vectra-C-Signum	IL (Interior Lighting)	●	●	●	●	●
2008	Vectra-C-Signum	MTA (Easytronic)	●	●	●	●	●
2008	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2008	Vectra-C-Signum	SAC (Automatic Climate Control)	●	●	●	●	●
2008	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2008	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2008	Vectra-C-Signum	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2008	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2008	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2008	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2008	Vivaro	MTA (Tecshift)	●	●	●	●	●
2008	Vivaro	PP (Park Pilot)	※	●	●	●	※
2008	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2008	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2008	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2008	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2008	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2008	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2008	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2008	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2008	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2008	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2008	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2008	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2008	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2008	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※

2008	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2008	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2008	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2009	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2009	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2009	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2009	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2009	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2009	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2009	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2009	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2009	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2009	Astra-G	Cruise Control	●	●	●	●	※
2009	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2009	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2009	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2009	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2009	Astra-G	TU (Telematic unit)	●	●	●	※	※
2009	Astra-H	AF 40-6	●	●	●	●	●
2009	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2009	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2009	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2009	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2009	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2009	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2009	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2009	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2009	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2009	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2009	Astra-H	PAS (Park pilot)	●	●	●	●	●
2009	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2009	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2009	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2009	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2009	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2009	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2009	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●

2009	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2009	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2009	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2009	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2009	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2009	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2009	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2009	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2009	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2009	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2009	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2009	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2009	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2009	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2009	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2009	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Corsa-D	AF 13-4	●	●	●	●	●
2009	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2009	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2009	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2009	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2009	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2009	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2009	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2009	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2009	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Insignia	BCM (Body Control Module)	●	●	●	●	●
2009	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2009	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2009	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2009	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2009	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2009	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2009	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2009	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2009	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2009	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2009	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2009	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2009	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2009	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2009	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2009	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2009	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2009	Insignia	RADIO (Radio)	●	●	●	●	●
2009	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2009	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2009	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2009	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2009	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2009	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2009	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2009	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2009	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2009	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2009	Meriva	AOH (Add On Heater)	※	●	●	●	●

2009	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Meriva	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2009	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2009	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2009	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2009	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2009	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2009	Movano	BCM (Body Control Module)	※	●	●	●	※
2009	Movano	ECM (Engine Control Module)	●	●	●	●	※
2009	Movano	MTA (Tecshift)	●	●	●	●	●
2009	Movano	PP (Park Pilot)	※	●	●	●	※
2009	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2009	Tigra-B	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2009	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2009	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2009	Tigra-B	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2009	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2009	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2009	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2009	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2009	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2009	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2009	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2009	Vauxhall-VXR8	Audio system	●	●	●	●	※
2009	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2009	Vauxhall-VXR8	Driver information display	●	●	●	●	※
2009	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2009	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2009	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2009	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2009	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2009	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2009	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2009	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2009	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2009	Vauxhall-VXR8	Telematics	●	●	●	●	※
2009	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2009	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2009	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2009	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2009	Vivaro	MTA (Tecshift)	●	●	●	●	●
2009	Vivaro	PP (Park Pilot)	※	●	●	●	※
2009	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2009	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2009	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2009	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2009	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2009	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2009	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2009	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2009	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2009	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2009	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2009	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2009	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●

2009	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2009	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2009	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2009	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2010	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2010	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2010	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2010	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2010	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2010	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2010	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2010	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2010	Astra-G	Cruise Control	●	●	●	●	※
2010	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2010	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2010	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2010	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2010	Astra-G	TU (Telematic unit)	●	●	●	※	※
2010	Astra-H	AF 40-6	●	●	●	●	●
2010	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2010	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2010	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2010	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2010	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2010	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2010	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2010	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2010	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2010	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2010	Astra-H	PAS (Park pilot)	●	●	●	●	●
2010	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2010	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2010	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2010	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2010	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2010	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●

2010	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2010	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2010	Astra-J	CACM (Chime Alarm Control Module)	●	●	●	※	●
2010	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2010	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2010	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2010	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2010	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2010	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2010	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2010	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2010	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2010	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2010	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2010	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2010	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2010	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2010	Astra-J	RADIO (Radio)	●	●	●	●	●
2010	Astra-J	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2010	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2010	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2010	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2010	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2010	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2010	Astra-J	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2010	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2010	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2010	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2010	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2010	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2010	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2010	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2010	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Corsa-C	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2010	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2010	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2010	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2010	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Corsa-D	AF 13-4	●	●	●	●	●
2010	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2010	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2010	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2010	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2010	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2010	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2010	Corsa-D	MTA (Easytronic)	●	●	●	●	●
2010	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2010	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2010	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Insignia	BCM (Body Control Module)	●	●	●	●	●
2010	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2010	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2010	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※

2010	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2010	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2010	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2010	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2010	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2010	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2010	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2010	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2010	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2010	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2010	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2010	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2010	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2010	Insignia	RADIO (Radio)	●	●	●	●	●
2010	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2010	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2010	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2010	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2010	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2010	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2010	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2010	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2010	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2010	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2010	Meriva	AOH (Add On Heater)	※	●	●	●	●
2010	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Meriva	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2010	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2010	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2010	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2010	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2010	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2010	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●
2010	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2010	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2010	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2010	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2010	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2010	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2010	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2010	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2010	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2010	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2010	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2010	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2010	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2010	Movano	BCM (Body Control Module)	※	●	●	●	※
2010	Movano	ECM (Engine Control Module)	●	●	●	●	※
2010	Movano	MTA (Tecshift)	●	●	●	●	●
2010	Movano	PP (Park Pilot)	※	●	●	●	※
2010	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2010	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2010	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※

2010	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2010	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2010	Movano-B	Radio	●	●	●	※	※
2010	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2010	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2010	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2010	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2010	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2010	Vivaro	MTA (Tecshift)	●	●	●	●	●
2010	Vivaro	PP (Park Pilot)	※	●	●	●	※
2010	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2010	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2010	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2010	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2010	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2010	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2010	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2010	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2010	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2010	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2010	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2010	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2010	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2010	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2010	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2010	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2011	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2011	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2011	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2011	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2011	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2011	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2011	Antara	BCM (Body Control Module)	●	●	●	●	●
2011	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Antara	ECM (Engine Control Module)	●	●	●	●	●
2011	Antara	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2011	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2011	Antara	IC (Instrument Cluster)	●	●	●	●	●
2011	Antara	IDM (Info Display Module)	●	●	●	●	●
2011	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2011	Antara	PACM (Parking Assist Control Module)	●	●	●	※	●
2011	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Antara	RADIO (Radio)	●	●	●	●	●
2011	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2011	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2011	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2011	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2011	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2011	Antara	VPSCM (Variable Power Steering Control Module)	※	●	●	※	●
2011	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●

2011	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2011	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2011	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2011	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2011	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2011	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2011	Astra-G	Cruise Control	●	●	●	●	※
2011	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2011	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2011	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2011	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2011	Astra-G	TU (Telematic unit)	●	●	●	※	※
2011	Astra-H	AF 40-6	●	●	●	●	●
2011	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2011	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2011	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2011	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2011	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2011	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2011	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2011	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2011	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2011	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2011	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2011	Astra-H	PAS (Park pilot)	●	●	●	●	●
2011	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2011	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2011	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2011	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2011	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2011	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2011	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2011	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2011	Astra-J	CACM (Chime Alarm Control Module)	●	●	●	※	●
2011	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2011	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2011	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2011	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2011	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2011	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2011	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2011	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2011	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2011	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2011	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2011	Astra-J	RADIO (Radio)	●	●	●	●	●
2011	Astra-J	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●

2011	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2011	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2011	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2011	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2011	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2011	Astra-J	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2011	CaptivaLong-Body	AT (Automatic Transmission)	●	●	●	●	●
2011	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2011	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2011	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2011	CaptivaLong-Body	PAS (Park pilot)	●	●	●	●	●
2011	CaptivaLong-Body	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2011	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2011	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2011	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2011	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2011	Corsa-C	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2011	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2011	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2011	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2011	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Corsa-D	AF 13-4	●	●	●	●	●
2011	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2011	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2011	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2011	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2011	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2011	Corsa-D	FICM (Fuel Injector Control Module)	●	●	●	●	●
2011	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2011	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2011	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2011	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2011	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Insignia	BCM (Body Control Module)	●	●	●	●	●
2011	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2011	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2011	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2011	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2011	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2011	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2011	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2011	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2011	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2011	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2011	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2011	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2011	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2011	Insignia	RADIO (Radio)	●	●	●	●	●
2011	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●

2011	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2011	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2011	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2011	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2011	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2011	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2011	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2011	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2011	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2011	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●
2011	Meriva-B	FICM (Fuel Injector Control Module)	●	●	●	●	●
2011	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2011	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2011	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2011	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2011	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2011	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2011	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2011	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2011	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2011	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2011	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2011	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2011	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※
2011	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2011	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2011	Movano-B	Radio	●	●	●	※	※
2011	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2011	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2011	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2011	Vauxhall-VXR8	Audio system	●	●	●	●	※
2011	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2011	Vauxhall-VXR8	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2011	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2011	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2011	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2011	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2011	Vauxhall-VXR8	RSE (rear seat entertainment)	●	●	●	●	※
2011	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2011	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2011	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2011	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2011	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2011	Vivaro	MTA (Tecshift)	●	●	●	●	※
2011	Vivaro	PP (Park Pilot)	※	●	●	●	※
2011	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2011	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2011	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2011	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※

2011	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2011	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2011	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2011	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2011	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2011	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2011	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2011	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2011	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2011	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2011	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2011	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2012	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2012	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2012	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2012	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2012	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2012	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2012	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2012	Ampera	BCM (Body Control Module)	●	●	●	●	●
2012	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2012	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2012	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2012	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2012	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2012	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2012	Ampera	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2012	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2012	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2012	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2012	Ampera	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Ampera	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Ampera	PPM (Passenger Presence Module)	●	●	●	●	※
2012	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	●
2012	Ampera	RADIO (Radio)	●	●	●	●	●
2012	Ampera	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2012	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2012	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2012	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2012	Antara	BCM (Body Control Module)	●	●	●	●	●
2012	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Antara	ECM (Engine Control Module)	●	●	●	●	●
2012	Antara	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Antara	HCM (Headlamp Control Module)	●	●	●	●	●

2012	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2012	Antara	IC (Instrument Cluster)	●	●	●	●	●
2012	Antara	IDM (Info Display Module)	●	●	●	●	●
2012	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2012	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Antara	RADIO (Radio)	●	●	●	●	●
2012	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2012	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2012	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2012	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2012	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2012	Astra-H	AF 40-6	●	●	●	●	●
2012	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2012	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2012	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2012	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2012	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2012	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2012	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2012	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2012	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2012	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2012	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2012	Astra-H	PAS (Park pilot)	●	●	●	●	●
2012	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2012	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2012	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2012	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2012	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2012	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2012	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2012	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2012	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2012	Astra-J	CACM (Chime Alarm Control Module)	●	●	●	※	●
2012	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2012	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2012	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2012	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2012	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2012	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2012	Astra-J	RADIO (Radio)	●	●	●	●	●
2012	Astra-J	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2012	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●

2012	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Astra-J	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2012	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2012	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2012	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2012	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2012	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2012	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2012	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2012	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2012	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2012	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2012	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2012	Corsa-D	AF 13-4	●	●	●	●	●
2012	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2012	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2012	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2012	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2012	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2012	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2012	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2012	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2012	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2012	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2012	Insignia	BCM (Body Control Module)	●	●	●	●	●
2012	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2012	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2012	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2012	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2012	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2012	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2012	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2012	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2012	Insignia	RADIO (Radio)	●	●	●	●	●
2012	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2012	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2012	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2012	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2012	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2012	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2012	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●

2012	Meriva-B	FICM (Fuel Injector Control Module)	●	●	●	●	●
2012	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2012	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2012	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2012	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2012	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2012	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2012	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2012	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※
2012	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2012	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2012	Movano-B	Radio	●	●	●	※	※
2012	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2012	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2012	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2012	Vauxhall-VXR8	Audio system	●	●	●	●	※
2012	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2012	Vauxhall-VXR8	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2012	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2012	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2012	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2012	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2012	Vauxhall-VXR8	RSE (rear seat entertainment)	●	●	●	●	※
2012	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2012	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2012	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2012	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2012	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2012	Vivaro	MTA (Tecshift)	●	●	●	●	※
2012	Vivaro	PP (Park Pilot)	※	●	●	●	※
2012	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2012	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2012	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2012	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2012	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2012	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2012	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2012	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2012	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2012	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2012	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2012	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2012	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2012	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2012	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※

2012	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2012	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2012	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2012	Zafira-C	CACM (Chime Alarm Control Module)	●	●	●	※	●
2012	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2012	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2012	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2012	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2012	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2012	Zafira-C	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2012	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	●
2012	Zafira-C	RADIO (Radio)	●	●	●	●	●
2012	Zafira-C	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2012	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2012	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Zafira-C	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2013	Adam	BCM (Body Control Module)	●	●	●	●	●
2013	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Adam	ECM (Engine Control Module)	●	●	●	●	●
2013	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Adam	IC (Instrument Cluster)	●	●	●	●	●
2013	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Adam	RADIO (Radio)	●	●	●	●	●
2013	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2013	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2013	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2013	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2013	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2013	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2013	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2013	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2013	Ampera	BCM (Body Control Module)	●	●	●	●	●
2013	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2013	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2013	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2013	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2013	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2013	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2013	Ampera	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Ampera	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●

2013	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2013	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2013	Ampera	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2013	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2013	Ampera	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Ampera	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Ampera	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Ampera	RADIO (Radio)	●	●	●	●	●
2013	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2013	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2013	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2013	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2013	Antara	BCM (Body Control Module)	●	●	●	●	●
2013	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Antara	ECM (Engine Control Module)	●	●	●	●	●
2013	Antara	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2013	Antara	IC (Instrument Cluster)	●	●	●	●	●
2013	Antara	IDM (Info Display Module)	●	●	●	●	●
2013	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2013	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Antara	RADIO (Radio)	●	●	●	●	●
2013	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2013	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2013	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2013	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2013	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2013	Astra-H	AF 40-6	●	●	●	●	●
2013	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2013	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2013	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2013	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2013	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2013	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2013	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2013	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2013	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2013	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2013	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2013	Astra-H	PAS (Park pilot)	●	●	●	●	●
2013	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2013	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2013	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2013	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2013	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2013	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2013	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●

2013	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2013	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2013	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Astra-J	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2013	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2013	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2013	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2013	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	●
2013	Astra-J	RADIO (Radio)	●	●	●	●	●
2013	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2013	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2013	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Cascada	BCM (Body Control Module)	●	●	●	●	●
2013	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2013	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Cascada	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2013	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2013	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Cascada	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Cascada	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Cascada	RADIO (Radio)	●	●	●	●	●
2013	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2013	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2013	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2013	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2013	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2013	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2013	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2013	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※

2013	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2013	Corsa-D	AF 13-4	●	●	●	●	●
2013	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2013	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2013	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2013	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2013	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2013	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2013	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2013	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2013	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2013	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2013	Insignia	BCM (Body Control Module)	●	●	●	●	●
2013	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2013	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2013	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2013	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2013	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2013	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2013	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2013	Insignia	RADIO (Radio)	●	●	●	●	●
2013	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2013	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2013	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2013	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2013	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2013	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●
2013	Meriva-B	FICM (Fuel Injector Control Module)	●	●	●	●	●
2013	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2013	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2013	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2013	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2013	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2013	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2013	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2013	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Mokka	BCM (Body Control Module)	●	●	●	●	●

2013	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2013	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2013	Mokka	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Mokka	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Mokka	RADIO (Radio)	●	●	●	●	●
2013	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2013	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2013	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2013	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2013	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2013	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2013	Vivaro	MTA (Tecshift)	●	●	●	●	※
2013	Vivaro	PP (Park Pilot)	※	●	●	●	※
2013	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2013	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2013	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2013	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2013	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2013	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2013	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2013	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2013	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2013	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2013	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2013	Zafira-B	SAC (Electronic Climate Control)	●	●	●	●	●
2013	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2013	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2013	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2013	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2013	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2013	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2013	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2013	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2013	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2013	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2013	Zafira-C	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2013	Zafira-C	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●

2013	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Zafira-C	RADIO (Radio)	●	●	●	●	●
2013	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2013	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2013	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Adam	BCM (Body Control Module)	●	●	●	●	●
2014	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Adam	ECM (Engine Control Module)	●	●	●	●	●
2014	Adam	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Adam	IC (Instrument Cluster)	●	●	●	●	●
2014	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Adam	RADIO (Radio)	●	●	●	●	●
2014	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2014	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Agila-B	IMMO (Immobliser)	●	●	●	●	※
2014	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2014	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2014	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2014	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2014	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2014	Ampera	BCM (Body Control Module)	●	●	●	●	●
2014	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2014	Ampera	CCM (Chassis Control Module)	●	●	●	●	●
2014	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2014	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2014	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2014	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2014	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2014	Ampera	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2014	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2014	Ampera	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2014	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2014	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Ampera	RADIO (Radio)	●	●	●	●	●
2014	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2014	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2014	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2014	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●

2014	Antara	BCM (Body Control Module)	●	●	●	●	●
2014	Antara	CCM (Chassis Control Module)	●	●	●	●	●
2014	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Antara	ECM (Engine Control Module)	●	●	●	●	●
2014	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2014	Antara	IC (Instrument Cluster)	●	●	●	●	●
2014	Antara	IDM (Info Display Module)	●	●	●	●	●
2014	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2014	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Antara	RADIO (Radio)	●	●	●	●	●
2014	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2014	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2014	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2014	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2014	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2014	Astra-H	AF 40-6	●	●	●	●	●
2014	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2014	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2014	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2014	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2014	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2014	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2014	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2014	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2014	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2014	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2014	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2014	Astra-H	PAS (Park pilot)	●	●	●	●	●
2014	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2014	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2014	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2014	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2014	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2014	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2014	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2014	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2014	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2014	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2014	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Astra-J	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2014	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2014	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2014	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※

2014	Astra-J	RADIO (Radio)	●	●	●	●	●
2014	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2014	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2014	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Cascada	BCM (Body Control Module)	●	●	●	●	●
2014	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2014	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2014	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2014	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2014	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Cascada	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Cascada	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Cascada	RADIO (Radio)	●	●	●	●	●
2014	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2014	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2014	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2014	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2014	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2014	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2014	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2014	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2014	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2014	Corsa-D	AF 13-4	●	●	●	●	●
2014	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2014	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2014	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2014	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2014	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2014	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2014	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2014	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2014	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2014	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2014	Insignia	Amplifier	●	●	●	●	※
2014	Insignia	BCM (Body Control Module)	●	●	●	●	●
2014	Insignia	CCM (Chassis Control Module)	●	●	●	●	●
2014	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2014	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2014	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●

2014	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2014	Insignia	HC (HVAC Controls)	●	●	●	●	●
2014	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2014	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2014	Insignia	ICT (Infotainment Control Touchpad)	●	●	●	●	●
2014	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2014	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2014	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2014	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2014	Insignia	RADIO (Radio)	●	●	●	●	●
2014	Insignia	RC (Radio Controls)	●	●	●	●	●
2014	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2014	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2014	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2014	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2014	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Meriva-B	BCM (Body Control Module)	●	●	●	●	●
2014	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2014	Meriva-B	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2014	Meriva-B	RADIO (Radio)	●	●	●	●	●
2014	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	※	●	※	※
2014	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2014	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Mokka	BCM (Body Control Module)	●	●	●	●	●
2014	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2014	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2014	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Mokka	RADIO (Radio)	●	●	●	●	●

2014	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2014	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2014	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2014	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※
2014	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2014	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2014	Movano-B	Radio	●	●	●	※	※
2014	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2014	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2014	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2014	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2014	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2014	Vivaro	MTA (Tecshift)	●	●	●	●	※
2014	Vivaro	PP (Park Pilot)	※	●	●	●	※
2014	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2014	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2014	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2014	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2014	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2014	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2014	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2014	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2014	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2014	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2014	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2014	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2014	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2014	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2014	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2014	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2014	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2014	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2014	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2014	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2014	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2014	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2014	Zafira-C	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Zafira-C	RADIO (Radio)	●	●	●	●	●
2014	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●

2014	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2014	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Adam	BCM (Body Control Module)	●	●	●	●	●
2015	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2015	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Adam	ECM (Engine Control Module)	●	●	●	●	●
2015	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2015	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Adam	IC (Instrument Cluster)	●	●	●	●	●
2015	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Adam	RADIO (Radio)	●	●	●	●	●
2015	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2015	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2015	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2015	Ampera	BCM (Body Control Module)	●	●	●	●	●
2015	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2015	Ampera	CCM (Chassis Control Module)	●	●	●	●	●
2015	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2015	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2015	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2015	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2015	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2015	Ampera	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2015	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2015	Ampera	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2015	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2015	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Ampera	RADIO (Radio)	●	●	●	●	●
2015	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2015	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2015	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2015	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2015	Antara	BCM (Body Control Module)	●	●	●	●	●
2015	Antara	CCM (Chassis Control Module)	●	●	●	●	●
2015	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Antara	ECM (Engine Control Module)	●	●	●	●	●
2015	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2015	Antara	IC (Instrument Cluster)	●	●	●	●	●
2015	Antara	IDM (Info Display Module)	●	●	●	●	●
2015	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●

2015	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Antara	RADIO (Radio)	●	●	●	●	●
2015	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2015	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2015	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2015	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2015	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2015	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2015	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2015	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Astra-J	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2015	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2015	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2015	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2015	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Astra-J	RADIO (Radio)	●	●	●	●	●
2015	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2015	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2015	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Cascada	BCM (Body Control Module)	●	●	●	●	●
2015	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2015	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2015	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2015	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2015	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2015	Cascada	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Cascada	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Cascada	RADIO (Radio)	●	●	●	●	●
2015	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2015	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2015	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●

2015	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2015	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2015	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2015	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2015	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2015	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2015	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2015	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2015	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2015	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2015	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2015	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2015	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Corsa-E	RADIO (Radio)	●	●	●	●	●
2015	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2015	Corsa-E	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Insignia	Amplifier	●	●	●	●	※
2015	Insignia	BCM (Body Control Module)	●	●	●	●	●
2015	Insignia	CCM (Chassis Control Module)	●	●	●	●	●
2015	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2015	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2015	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2015	Insignia	HC (HVAC Controls)	●	●	●	●	●
2015	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2015	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2015	Insignia	ICT (Infotainment Control Touchpad)	●	●	●	●	●
2015	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2015	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2015	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2015	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2015	Insignia	RADIO (Radio)	●	●	●	●	●
2015	Insignia	RC (Radio Controls)	●	●	●	●	●
2015	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2015	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2015	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2015	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2015	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Meriva-B	BCM (Body Control Module)	●	●	●	●	●

2015	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2015	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2015	Meriva-B	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2015	Meriva-B	RADIO (Radio)	●	●	●	●	●
2015	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2015	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Mokka	BCM (Body Control Module)	●	●	●	●	●
2015	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2015	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2015	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Mokka	RADIO (Radio)	●	●	●	●	●
2015	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2015	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2015	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2015	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2015	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2015	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2015	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2015	Movano-B	NCM (Navigation Control Module)	●	●	●	●	●
2015	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2015	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Movano-B	RADIO (Radio)	●	●	●	●	●
2015	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2015	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2015	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2015	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2015	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2015	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2015	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●

2015	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2015	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2015	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2015	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2015	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2015	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2015	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2015	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2015	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2015	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2015	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2015	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2015	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2015	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2015	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Zafira-C	RADIO (Radio)	●	●	●	●	●
2015	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2015	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2015	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Adam	BCM (Body Control Module)	●	●	●	●	●
2016	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2016	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Adam	ECM (Engine Control Module)	●	●	●	●	●
2016	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2016	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Adam	IC (Instrument Cluster)	●	●	●	●	●
2016	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Adam	RADIO (Radio)	●	●	●	●	●
2016	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2016	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2016	Antara	BCM (Body Control Module)	●	●	●	●	●
2016	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Antara	ECM (Engine Control Module)	●	●	●	●	●
2016	Antara	HCM (Headlamp Control Module)	●	●	●	●	●

2016	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2016	Antara	IC (Instrument Cluster)	●	●	●	●	●
2016	Antara	IDM (Info Display Module)	●	●	●	●	●
2016	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2016	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Antara	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Antara	RADIO (Radio)	●	●	●	●	●
2016	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2016	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2016	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2016	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2016	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2016	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2016	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2016	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2016	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2016	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Astra-J	RADIO (Radio)	●	●	●	●	●
2016	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2016	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Astra-J	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2016	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2016	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2016	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2016	Astra-K	HC (HVAC Controls)	●	●	●	●	●
2016	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2016	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2016	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2016	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2016	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2016	Astra-K	RADIO (Radio)	●	●	●	●	●
2016	Astra-K	RC (Radio Controls)	●	●	●	●	●
2016	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2016	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2016	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●

2016	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2016	Astra-K	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Cascada	BCM (Body Control Module)	●	●	●	●	●
2016	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2016	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2016	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2016	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2016	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2016	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Cascada	RADIO (Radio)	●	●	●	●	●
2016	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2016	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2016	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2016	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2016	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2016	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2016	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2016	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2016	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2016	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2016	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2016	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2016	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2016	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2016	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2016	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Corsa-E	RADIO (Radio)	●	●	●	●	●
2016	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2016	Corsa-E	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Insignia	Amplifier	●	●	●	●	※
2016	Insignia	BCM (Body Control Module)	●	●	●	●	●
2016	Insignia	CCM (Chassis Control Module)	●	●	●	●	●

2016	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2016	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2016	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2016	Insignia	HC (HVAC Controls)	●	●	●	●	●
2016	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2016	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2016	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2016	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2016	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2016	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2016	Insignia	RADIO (Radio)	●	●	●	●	●
2016	Insignia	RC (Radio Controls)	●	●	●	●	●
2016	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2016	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2016	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2016	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Insignia	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2016	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2016	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2016	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2016	Karl-Viva	FICM (Fuel Injector Control Module)	●	●	●	●	●
2016	Karl-Viva	HC (HVAC Controls)	●	●	●	●	●
2016	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2016	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2016	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Karl-Viva	TCM (Transmission Control Module)	●	●	●	●	●
2016	Meriva-B	BCM (Body Control Module)	●	●	●	●	●
2016	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2016	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2016	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2016	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2016	Meriva-B	RADIO (Radio)	●	●	●	●	●

2016	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Meriva-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2016	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Mokka	BCM (Body Control Module)	●	●	●	●	●
2016	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2016	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2016	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Mokka	RADIO (Radio)	●	●	●	●	●
2016	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2016	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2016	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2016	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2016	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2016	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2016	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2016	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2016	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2016	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Movano-B	RADIO (Radio)	●	●	●	●	●
2016	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2016	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2016	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2016	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2016	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2016	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2016	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2016	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2016	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2016	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2016	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2016	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2016	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2016	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2016	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●

2016	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2016	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2016	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2016	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2016	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2016	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2016	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2016	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2016	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Zafira-C	RADIO (Radio)	●	●	●	●	●
2016	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2016	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2016	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Adam	BCM (Body Control Module)	●	●	●	●	●
2017	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2017	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Adam	ECM (Engine Control Module)	●	●	●	●	●
2017	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Adam	IC (Instrument Cluster)	●	●	●	●	●
2017	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Adam	RADIO (Radio)	●	●	●	●	●
2017	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2017	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Ampera-E	BBCM (Brake Booster Control Module)	●	●	●	●	※
2017	Ampera-E	BCM (Body Control Module)	●	●	●	●	●
2017	Ampera-E	BECM (Battery Energy Control Module)	●	※	※	●	※
2017	Ampera-E	CCM (Chassis Control Module)	●	●	●	●	●
2017	Ampera-E	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2017	Ampera-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Ampera-E	ECM (Engine Control Module)	●	●	●	●	●
2017	Ampera-E	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 1)	●	●	●	●	●
2017	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 2)	●	●	●	●	●
2017	Ampera-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Ampera-E	IC (Instrument Cluster)	●	●	●	●	●
2017	Ampera-E	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Ampera-E	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●

2017	Ampera-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Ampera-E	PASCM (Pedestrian Alert Sound Control Module)	●	●	●	●	●
2017	Ampera-E	PLCM (Power Line Communication Module)	●	※	※	●	※
2017	Ampera-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Ampera-E	RADIO (Radio)	●	●	●	●	●
2017	Ampera-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Ampera-E	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Ampera-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Ampera-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Ampera-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2017	Ampera-E	TRCM (Transmission Range Control Module)	●	●	●	●	※
2017	Ampera-E	VPCM (Video Processing Control Module)	●	●	●	●	●
2017	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2017	Antara	BCM (Body Control Module)	●	●	●	●	●
2017	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Antara	ECM (Engine Control Module)	●	●	●	●	●
2017	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2017	Antara	IC (Instrument Cluster)	●	●	●	●	●
2017	Antara	IDM (Info Display Module)	●	●	●	●	●
2017	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2017	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Antara	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Antara	RADIO (Radio)	●	●	●	●	●
2017	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2017	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2017	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2017	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2017	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2017	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2017	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2017	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2017	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2017	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Astra-J	RADIO (Radio)	●	●	●	●	●
2017	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2017	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Astra-J	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2017	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2017	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2017	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2017	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2017	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2017	Astra-K	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Astra-K	HC (HVAC Controls)	●	●	●	●	●
2017	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2017	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2017	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2017	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2017	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2017	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2017	Astra-K	RADIO (Radio)	●	●	●	●	●
2017	Astra-K	RC (Radio Controls)	●	●	●	●	●
2017	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2017	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2017	Astra-K	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Cascada	BCM (Body Control Module)	●	●	●	●	●
2017	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2017	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2017	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2017	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2017	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2017	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Cascada	RADIO (Radio)	●	●	●	●	●
2017	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2017	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2017	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2017	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2017	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2017	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2017	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2017	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2017	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●

2017	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2017	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2017	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2017	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2017	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2017	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2017	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Corsa-E	RADIO (Radio)	●	●	●	●	●
2017	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2017	Corsa-E	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2017	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2017	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2017	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2017	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2017	Crossland-X	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Crossland-X	HC (HVAC Controls)	●	●	●	●	●
2017	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Crossland-X	HUDM (Head-Up Display Module)	●	●	●	●	●
2017	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2017	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2017	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2017	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2017	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2017	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2017	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2017	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2017	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2017	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2017	Crossland-X	RADIO (Radio)	●	●	●	●	●
2017	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2017	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2017	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2017	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2017	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2017	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2017	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2017	Insignia	Amplifier	●	●	●	●	※
2017	Insignia	BCM (Body Control Module)	●	●	●	●	●
2017	Insignia	CCM (Chassis Control Module)	●	●	●	●	●
2017	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2017	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2017	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2017	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2017	Insignia	HC (HVAC Controls)	●	●	●	●	●
2017	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2017	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2017	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2017	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2017	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2017	Insignia	RADIO (Radio)	●	●	●	●	●
2017	Insignia	RC (Radio Controls)	●	●	●	●	●
2017	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2017	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2017	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Insignia	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2017	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2017	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2017	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2017	Karl-Viva	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Karl-Viva	HC (HVAC Controls)	●	●	●	●	●
2017	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2017	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2017	Karl-Viva	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Karl-Viva	TCM (Transmission Control Module)	●	●	●	●	●
2017	Meriva-B	BCM (Body Control Module)	●	●	●	●	●
2017	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2017	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2017	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2017	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2017	Meriva-B	RADIO (Radio)	●	●	●	●	●

2017	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Meriva-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2017	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Mokka	Amplifier	●	●	●	●	※
2017	Mokka	BCM (Body Control Module)	●	●	●	●	●
2017	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2017	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Mokka	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2017	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2017	Mokka	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Mokka	PST (Power Supply Transformer)	●	●	●	●	※
2017	Mokka	RADIO (Radio)	●	●	●	●	●
2017	Mokka	RC (Radio Controls)	●	●	●	●	●
2017	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2017	Mokka	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Mokka	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2017	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2017	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2017	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2017	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2017	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2017	Movano-B	IDM (Info Display Module)	●	●	●	●	●
2017	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2017	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2017	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Movano-B	RADIO (Radio)	●	●	●	●	●
2017	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2017	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2017	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2017	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2017	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2017	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2017	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2017	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2017	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●

2017	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2017	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2017	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2017	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2017	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2017	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●
2017	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2017	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2017	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2017	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2017	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2017	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2017	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2017	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Zafira-C	RADIO (Radio)	●	●	●	●	●
2017	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2017	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2017	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2018	Adam	BCM (Body Control Module)	●	●	●	●	●
2018	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2018	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Adam	ECM (Engine Control Module)	●	●	●	●	●
2018	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Adam	IC (Instrument Cluster)	●	●	●	●	●
2018	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Adam	RADIO (Radio)	●	●	●	●	●
2018	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2018	Adam	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Ampera-E	BBCM (Brake Booster Control Module)	●	●	●	●	※
2018	Ampera-E	BCM (Body Control Module)	●	●	●	●	●
2018	Ampera-E	BECM (Battery Energy Control Module)	●	※	※	●	※
2018	Ampera-E	CCM (Chassis Control Module)	●	●	●	●	●
2018	Ampera-E	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2018	Ampera-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2018	Ampera-E	ECM (Engine Control Module)	●	●	●	●	●
2018	Ampera-E	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 1)	●	●	●	●	●
2018	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 2)	●	●	●	●	●
2018	Ampera-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Ampera-E	IC (Instrument Cluster)	●	●	●	●	●
2018	Ampera-E	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Ampera-E	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2018	Ampera-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Ampera-E	PASCM (Pedestrian Alert Sound Control Module)	●	●	●	●	●
2018	Ampera-E	PLCM (Power Line Communication Module)	●	※	※	●	※
2018	Ampera-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Ampera-E	RADIO (Radio)	●	●	●	●	●
2018	Ampera-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Ampera-E	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Ampera-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Ampera-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Ampera-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Ampera-E	TRCM (Transmission Range Control Module)	●	●	●	●	※
2018	Ampera-E	VPCM (Video Processing Control Module)	●	●	●	●	●
2018	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2018	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2018	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2018	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2018	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2018	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2018	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2018	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2018	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Astra-J	RADIO (Radio)	●	●	●	●	●
2018	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2018	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Astra-J	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2018	Astra-J	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2018	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2018	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2018	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2018	Astra-K	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Astra-K	HC (HVAC Controls)	●	●	●	※	※
2018	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2018	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2018	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※

2018	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2018	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2018	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2018	Astra-K	RADIO (Radio)	●	●	●	●	●
2018	Astra-K	RC (Radio Controls)	●	●	●	※	※
2018	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2018	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2018	Astra-K	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Cascada	BCM (Body Control Module)	●	●	●	●	●
2018	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2018	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2018	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2018	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2018	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2018	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2018	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2018	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Cascada	RADIO (Radio)	●	●	●	●	●
2018	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2018	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2018	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2018	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2018	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2018	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2018	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2018	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2018	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2018	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2018	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2018	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2018	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2018	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●

2018	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Corsa-E	RADIO (Radio)	●	●	●	●	●
2018	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2018	Corsa-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2018	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2018	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2018	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2018	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2018	Crossland-X	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Crossland-X	FICM (Fuel Injector Control Module)	●	●	●	※	※
2018	Crossland-X	HC (HVAC Controls)	●	●	●	●	●
2018	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Crossland-X	HUDM (Head-Up Display Module)	●	●	●	●	●
2018	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2018	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2018	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2018	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2018	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2018	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2018	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2018	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2018	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2018	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2018	Crossland-X	RADIO (Radio)	●	●	●	●	●
2018	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2018	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2018	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2018	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2018	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2018	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2018	Grandland-X	AA (Audio Amplifier)	●	●	●	※	●
2018	Grandland-X	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2018	Grandland-X	BCM (Body Control Module)	●	●	●	●	※
2018	Grandland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2018	Grandland-X	BVSCM (Battery Voltage Switching Control Module)	●	●	●	●	※
2018	Grandland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2018	Grandland-X	DSCM (Driver Seat Control Module)	●	●	●	●	●
2018	Grandland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Grandland-X	ECM (Engine Control Module)	●	●	●	●	●
2018	Grandland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2018	Grandland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2018	Grandland-X	HC (HVAC Controls)	●	●	●	●	●
2018	Grandland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Grandland-X	HLSCM (Hands-Free Liftgate Sensor Control Module)	●	●	●	※	※

2018	Grandland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Grandland-X	IC (Instrument Cluster)	●	●	●	●	●
2018	Grandland-X	IDM (Info Display Module)	●	●	●	●	●
2018	Grandland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2018	Grandland-X	LCM (Liftgate Control Module)	●	●	●	●	●
2018	Grandland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2018	Grandland-X	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	●
2018	Grandland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2018	Grandland-X	LWMM (Left Windshield Wiper Motor Module)	●	●	●	●	●
2018	Grandland-X	MDP (Media Disc Player)	●	●	●	●	●
2018	Grandland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Grandland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2018	Grandland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2018	Grandland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2018	Grandland-X	PST (Power Supply Transformer)	●	●	●	※	※
2018	Grandland-X	RADIO (Radio)	●	●	●	●	●
2018	Grandland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2018	Grandland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2018	Grandland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2018	Grandland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Grandland-X	SLSCM-D (Seat Lumbar Support Control Module - Driver)	●	●	●	●	●
2018	Grandland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Grandland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2018	Grandland-X	TCM (Transmission Control Module)	●	●	●	●	※
2018	Grandland-X	TCS (Traction Control Switch)	●	※	※	●	●
2018	Grandland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Grandland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2018	Grandland-X	VPCM (Video Processing Control Module)	●	●	●	●	●
2018	Insignia-B	AA (Audio Amplifier)	●	●	●	●	※
2018	Insignia-B	ASCM (Active Safety Control Module)	●	●	●	●	●
2018	Insignia-B	BCM (Body Control Module)	●	●	●	●	●
2018	Insignia-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Insignia-B	ECM (Engine Control Module)	●	●	●	●	●
2018	Insignia-B	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Insignia-B	HC (HVAC Controls)	●	●	●	※	※
2018	Insignia-B	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Insignia-B	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2018	Insignia-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Insignia-B	IC (Instrument Cluster)	●	●	●	●	●
2018	Insignia-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Insignia-B	LCM (Liftgate Control Module)	●	●	●	●	※
2018	Insignia-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2018	Insignia-B	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2018	Insignia-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Insignia-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Insignia-B	PST (Power Supply Transformer)	●	●	●	●	※
2018	Insignia-B	RADIO (Radio)	●	●	●	●	●
2018	Insignia-B	RC (Radio Controls)	●	●	●	※	※
2018	Insignia-B	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2018	Insignia-B	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Insignia-B	SCM (Suspension Control Module)	●	●	●	●	●
2018	Insignia-B	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Insignia-B	SMCM-D (Seat Memory Control Module - Driver)	●	●	●	●	●
2018	Insignia-B	SMCM-P (Seat Memory Control Module - Passenger)	●	●	●	●	●
2018	Insignia-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●

2018	Insignia-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Insignia-B	TCM (Transmission Control Module)	●	●	●	●	●
2018	Insignia-B	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Insignia-B	VPCM (Video Processing Control Module)	●	●	●	●	●
2018	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2018	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2018	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2018	Karl-Viva	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Karl-Viva	HC (HVAC Controls)	●	●	●	※	※
2018	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2018	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2018	Karl-Viva	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Karl-Viva	TCM (Transmission Control Module)	●	●	●	●	●
2018	Mokka	Amplifier	●	●	●	●	※
2018	Mokka	BCM (Body Control Module)	●	●	●	●	●
2018	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2018	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2018	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Mokka	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2018	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2018	Mokka	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Mokka	PST (Power Supply Transformer)	●	●	●	●	※
2018	Mokka	RADIO (Radio)	●	●	●	●	●
2018	Mokka	RC (Radio Controls)	●	●	●	※	※
2018	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2018	Mokka	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Mokka	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2018	Mokka	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2018	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2018	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2018	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2018	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2018	Movano-B	IDM (Info Display Module)	●	●	●	●	●
2018	Movano-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2018	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※

2018	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2018	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Movano-B	RADIO (Radio)	●	●	●	●	●
2018	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2018	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2018	Movano-B	SDGM-S (Serial Data Gateway Module - Secondary)	●	●	●	●	※
2018	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2018	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2018	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2018	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2018	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2018	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2018	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2018	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2018	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2018	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2018	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2018	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●
2018	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2018	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2018	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2018	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2018	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2018	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2018	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2018	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2018	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2018	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2018	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Zafira-C	RADIO (Radio)	●	●	●	●	●
2018	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2018	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2018	Zafira-C	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Adam	BCM (Body Control Module)	●	●	●	●	●
2019	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2019	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Adam	ECM (Engine Control Module)	●	●	●	●	●
2019	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●

2019	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Adam	IC (Instrument Cluster)	●	●	●	●	●
2019	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Adam	RADIO (Radio)	●	●	●	●	●
2019	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Ampera-E	BBCM (Brake Booster Control Module)	●	●	●	●	※
2019	Ampera-E	BCM (Body Control Module)	●	●	●	●	●
2019	Ampera-E	BECM (Battery Energy Control Module)	●	※	※	●	※
2019	Ampera-E	CCM (Chassis Control Module)	●	●	●	●	●
2019	Ampera-E	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2019	Ampera-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Ampera-E	ECM (Engine Control Module)	●	●	●	●	●
2019	Ampera-E	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 1)	●	●	●	●	●
2019	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 2)	●	●	●	●	●
2019	Ampera-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Ampera-E	IC (Instrument Cluster)	●	●	●	●	●
2019	Ampera-E	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Ampera-E	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2019	Ampera-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Ampera-E	PASCM (Pedestrian Alert Sound Control Module)	●	●	●	●	●
2019	Ampera-E	PLCM (Power Line Communication Module)	●	※	※	●	※
2019	Ampera-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Ampera-E	RADIO (Radio)	●	●	●	●	●
2019	Ampera-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Ampera-E	SDGM-PA (Serial Data Gateway Module - Processor A)	●	●	●	※	※
2019	Ampera-E	SDGM-PB (Serial Data Gateway Module - Processor B)	●	●	●	※	※
2019	Ampera-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Ampera-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Ampera-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Ampera-E	TRCM (Transmission Range Control Module)	●	●	●	●	※
2019	Ampera-E	VPCM (Video Processing Control Module)	●	●	●	●	●
2019	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2019	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2019	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2019	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2019	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2019	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Astra-J	RADIO (Radio)	●	●	●	●	●
2019	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2019	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2019	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2019	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2019	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2019	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2019	Astra-K	FICM (Fuel Injector Control Module)	●	●	●	●	●
2019	Astra-K	HC (HVAC Controls)	●	●	●	※	※
2019	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2019	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2019	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2019	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2019	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2019	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2019	Astra-K	RADIO (Radio)	●	●	●	●	●
2019	Astra-K	RC (Radio Controls)	●	●	●	※	※
2019	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2019	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2019	Astra-K	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Cascada	BCM (Body Control Module)	●	●	●	●	●
2019	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2019	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2019	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2019	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2019	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2019	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2019	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2019	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Cascada	RADIO (Radio)	●	●	●	●	●
2019	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2019	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2019	Combo-E	BCM (Body Control Module)	●	●	●	●	※
2019	Combo-E	BSM (Battery Sensor Module)	●	●	●	●	※
2019	Combo-E	COICM (Cargo Overload Indication Control Module)	●	●	●	●	※
2019	Combo-E	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2019	Combo-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Combo-E	ECM (Engine Control Module)	●	●	●	●	●
2019	Combo-E	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2019	Combo-E	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2019	Combo-E	HC (HVAC Controls)	●	●	●	●	●
2019	Combo-E	HUDEM (Head-Up Display Module)	●	●	●	●	●

2019	Combo-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Combo-E	IC (Instrument Cluster)	●	●	●	●	●
2019	Combo-E	IDM (Info Display Module)	●	●	●	●	●
2019	Combo-E	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2019	Combo-E	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2019	Combo-E	MDP (Media Disc Player)	●	●	●	●	●
2019	Combo-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Combo-E	PHCM (Parking Heater Control Module)	●	※	※	●	●
2019	Combo-E	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2019	Combo-E	PSCM (Power Steering Control Module)	●	●	●	●	●
2019	Combo-E	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2019	Combo-E	PST (Power Supply Transformer)	●	●	●	※	※
2019	Combo-E	RADIO (Radio)	●	●	●	●	●
2019	Combo-E	RD (Rearview Display)	●	※	※	●	※
2019	Combo-E	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2019	Combo-E	SCCM (Steering Column Control Module)	●	●	●	●	●
2019	Combo-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Combo-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Combo-E	Special Vehicle Control Module	●	●	●	●	※
2019	Combo-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Combo-E	TCM (Transmission Control Module)	●	●	●	●	※
2019	Combo-E	TCS (Traction Control Switch)	●	※	※	●	●
2019	Combo-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Combo-E	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2019	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2019	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2019	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2019	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2019	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2019	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Corsa-E	RADIO (Radio)	●	●	●	●	●
2019	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2019	Corsa-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2019	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2019	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2019	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2019	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2019	Crossland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2019	Crossland-X	FICM (Fuel Injector Control Module)	●	●	●	※	※
2019	Crossland-X	HC (HVAC Controls)	●	●	●	●	●
2019	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Crossland-X	HUDM (Head-Up Display Module)	●	●	●	●	●
2019	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2019	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2019	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※

2019	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2019	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2019	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2019	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2019	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2019	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2019	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2019	Crossland-X	RADIO (Radio)	●	●	●	●	●
2019	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2019	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2019	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2019	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2019	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2019	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2019	Grandland-X	AA (Audio Amplifier)	●	●	●	※	●
2019	Grandland-X	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2019	Grandland-X	BCM (Body Control Module)	●	●	●	●	※
2019	Grandland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2019	Grandland-X	BVSCM (Battery Voltage Switching Control Module)	●	●	●	●	※
2019	Grandland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2019	Grandland-X	DSCM (Driver Seat Control Module)	●	●	●	●	●
2019	Grandland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Grandland-X	ECM (Engine Control Module)	●	●	●	●	●
2019	Grandland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2019	Grandland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2019	Grandland-X	HC (HVAC Controls)	●	●	●	●	●
2019	Grandland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Grandland-X	HLSCM (Hands-Free Liftgate Sensor Control Module)	●	●	●	※	※
2019	Grandland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Grandland-X	IC (Instrument Cluster)	●	●	●	●	●
2019	Grandland-X	IDM (Info Display Module)	●	●	●	●	●
2019	Grandland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2019	Grandland-X	LCM (Liftgate Control Module)	●	●	●	●	●
2019	Grandland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2019	Grandland-X	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	●
2019	Grandland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2019	Grandland-X	LWMM (Left Windshield Wiper Motor Module)	●	●	●	●	●
2019	Grandland-X	MDP (Media Disc Player)	●	●	●	●	●
2019	Grandland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Grandland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2019	Grandland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2019	Grandland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2019	Grandland-X	PST (Power Supply Transformer)	●	●	●	※	※
2019	Grandland-X	RADIO (Radio)	●	●	●	●	●
2019	Grandland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2019	Grandland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2019	Grandland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2019	Grandland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Grandland-X	SLSCM-D (Seat Lumbar Support Control Module - Driver)	●	●	●	●	●

2019	Grandland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Grandland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Grandland-X	TCM (Transmission Control Module)	●	●	●	●	※
2019	Grandland-X	TCS (Traction Control Switch)	●	※	※	●	●
2019	Grandland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Grandland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2019	Grandland-X	VPCM (Video Processing Control Module)	●	●	●	●	●
2019	Insignia-B	AA (Audio Amplifier)	●	●	●	●	※
2019	Insignia-B	ASCM (Active Safety Control Module)	●	●	●	●	●
2019	Insignia-B	BCM (Body Control Module)	●	●	●	●	●
2019	Insignia-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Insignia-B	ECM (Engine Control Module)	●	●	●	●	●
2019	Insignia-B	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Insignia-B	HC (HVAC Controls)	●	●	●	※	※
2019	Insignia-B	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Insignia-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Insignia-B	IC (Instrument Cluster)	●	●	●	●	●
2019	Insignia-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Insignia-B	LCM (Liftgate Control Module)	●	●	●	●	※
2019	Insignia-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2019	Insignia-B	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2019	Insignia-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Insignia-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Insignia-B	PST (Power Supply Transformer)	●	●	●	●	※
2019	Insignia-B	RADIO (Radio)	●	●	●	●	●
2019	Insignia-B	RC (Radio Controls)	●	●	●	※	※
2019	Insignia-B	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2019	Insignia-B	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Insignia-B	SCM (Suspension Control Module)	●	●	●	●	●
2019	Insignia-B	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Insignia-B	SMCM-D (Seat Memory Control Module - Driver)	●	●	●	●	●
2019	Insignia-B	SMCM-P (Seat Memory Control Module - Passenger)	●	●	●	●	●
2019	Insignia-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Insignia-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Insignia-B	TCM (Transmission Control Module)	●	●	●	●	●
2019	Insignia-B	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Insignia-B	VPCM (Video Processing Control Module)	●	●	●	●	●
2019	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2019	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2019	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2019	Karl-Viva	HC (HVAC Controls)	●	●	●	※	※
2019	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2019	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2019	Karl-Viva	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Mokka	Amplifier	●	●	●	●	※
2019	Mokka	BCM (Body Control Module)	●	●	●	●	●
2019	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Mokka	ECM (Engine Control Module)	●	●	●	●	●

2019	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2019	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Mokka	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2019	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2019	Mokka	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Mokka	PST (Power Supply Transformer)	●	●	●	●	※
2019	Mokka	RADIO (Radio)	●	●	●	●	●
2019	Mokka	RC (Radio Controls)	●	●	●	※	※
2019	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2019	Mokka	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Mokka	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2019	Mokka	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2019	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2019	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2019	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2019	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2019	Movano-B	IDM (Info Display Module)	●	●	●	●	●
2019	Movano-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2019	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2019	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2019	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Movano-B	RADIO (Radio)	●	●	●	●	●
2019	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2019	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2019	Movano-B	SDGM-S (Serial Data Gateway Module - Secondary)	●	●	●	●	※
2019	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2019	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2019	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2019	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2019	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2019	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2019	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2019	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2019	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2019	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2019	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2019	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●

2019	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2019	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2019	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2019	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2019	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2019	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2019	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2019	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2019	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Zafira-C	RADIO (Radio)	●	●	●	●	●
2019	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2019	Zafira-C	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2020	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2020	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2020	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2020	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2020	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2020	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2020	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2020	Astra-J	RADIO (Radio)	●	●	●	●	●
2020	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2020	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2020	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2020	Astra-K	AA (Audio Amplifier)	●	●	●	●	※
2020	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2020	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2020	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2020	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2020	Astra-K	HC (HVAC Controls)	●	●	●	※	※
2020	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2020	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2020	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2020	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2020	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2020	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※

2020	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2020	Astra-K	RADIO (Radio)	●	●	●	●	●
2020	Astra-K	RC (Radio Controls)	●	●	●	※	※
2020	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2020	Astra-K	SDGM-PA (Serial Data Gateway Module - Processor A)	●	●	●	※	※
2020	Astra-K	SDGM-PB (Serial Data Gateway Module - Processor B)	●	●	●	※	※
2020	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2020	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2020	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2020	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2020	Astra-K	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Combo-E	BCM (Body Control Module)	●	●	●	●	※
2020	Combo-E	BSM (Battery Sensor Module)	●	●	●	●	※
2020	Combo-E	COICM (Cargo Overload Indication Control Module)	●	●	●	●	※
2020	Combo-E	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2020	Combo-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Combo-E	ECM (Engine Control Module)	●	●	●	●	●
2020	Combo-E	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2020	Combo-E	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2020	Combo-E	HC (HVAC Controls)	●	●	●	●	●
2020	Combo-E	HUDM (Head-Up Display Module)	●	●	●	●	●
2020	Combo-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Combo-E	IC (Instrument Cluster)	●	●	●	●	●
2020	Combo-E	IDM (Info Display Module)	●	●	●	●	●
2020	Combo-E	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2020	Combo-E	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2020	Combo-E	MDP (Media Disc Player)	●	●	●	●	●
2020	Combo-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Combo-E	PHCM (Parking Heater Control Module)	●	※	※	●	●
2020	Combo-E	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2020	Combo-E	PSCM (Power Steering Control Module)	●	●	●	●	●
2020	Combo-E	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2020	Combo-E	PST (Power Supply Transformer)	●	●	●	※	※
2020	Combo-E	RADIO (Radio)	●	●	●	●	●
2020	Combo-E	RD (Rearview Display)	●	※	※	●	※
2020	Combo-E	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2020	Combo-E	SCCM (Steering Column Control Module)	●	●	●	●	●
2020	Combo-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Combo-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Combo-E	Special Vehicle Control Module	●	●	●	●	※
2020	Combo-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2020	Combo-E	TCM (Transmission Control Module)	●	●	●	●	※
2020	Combo-E	TCS (Traction Control Switch)	●	※	※	●	●
2020	Combo-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Combo-E	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2020	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2020	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2020	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2020	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2020	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2020	Crossland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2020	Crossland-X	HC (HVAC Controls)	●	●	●	●	●

2020	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Crossland-X	HUDD (Head-Up Display Module)	●	●	●	●	●
2020	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2020	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2020	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2020	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2020	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2020	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2020	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2020	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2020	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2020	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2020	Crossland-X	RADIO (Radio)	●	●	●	●	●
2020	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2020	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2020	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2020	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2020	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2020	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2020	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2020	Grandland-X	12V BIM1 (12V Battery Isolator Module 1)	●	●	●	●	※
2020	Grandland-X	A/C-C (A/C Compressor)	●	●	●	●	※
2020	Grandland-X	AA (Audio Amplifier)	●	●	●	※	●
2020	Grandland-X	BCM (Body Control Module)	●	●	●	●	※
2020	Grandland-X	BECM (Battery Energy Control Module)	●	●	●	●	※
2020	Grandland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2020	Grandland-X	BVSCM (Battery Voltage Switching Control Module)	●	●	●	●	※
2020	Grandland-X	CH (Coolant Heater)	●	●	●	●	●
2020	Grandland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2020	Grandland-X	DM1CM (Drive Motor 1 Control Module)	●	●	●	●	※
2020	Grandland-X	DM2CM (Drive Motor 2 Control Module)	●	●	●	●	※
2020	Grandland-X	DSCM (Driver Seat Control Module)	●	●	●	●	●
2020	Grandland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Grandland-X	ECM (Engine Control Module)	●	●	●	●	●
2020	Grandland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2020	Grandland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2020	Grandland-X	H/EV-PCM (Hybrid/EV Powertrain Control Module)	●	●	●	●	※
2020	Grandland-X	HC (HVAC Controls)	●	●	●	●	●
2020	Grandland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Grandland-X	HLSCM (Hands-Free Liftgate Sensor Control Module)	●	●	●	※	※
2020	Grandland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Grandland-X	IC (Instrument Cluster)	●	●	●	●	●
2020	Grandland-X	IDM (Info Display Module)	●	●	●	●	●
2020	Grandland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2020	Grandland-X	LCM (Liftgate Control Module)	●	●	●	●	●
2020	Grandland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2020	Grandland-X	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	●
2020	Grandland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2020	Grandland-X	LWMM (Left Windshield Wiper Motor Module)	●	●	●	●	●
2020	Grandland-X	MDP (Media Disc Player)	●	●	●	●	●

2020	Grandland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Grandland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2020	Grandland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2020	Grandland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2020	Grandland-X	PST (Power Supply Transformer)	●	●	●	※	※
2020	Grandland-X	RADIO (Radio)	●	●	●	●	●
2020	Grandland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2020	Grandland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2020	Grandland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2020	Grandland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Grandland-X	SLSCM-D (Seat Lumbar Support Control Module - Driver)	●	●	●	●	●
2020	Grandland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Grandland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2020	Grandland-X	TCM (Transmission Control Module)	●	●	●	●	※
2020	Grandland-X	TCS (Traction Control Switch)	●	※	※	●	●
2020	Grandland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Grandland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2020	Grandland-X	VPCM (Video Processing Control Module)	●	●	●	●	●
2020	Insignia-B	AA (Audio Amplifier)	●	●	●	●	※
2020	Insignia-B	ASCM (Active Safety Control Module)	●	●	●	●	●
2020	Insignia-B	BCM (Body Control Module)	●	●	●	●	●
2020	Insignia-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Insignia-B	ECM (Engine Control Module)	●	●	●	●	●
2020	Insignia-B	FCM (Frontview Camera Module)	●	●	●	●	●
2020	Insignia-B	HC (HVAC Controls)	●	●	●	※	※
2020	Insignia-B	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Insignia-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Insignia-B	IC (Instrument Cluster)	●	●	●	●	●
2020	Insignia-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2020	Insignia-B	LCM (Liftgate Control Module)	●	●	●	●	※
2020	Insignia-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2020	Insignia-B	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2020	Insignia-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Insignia-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2020	Insignia-B	PST (Power Supply Transformer)	●	●	●	●	※
2020	Insignia-B	RADIO (Radio)	●	●	●	●	●
2020	Insignia-B	RC (Radio Controls)	●	●	●	※	※
2020	Insignia-B	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2020	Insignia-B	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Insignia-B	SCM (Suspension Control Module)	●	●	●	●	●
2020	Insignia-B	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2020	Insignia-B	SMCM-D (Seat Memory Control Module - Driver)	●	●	●	●	●
2020	Insignia-B	SMCM-P (Seat Memory Control Module - Passenger)	●	●	●	●	●
2020	Insignia-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2020	Insignia-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2020	Insignia-B	TCM (Transmission Control Module)	●	●	●	●	●
2020	Insignia-B	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Insignia-B	VPCM (Video Processing Control Module)	●	●	●	●	●
2020	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2020	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2020	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2020	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2020	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●

2020	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2020	Movano-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2020	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2020	Movano-B	MDWCM (Mobile Device Wireless Charger Module)	●	●	●	●	※
2020	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Movano-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2020	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2020	Movano-B	RADIO (Radio)	●	●	●	●	●
2020	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2020	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2020	Movano-B	SDGM-S (Serial Data Gateway Module - Secondary)	●	●	●	●	※
2020	Movano-B	SDGM3 (Serial Data Gateway Module 3)	●	●	●	●	※
2020	Movano-B	SOSCM (Side Object Sensing Control Module)	●	●	●	●	●
2020	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2020	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●