

OPEL INJ Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	INJ
2002	Combo	●
2004	Agila	●
2004	Astra-H	●
2004	Combo	●
2004	Corsa-C	●
2004	Vectra-C-Signum	●
2005	Agila	●
2005	Astra-H	●
2005	Combo	●
2005	Meriva	●
2005	Tigra-B	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Agila	●
2006	Astra-H	●
2006	Combo	●
2006	Meriva	●
2006	Tigra-B	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Agila	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-H	●
2007	CaptivaLong-Body	●
2007	Combo	●
2007	Corsa-D	●
2007	Meriva	●
2007	Tigra-B	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-H	●
2008	CaptivaLong-Body	●
2008	Corsa-D	●
2008	Meriva	●
2008	Tigra-B	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-H	●
2009	CaptivaLong-Body	●
2009	Corsa-D	●
2009	Meriva	●
2009	Tigra-B	●
2009	Zafira-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-H	●
2010	CaptivaLong-Body	●
2010	Corsa-D	●
2010	Meriva	●
2010	Meriva-B	●
2010	Zafira-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-H	●
2011	CaptivaLong-Body	●

2011	Corsa-D	●
2011	Meriva-B	●
2011	Zafira-B	●
2012	Antara	●
2012	Astra-H	●
2012	Corsa-D	●
2012	Meriva-B	●
2012	Zafira-B	●
2013	Antara	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Antara	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Insignia	●
2015	Meriva-B	●
2015	Zafira-C	●
2016	Astra-J	●
2016	Astra-K	●
2016	Zafira-C	●
2017	Astra-J	●
2017	Astra-K	●
2017	Crossland-X	●
2018	Astra-J	●
2018	Astra-K	●
2018	Crossland-X	●
2018	Grandland-X	●
2018	Mokka	●
2019	Astra-K	●
2019	Crossland-X	●
2019	Grandland-X	●
2019	Mokka	●
2019	Combo-E	●
2020	Crossland-X	●
2020	Grandland-X	●

INJ Function List

Cylinder 1 Injector
Cylinder 1 Injector Flow Identifier
Cylinder 2 Injector
Cylinder 2 Injector Flow Identifier
Cylinder 3 Injector
Cylinder 3 Injector Flow Identifier
Cylinder 4 Injector
Cylinder 4 Injector Flow Identifier
Injector Flow Rate Programming
Replace Injector