

PORSCHE MIS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	ETC
911 (991)	●
911 (996)	●
911 (997)	●
918 Spyder	●
Boxster/Cayman (981)	●
Boxster/Cayman (982)	●
Boxster/Cayman (986)	●
Boxster/Cayman (987)	●
Cayenne-9PA (Up to 2010)	●
Cayenne-92A (2011 - 2017)	●
Cayenne-9YA (As of 2018)	●
Macan	●
Panamera-970 (Up to 2017)	●
Panamera-971 (As of 2018)	●

MIS Function List

Activate instrument cluster

Activation of key retaining solenoid

Activation state memory

Actual values

Actual/specified configuration

Adaptations

Adjusting adaptive cruise control system

Adopt bank 1 diesel particulate filter mileage in the DME

Adopt bank 2 diesel particulate filter mileage in the DME

Adopt particle filter mileage in the DME

AHBA Calibration

Alarm event memory

Bleed fuel system

Bleeding high temperature coolant circuit

Calibrate

Calibrate fuel-level sensor

Calibrate longitudinal acceleration sensor

Calibrate rear lid

Calibrate seat occupancy detection

Calibration

Calibration of combination sensor

Clutch actuator and separating clutch

Compressor bypass flap

Compressor run-in

Control unit type

Crash record

Delete adaptation data

Display servotronic emergency operation counter

Display test images

Drive link test: damper valves

ELV identification

Empty the tank

Erase adaptation values

Events

Exhaust gas recirculation test
First start
Fluid fill mode
Front-axle final drive replacement
Function activation
Function enable
Gate resetting the range calculation
Gateway installed components list
Grille air shutter
HBA calibration
Headlight beam adjustment calibration
Headlight commissioning
Hydraulic swap test
Kick-down adaptation
Kick-down threshold
MOST system reserve
Multimedia interface test
Normalise seat motors (Driver)
Normalise seat motors (Passenger)
Occupant detection, replacement/commissioning
Oil filling
Porsche stability management sensor calibration
Power windows standardization run (front left)
Power windows standardization run (front Right)
Power windows standardization run (Rear left)
Power windows standardization run (Rear Right)
Pre-calibration camera
Pressure sensor calibration
Pump test
Radiator shutter
Read out ready status
Read system time and AWS status
Ready status
Reducing agent system
Replacement of several components or replacement of the pressure accumulator
Reset
Reset adaption values
Reset dipped beam values
Reset high beam values
Reset Personalization
Reset static cornering light values
Reset tank calibration value
Restoration of the tank sensor calibration values from the rear-end electronic control unit
Rolling test mode
Save fuel level sensor comparison values to rear-end electronic control unit
Self-test
Sensor cluster compensation
Service position
Set ready status
Set total mileage
Short tests
Single-wire test
Sleep mode
Sliding/lifting roof standardization
Speed sensor test
Standardisation of sliding roof/panorama roof
Standardizing power windows (front left)
Standardizing power windows (Passenger)

Standardizing power windows (Rear Left)
Standardizing power windows (Rear Right)
Static test
Steering column adjustment normalising run
Swap test
Swirl-flap actuator
Swirl-flap actuator, bank 1
Swirl-flap actuator, bank 2
System adaptation
System check
System exchange
System tests
Tank calibration
Tank leakage diagnostics
Tank leakage diagnostics (if system is installed)
Teach electronic steering column lock
Teach headlight beam adjustment
Teach reversible belt tensioners
Teach seat occupancy detection
Teach sensors
Teach steering column adjustment
Teaching sensors
Total distance
Transfer-box oil service
Valve actuation
Wake-up guardian
Wiping angle adaptation