

TOYOTA/LEXUS/SCION LAP Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Car List

CarMode	CarMode	CarMode	CarMode
ALPHARD HV	ALPHARD HV/VELLFIRE HV	ALPHARD/VELLFIRE	AURIS
AURIS HV	Avalon	Avalon HV	AVENSIS
AYGO	CAMRY	CAMRY HV	CAMRY/AURION
CENTURY	C-HR	C-HR HV	COROLLA
COROLLA AXIO	COROLLA HV	COROLLA HV/AURIS HV	COROLLA VERSO
COROLLA/AURIS	CROWN	CROWN HV	CROWN MAJESTA
CT200h	ES200	ES250	ES300h
ES350	FORTUNER/HILUX SW4	GS F	GS200t
GS250	GS300	GS300h	GS350
GS450h	GX400	GX460	HARRIER
Highlander	HIGHLANDER HV	HIGHLANDER/KLUGER	Hilux
IS200t	IS250	IS300	IS300h
IS350	LAND CR PRADO	LAND CR.	LAND CRUISER
LAND CRUISER PRADO	LC500	LC500h	LS350
LS460	LS500	LS500h	LS600h
LX450d	LX570	MIRAI	NX200
NX200t	NX300	NX300h	PRIUS
PRIUS +/PRIUS V/PRIUS ALPHA	PRIUS C	PRIUS PHV	PRIUS Plug-in
Prius Prime	RAV4	Rav4 HV	RC200t
RC300	RC300h	RC350	RC-F
RX200t	RX300	RX350	RX450h
SEQUOIA	Sienna	Tacoma	TUNDRA
VERSO	Yaris	YARIS HV	ZZZ3_P4C

LAP Function List (Note:For reference only)

BSM Master Abnormal History

BSM Master Beam Axis Adjustment

BSM Master Beam Axis Display

BSM Master Beam Axis Inspection

BSM Slave Abnormal History

BSM Slave Beam Axis Adjustment

BSM Slave Beam Axis Display

BSM Slave Beam Axis Inspection

Headlight Type Setting