





















# Assembly Instructions

<b>A</b> 5 PCS 	<b>B</b> 1 PC 
<b>C</b> 1 PC 	<b>D</b> 1 PC 
<b>E</b> 1 PC 	<b>F</b> 1 PC 
<b>G</b> 1 PC 	<b>H</b> 1 SET 
<b>I</b> 1/4"x7/8" 4 PCS 	<b>J</b> 5/16"x1-1/4" 4 PCS 
<b>K</b> 5/16"x1-3/4" 4 PCS 	<b>L</b> 4 PCS 
<b>M</b> 4 PCS 	<b>N</b> 1 PC 



P/N:D1003018A03