

# PYRAMID

## 12411 & 12412 Yamaha MT-09 Seat Cowl

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

[sales@pyramid-plastics.co.uk](mailto:sales@pyramid-plastics.co.uk)  
+44 (0)1427 677990  
[www.pyramid-plastics.co.uk](http://www.pyramid-plastics.co.uk)



# PYRAMID

## 12411 & 12412 Yamaha MT-09 Seat Cowl

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

[sales@pyramid-plastics.co.uk](mailto:sales@pyramid-plastics.co.uk)  
+44 (0)1427 677990  
[www.pyramid-plastics.co.uk](http://www.pyramid-plastics.co.uk)



# PYRAMID

## 12411 & 12412 Yamaha MT-09 Seat Cowl

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

[sales@pyramid-plastics.co.uk](mailto:sales@pyramid-plastics.co.uk)  
+44 (0)1427 677990  
[www.pyramid-plastics.co.uk](http://www.pyramid-plastics.co.uk)

