

PYRAMID



12414G Yamaha MT-10SP Seat Cowl Fitting Instructions

Please note: this Seat Cowl is designed to fit the standard MT-10 seat and not the comfort seat.

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Re-fit the seat to the bike.

Got questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

PYRAMID



12414G Yamaha MT-10SP Seat Cowl Fitting Instructions

Please note: this Seat Cowl is designed to fit the standard MT-10 seat and not the comfort seat.

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Re-fit the seat to the bike.

Got questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

PYRAMID



12414G Yamaha MT-10SP Seat Cowl Fitting Instructions

Please note: this Seat Cowl is designed to fit the standard MT-10 seat and not the comfort seat.

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Re-fit the seat to the bike.

Got questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

PYRAMID



12414G Yamaha MT-10SP Seat Cowl Fitting Instructions

Please note: this Seat Cowl is designed to fit the standard MT-10 seat and not the comfort seat.

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Re-fit the seat to the bike.

Got questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!