

RAD Children's Furniture Custom-made Furniture for Infants and Toddlers, Inspired

by RIE, PIKLER, and WALDORF.

310-266-8973
INFO@RADchildrensFurniture.com
3130 by St. | Los Angeles, CA 90034

ROCKER ASSEMBLY INSTRUCTIONS

Please FULLY read these instructions before you start assembling the Rocker

In the box:

- (2) Rocker Sides
- (2) Dowels
- (9) Slats
- (22) Screws

The dowel and slats fit snugly into the holes, so make sure they are all the way in when assembling it.

- 1. Place one side of the Rocker on a flat hard surface with the holes facing up.
- 2. Put all the slats and the dowels in the holes of one side of the Rocker, knocking the ends with a hammer if needed until they sit firmly at the bottom of the holes.
- 3. When done, place the other side of the Rocker on top of the steps and dowels, working from one end to the other. Again, tapping with a hammer as needed so the slats and dowels go all the way into the holes.
- 4. Using provided screws, screw the side of the Rocker to the slats and dowels through the predrilled holes leaving the screws slightly loose.
- 5. Carefully flip the Rocker so its other side is facing up and put the rest of the screws in leaving them slightly loose as well.
- 6. Place the Rocker so it's resting on its four feet making sure that they all sit flat on the floor. Screw the screws the rest of the way in tight.

NOTE A: In order not to damage the side with a hammer, place a flat piece of scrap board, on the surface on which you will use the hammer, as a protection. or use a "dead weight hammer" if you have one.