

# FILL PORT WATER SEAL

## Tools Needed

*No Tools Needed*

This document will walk you through installing a fill port water seal on the Mopit Mid.

## FOLLOW THESE STEPS

**Step 1.** Unlatch the 3 buckle latches

**Step 2.** Remove adhesive paper from the black seal


**Step 3.** Apply the black seal to the top of the lower tank as seen in the picture. Apply the seal in a similar pattern shown in the picture.

**Step 4.** Re-attach the tank and attach the buckle latches

**Purpose:** This seal is to prevent water from flowing into the vacuum cavity when overfilling the solution tank. This will extend the life of your vacuum motor.



Buckle Latches (3)



Fill Port Water Seal



Fill Port Area