FILL PORT WATER SEAL

Tools Needed

No Tools Needed

This document will walk you through adding a fill port water seal on your Mopit mini.

## FOLLOW THESE STEPS

Step 1. Unlatch the 3 buckle latches

Step 2. Remove adhesive paper from the black seal

Step 3. Apply the black seal to the bottom of the upper tank as seen in the picture. The seal should be within 1/8 inch from the outer edge of the plastic.

Step 4. Re-attach the tank and attach the buckle latches

Purpose: This seal is to prevent water from flowing into the vacuum cavity when overfilling the solution tank. This can help extend the life of the vacuum motor.

Buckle Latches (3)

Apply seal 1/8" away from this edge

Fill Port Water Seal

Fill Port Area