

Laundry Detergent - unscented

Ingredients	Function	CAS
aqua / water / eau	SOLVENT	7732-18-5
sodium coco-sulfate	SURFACTANT	97375-27-4
lauryl glucoside	SURFACTANT	110615-47-9
myristyl glucoside	SURFACTANT	54549-26-7
caprylyl glucoside	SURFACTANT	29836-26-8
sodium chloride	VISCOSITY CONTROLLING	7647-14-5
citric acid	BUFFERING	77-92-9
sodium gluconate	CHELATING	527-07-1
sodium benzoate	PRESERVATIVE	532-32-1
glycerin	HUMECTANT	56-81-5
camellia sinensis (green tea / thé vert) leaf extract	SKIN CONDITIONING	84650-60-2