

Mini Illuminated Mark Making Boards

Light Up Learning on the move.



User Guide www.tts-group.co.uk

QČS


Important Information

- Please retain the information in this User Guide for future reference.
- Please read all instructions fully before using.
- To clean, wipe the surface with a clean damp cloth.
- Do not allow the product to come into contact with water or any other liquids.
- Keep the product away from direct sunlight and heat.
- If your product malfunctions please switch it off and then back on again to reset it.

Pack Contents

- 6 Mini Mark Making Boards
- User guide

Know Your Product



Mini Illuminated Mark Making Boards

Using Your Product

To switch the Board on, move the slide switch to the ON position.

The first colour when switched on will be Red. To cycle through the seven colours press the button on the front of the Writing Board once for each colour change. When the colour Red is reached again it will automatically cycle through the colours in sequence. Pressing the button again whilst in automatic sequence mode will turn the writing board back to red.

Always switch your Illuminated Writing Board off using the on/off switch to preserve the battery life.

Each board has a slot to insert an A5 sized card if required. (not provided).

Battery Precautions

- Batteries are to be inserted with the correct polarity.
- The supply terminals are not to be short circuited.
- Only batteries of equal size and type should be used.
- Non-rechargable batteries are not to be recharged.

Replacing Batteries

- Remove the battery hatch cover and carefully remove the batteries and dispose of them responsibly.
- Insert new batteries, ensuring the correct polarity. Replace the battery hatch firmly.
- Different types of batteries or new and used batteries are not to be mixed.
- Exhausted batteries are to be removed from the toy.
- This product used 3 X 1.5V AAA batteries (not included)



Trouble Shooting

Problem	Solution
Writing Board will not light up	Ensure that the slide switch is in the ON position
	Ensure the batteries are inserted correctly
	Replace discharged batteries

Technical Support

Please visit www.tts-group.co.uk for the latest product information.

Email feedback@tts-group.co.uk for technical support.

TTS Group Ltd. Park Lane Business Park Kirkby-in-Ashfield Nottinghamshire NG17 9GU, UK. Freephone: 0800 318686 Freefax: 0800 137525

WARNING: Do not dispose of this product in household waste.

WARNING: Hand it over to a collection point for recycling electronic appliances.

WARNING: Not suitable for children under 36 months due to small parts- choking hazard

Made in China, on behalf of TTS Group Ltd.

TTS Product Code: EY10006



TTS is proud to be part of **RM**[°] plc