


BLADE[®]


70S

**Instruction Manual
Bedienungsanleitung
Manuel d'utilisation
Manuale di istruzioni**



RTF

Exploded View



Parts Listings

Part #	Description
	BLH4200 Blade 70 S RTF
1	BLH4201 Replacement Canopy: 70 S
2	BLH4202 Replacement flight controller w/ Case: 70 S
3	BLH4203 Replacement Tail Assembly w/Motor: 70 S
4	BLH4204 Replacement main frame with servos: 70 S
5	BLH4205 Replacement Main Motor : 70 S
6	BLH4206 Main rotor blades (2): 70 S
7	BLH4207 Replacement Tail Blades (4): 70 S

Part #	Description
8	BLH4208 Replacement Landing Gear(2): 70 S
9	BLH4209 Complete Rotor Head
10	BLH4212 Body Post/Servo Linkage: 70 S
11	BLH4213 Replacement Main Gear (2): 70 S
12	BLH4214 Swash Plate: 70 S
13	BLH4215 Blade Grips w/ Hardware: 70 S
	BLH4210 Replacement battery: 70 S
	BLH4211 USB 1s Charger: 70 S

©2017 Horizon Hobby, LLC.

Blade is a registered trademark of Horizon Hobby, LLC.

All other trademarks, service marks and logos are property of their respective owners. Patents pending.

Created 10/17

57140

BLH4200