

Kit contents



Kit contents

- 1. The fuselage assembly (With the motor, the canopy, the electronic parts, ESC)
- 2. Vertical stabilizer assembly
- 3. Horizontal stabilizer with the elevator
- 4. Landing gear set
- 5. Propeller and spinner
- 6. Spare parts bag
- 7. Wing tube and the stay bar

The spare parts list

Replacement parts for the FMS Sky trainer 182 are available using the order numbers in the Spare parts list that follows. The fastest, most economical service can be provided by your hobby dealer or mail-order company.

Spare parts list content

Spare parts list content

MG 101 Fuselage (With all the plastic parts installed)

MG 102 Red/Blue/AT-Red/AT-Blue Main wing set (With the control horn in stored)

MG 103 Red/Blue/AT-Red/AT-Blue Vertical stabilizer

MG 104 Horizontal stabilizer

MG 105 Cowl

MG 106 Spinner (With the back plate)

MG 201 Motor (3536-KV850)

MG 202 ESC (35A with 4A integrated BEC)



MG 203 Battery (11.1V 2200mAh 25C)

MG 205 Servo (9g)

MG 206 LED set (Navigation light and the landing light)

MG 301-Red/blue/AT Red/AT Blue Landing gear set (The main and the front landing gear)

MG 302 Linkage rod (With the clevis and securing ring)

MG 303 Stay bar

MG 304 Screw set

MG 305-Red/Blue/AT Red/AT Blue Sticker

MG 306 Propeller (11*9 three blades durable propeller)

MG 307 Motor mount

MG 308 Firewall

MG 309 Wing tube

MG 310 Motor shaft

Note: The item# with the color mark means the parts are special for the different scheme.

The illustration of the spare parts



MG 101



MG 102



MG 103



MG 104



MG 105



MG 106



MG 201



MG 202



MG 203



MG 205



MG 206



MG 301



MG 302



MG 303




MG 304



MG 305




MG 306



MG 307



MG 308



MG 310