

Replacement Parts

Part #	Description
EFL310017	LAS Cover: Apprentice STS
EFLA1030FB	30-Amp Telemetry Capable ESC
EFLM480BL	480 BL Outrunner Motor; 960Kv
EFLP09060	Prop P-51 BL 9 x 6; Sportsman S
HBZ3218	Pushrod Set: Sport Cub
HBZ3219	Wing Tube Carbon Cub
HBZ3220	Fuselage: Carbon Cub S+ 1.3m
HBZ3221	Main Wing: Carbon Cub S+ 1.3m
HBZ3222	Tail Set: Carbon Cub S+ 1.3m
HBZ3223	LandingGearSet:CarbonCub S+ 1.3
HBZ3224	Cowl: Carbon Cub S+ 1.3m
HBZ3225	Spinner 40mm: Carbon Cub S+ 1.3
HBZ3226	Wing Struts: Carbon Cub S+ 1.3m
HBZ3227	Mtr Mnt w/Scrws:CarbonCub S+1.3
HBZ3228	Battery Hatch:Carbon Cub S+ 1.3
HBZ3229	Decal Sheet: Carbon Cub S+ 1.3m
HBZ3230	Vrtx Gents:CarbonCub S+1.3m
HBZ3233	Prop Adapter: Carbon Cub S
HBZ3234	LG Covers: Carbon Cub S+
SPM4650C	DSMX SRXL2 RX w/Connector
SPMA3230A	Carbon Cub S2 FC
SPMR1010	DXS Transmitter Only
SPMSA381	9g Sub-Micro Servo: 400mm Lead

Recommended Parts

Part #	Description
SPMXPSA200	Smart G2 Air Powerstage 2

Optional Parts

Part #	Description
DYN1405	LiPo Charge Protection Bag, Large
EFL1090	DSV130 3-Wire Digital Srvo MT G
EFLA250	Park Flyer Tool Asst, 5 pc
HBZ7390	Float Set: Super Cub LP
SPM9747	DSMX SRXL2 Remote Receiver
SPMA3052	Standard Servo Extension 9"
SPMA3173	Spektrum GPS Module
SPMA3180	Landing Assist Sensor (LAS)
SPMR6650	DX6e 6CH Transmitter Only
SPMX13003S30M	1300mAh 3S 11.1V Smart 30C LiPo;IC3
SPMX22003S30	2200mAh 3S 11.1V Smart 30C; IC3
SPMXBC100	SMART Battery & Servo Tester
SPMXC1080	Smart S1100 AC Charger, 1x100W

Hardware

Location	Description	Quantity
Spinner	2.5mm x 8mm Machine Screw	1
Cowl	2mm x 5mm Round Head Self-Tapping Screw	3
Motor mount	3mm x 10mm Round Head Screw	4
Firewall	3mm x 12mm BT Self-Tapping Screw	4
Wing mount	3mm x 12mm Round Head Screw	5
Flap plate(left)	2mm x 10mm Pointed Self-Tapping Screw	2
Flap plate(right)	2mm x 10mm Pointed Self-Tapping Screw	2
Control horn (main wings)	3mm x 16mm Round Head Screw	2
	2mm x 18mm Round Head Screw	2
Interplane strut mount	2.5mm x 10mm Pointed Self-Tapping Screw	6
Wire mount(float)	2.5mm x 10mm Flat Head Self-Tapping Screw	4
Nose landing gear plate	2.5mm x 10mm Flat Head Self-Tapping Screw	4
Battery door	2.5mm x 12mm Pointed Self-Tapping Screw	1
Servo arm (main wings)	2mm x 4mm PB Flat Head Machine Screw	2
Servo arm (fuselage)	2mm x 4mm PB Flat Head Machine Screw	2
Rear landing gear mount	3mm x 14mm Pointed Self-Tapping Screw	2
Wire mount(tail wheel)	2mm x 8mm Round Head Self-Tapping Screw	3
Servo arm (flap)	2mm x 4.5mm Pan Head Triangular Self-Tapping Screw	1
Wheel	2.5mm x 4mm Round Head Machine Screw	2