

Assembly



1. Back out the retaining screw with the correct Allen wrench provided, until the screw is not visible within the stock opening. Do not unscrew completely. Insert the limb into the stock so that the white lines are even on either side of the stock opening. Place the two rubber pads on the front and back side of the limb within the stock opening. Place the metal pressure pad in between the front rubber pad and the retaining screw.



2. Tighten retaining screw using the wrench provided. Do not overtighten.



3. Attach limb tips to each end of the limb with the string spacers pointing towards the back of the crossbow. Make sure to **FIRMLY** press the limb tips onto the crossbow limb to ensure a snug fit. Loop the string around the left side of the limb and then twist the string in your right hand between 4-6 rotations. This will ensure optimal string performance. Place the crossbow straight down on the ground as shown. Step on the left side of the limb with your foot. With your left hand, grab the right side of the limb and pull towards the body of the crossbow. While holding the limb, string the right side of the limb with your right hand.

WARNING: You will need to use a good deal of force when stepping down on/pulling on the limb to get it strung. Please use caution when stringing the crossbow.

Attaching the Fore Grip



4. Slide the fore grip onto the lower Weaver rail. Move the fore grip to your preferred position.



5. Drop the 2 nuts into the slots provided on the grip.



6. While holding the 2 nuts in place with your fingers, flip the crossbow over and insert the bolts into the opposite holes. Secure the bolts in place with the correct Allen wrench provided.

WARNING: Do not fire the crossbow without the Fore Grip attached. When firing, the crossbow should be held firmly with two hands. Hold the crossbow by BOTH the Fore Grip (front) and the Pistol Grip (rear). Failure to hold the crossbow correctly could result in your hand/fingers getting hit by the string when fired resulting in injury.

Cocking the Crossbow



7. While holding the front of the crossbow as shown, press the red release button on the cocking lever with the other hand and then pull all the way down to cock the crossbow. The safety mechanism will automatically engage. Return cocking lever to original position.



8. Safety Switch Positioning:
Back = Safety On (Safe)
Forward = Safety Off (Ready to Fire)

Loading Bolt



9. With the safety on, place the bolt in the track as shown and push it back all the way.

WARNING: Do not load the bolt with the safety off. This could result in a dry fire / premature fire which could cause injury.

Release the safety mechanism by pressing forward. The crossbow is now ready to be fired.

Sight Adjustments



10. If the bolt is striking to the right, turn the windage knob clockwise. If the bolt is striking to the left, turn the windage knob counterclockwise.



11. If the bolt is striking either high or low, use the correct Allen wrench to loosen the bolt on the sight. Adjust the sight to your desired position and then re-tighten bolt to secure.

Stringing the Crossbow

****BEFORE OPERATING THE CROSSBOW MAKE SURE ALL SCREWS ARE SECURELY FASTENED, LIMB TIPS ARE FIRMLY PRESSED INTO THE LIMB AND STRING IS PROPERLY FITTED TO TIPS****

! WARNING

USE EXTREME CAUTION AT ALL TIMES WHEN HANDLING A CROSSBOW. FAILURE TO FOLLOW THESE RULES COULD RESULT IN SERIOUS INJURY OR DEATH.

- Do not shoot at people or pets
- Crossbows are for ages 18+
- Shooters and spectators should always wear proper eye protection when assembling and using crossbow
- Keep your fingers below the flight track and out of the path of strings when firing crossbow
- Do not cock or load crossbow until you intend to shoot
- Do not aim at anything you do not intend to shoot
- Only use your crossbow with BOLT brand bolts
- Do not shoot your crossbow without a bolt; result will be a dry fire which will damage the crossbow and string
- Do not use crossbow or bolts if damaged; this could cause injury

CHECK OUT ALL **BOLT** CROSSBOWS PRODUCTS AT

www.boltcrossbows.com

[f/boltcrossbows](https://www.facebook.com/boltcrossbows)

[@boltcrossbows](https://www.instagram.com/boltcrossbows)