



MODEL: L445
Solar Jar Light | Crackle Glass Lantern |
40LED | SPARKLE

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

 youtube.com/hoselink

User Manual

MODEL: L445
Solar Jar Light | Crackle Glass Lantern |
40LED | SPARKLE



HOSELINK[®]

Kit Contents

1 x Glass Crackle Jar Solar Light

With its unique design and 40LED light string, this Crackle Glass Jar Solar Light is perfect to illuminate any balcony, table or entertaining area. It can also be hung as a beautiful pendant light from a sunny pergola or tree branch.

Activate the Light

To activate the light, lift the aluminium lid and press the button on the underside. The same button can be used to turn the light off.

Rearrange the string of lights to fill the jar if needed.

To test the light function, cover the solar panel and confirm if it illuminates. The built-in intelligent sensor will automatically turn the light on at night and off at dawn.

Product Installation - Option 1

Placing the light.

Place on a tabletop, bench or in the garden. Simply position the light in a suitable location, making sure it has access to at least 8 hours of direct sunlight per day to fully charge.

Product Installation - Option 2

Hanging handle.

Use the rope to hang the light in a sunny location and enjoy!

Be sure to clean the solar panel periodically to maintain optimal performance.

Specifications

Solar panel	2V / 0.24W
LED Lumens	5–6 lumens
Light Temperature	3000–3200 kelvins
Lithium Battery	600mAh / 1.2V
Charge Time	8 hours
Working Time	7 hours

NOTE: if the light does not turn on, this could be due to the battery not being charged. Leave out in direct sunlight for 6–8 hours and try again.

WARNING: do not use underwater or in low lying puddles.