



MODEL: L280
Mounted Solar Spotlight |
Motion Sensor | 8LED | PINNACLE

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

 youtube.com/hoselink

User Manual

MODEL: L280
Mounted Solar Spotlight |
Motion Sensor | 8LED | PINNACLE



HOSELINK[®]

Kit Contents

1 x Spotlight
3 x Screws
3 x Plugs

Lighting Mode

Dim light sensor mode

Continuously emits a dim light (6 LEDs) from dusk until dawn, with a bright light for 15-20 seconds when motion is detected.

Activate the Light

To activate the light, click the IO button on the back of the light. Test by covering the solar panel completely to check that light comes on. The light is now ready for use.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6-8 hours per day. The motion sensor will detect movement up to 5m away.

STEP 2 Mounting the light

Use a 6mm drill piece for masonry installation. Once your hole is drilled, gently hammer the plugs into place and then secure the screws tightly. For timber, use a 3mm drill piece without the plugs. Hang the light and enjoy.

Be sure to clean the solar panel periodically to maintain optimal performance.

Specifications

Solar panel	5.5V / 1.22W
LED Lumens	2.5 lumens (dim light) 200 lumens (bright light)
Light Temperature	6500-6500 kelvins
Lithium Battery	2000mAh / 3.7V
Charge Time	6-8 hours
Waterproof Rating	IP65

NOTE: if the light does not turn on, this could be due to the battery not being charged. Leave out in direct sunlight for 6-8 hours and try again.