




Operating Guidelines

SA40™

ATTENTION! Do not use the machine before you have read and understood the Instructions for Use Manual.




1. Check the battery charge gauge (and if necessary re-charge).



2. Fill the tank with clean water.



3. Check to make sure the vacuum hose is connected to the squeegee.



4. Check to make sure the pad is clean.




5. Install the pad on the deck.



6. Check if the solution filter is clean.



7. Stand on the machine and turn the key on.



8. Press the One-Touch scrub button (squeegee will lower automatically).



9. Adjust the desired water flow.



10. Select double pressure if needed.




11. Select silent mode if needed.



12. Press the forward foot pedal, then select the direction and start operating the machine.



13. Empty the recovery tank with the squeezable hose.



14. If necessary, empty the solution tank through the solution valve and clean the filter net.



15. Remove and clean the debris tray.



16. Wash the recovery tank with clean water.



17. Remove debris from the scrub pad.



18. Take the squeegee off and check the blades' wear status.



19. Clean the machine using a damp cloth and park it with the recovery tank open.

If the machine has been used until the Red light illuminates on the battery level indicator on the machine, a full recharge of the batteries (10-12 hours) will be required. Failure to carry out this procedure may cause damage to the batteries. Charging the batteries after every use is recommended.



Troubleshooting SA40™

ATTENTION! Do not use the machine before you have read and understood the Instructions for Use Manual.

The machine
doesn't work
as it should?



- 1 Check the battery charge gauge (and if necessary re-charge).

The suction
doesn't work
as it should?



- 1 Check to make sure the vacuum hose is connected to the squeegee.




- 2 Open the recovery tank and check to see if the gasket and float cage are cleaned.



- 3 Check if squeegee blades are damaged or dirty.



- 4 Close the recovery tank properly and/or verify the gasket wear.



- 5 Check to see if the vac button is activated.

The machine
doesn't clean
as it should?



- 1 Check to see if you have solution in the tank.



- 2 Check to see if you have the right water setting.



- 3 Check to see if the filter is cleaned.

The pad
doesn't work
as it should?



- 1 Check to see if the pad is correctly installed and not worn out.



- 2 Check to make sure the pad is clean.



- 3 Check to see if there is debris preventing the pad from rotating.