










SC450 How To

Prepare for use

| | | | | | |
|-----------|--|-----------|--|-----------|---|
| 1 |  <p>Unplug battery charger.</p> | 2 |  <p>Wrap cord accordingly.</p> | 3 |  <p>Lower recovery tank lid.</p> |
| 4 |  <p>Inspect ball float cage.</p> | 5 |  <p>Fill solution tank with water (do not exceed 130°F).</p> | 6 |  <p>Inspect squeegee blade and install squeegee.</p> |
| 7 |  <p>Inspect brush or pad.</p> | 8 |  <p>Install brush or pad-holder under the deck.</p> | 9 |  <p>Turn on brush/pad-holder switch.</p> |
| 10 |  <p>Press handle button to engage brush. Repeat this step if necessary.</p> | 11 |  <p>Choose solution flow for the type of work to be performed.</p> | 12 |  <p>Lower squeegee lever.</p> |

SC450 How To Store the Machine

| | | | | | |
|-----------------|---|-----------------|--|-----------------|---|
| <p>1</p> |  <p>Empty recovery tank and solution tank.</p> | <p>2</p> |  <p>Wash recovery tank and vacuum grid with clean water.</p> | <p>3</p> |  <p>Inspect and clean, cover gasket, vacuum grid and automatic shut-off float.</p> |
| <p>4</p> |  <p>Inspect hoses; replace if kinked or damaged.</p> | <p>5</p> |  <p>Remove, rinse and inspect squeegee. Replace if needed.</p> | <p>6</p> |  <p>Remove, clean and inspect brush or pad. Rinse with warm water. Hang to dry. Replace if needed.</p> |
| <p>7</p> |  <p>Lift recovery tank lid.</p> | <p>8</p> |  <p>Charge batteries.</p> | <p>9</p> |  <p>Plug machine up to charge for next use.</p> |

SC450 How To Weekly Maintenance

| | | | | | |
|-----------------|---|-----------------|--|-----------------|---|
| <p>1</p> |  <p>Perform a squeegee blade check.</p> | <p>2</p> |  <p>Inspect and clean solution filter.</p> | <p>3</p> |  <p>Check each battery cell's water level (does not apply to gel batteries).</p> |
| <p>4</p> | <div style="border: 1px solid black; padding: 5px; text-align: center;">Six Month Maintenance</div> <p>Perform a screw and nut tightening check</p> | <p>5</p> | <div style="border: 1px solid black; padding: 5px; text-align: center;">Yearly Maintenance</div> <p>Brush/pad-holder motor carbon brush check or replacement</p> | <p>6</p> | <div style="border: 1px solid black; padding: 5px; text-align: center;">Yearly Maintenance</div> <p>Vacuum system motor carbon brush check or replacement</p> |