



dogsap.com

FLEXIBLE MEASURING TAPE CLAWGS SIZING GUIDE

SETUP

- Have your dog lay on its side.


STEP ONE

- Pinch the flexible measuring tape, or "tailor's tape", with your thumb's tip at the Clawg length that you would like to try.
- Each size's length is on the following table. (Centimeters is more precise and easier)


Sizes	Clawg Length cm (in)
Size 1	3.2 (1 1/4)
Size 2	3.7 (1 7/16)
Size 3	4.3 (1 11/16)
Size 4	4.9 (1 15/16)
Size 5	5.6 (2 3/16)
Size 6	6.4 (2 1/2)
Size 7	7.2 (2 13/16)
Size 8	8.1 (3 3/16)
Size 9	9.1 (3 9/16)
Size 10	10.1 (4)
Size 11	11.2 (4 7/16)
Size 12	12.4 (4 7/8)

STEP TWO

- Press the flexible measuring tape's pinched location against your dog's leg behind the metacarpal / metatarsal pad's ("heel pad's") furthest point from the front claws, which is not centered behind the heel pad.
- Your thumb should be at Clawgs' heel location, which is the leg's skinniest part directly behind the heel pad.



STEP TWO



STEP THREE

- Press the flexible measuring tape's loose end against your dog's front pads.
- Make sure your dog's wrist / ankle is bent as far as possible to its standing position.
- The flexible measuring tape's end is located at the front claw opening's edge for the size you are trying.

SIZE SELECTION

- Select the longest Clawg length that does not contact your dog's front claws' tips while your dog's wrist / ankle is fully bent to its standing position.
- Ideally, the flexible measuring tape will completely cover your dog's front pad but will not contact your dog's front claws' tips.

Note: Your dog's front paws and back paws may be different sizes.

Note: If you can't decide between two sizes, select the larger size.

STEP THREE

