-C-R-O-S-LE-Y

TURNTABLE BELT SETUP

STEP 1

Install the drive belt over the inner ring under the platter and make sure it won't fall off during the setup.

STEP 2

Place the platter through the turntable spindle, then rotate the platter until you see the drive motor pulley through the window at the top right corner.

STEP 3

Carefully grab the drive belt and put it around the slot of motor pulley







