


6 Ton Axle Spare Parts List



Note:
Left hand side brake assembly shown.
Right side assembly opposite hand.

BOM ID	Part Number	Description	Qty
1	AP6123	Hub Cap Bolt 5/16"	12
2	AP6121	6T Hub Cap	2
3	AP6122	6T Hub Cap Gasket	2
4	AP6119	6T Outer Axle Nut	2
5	AP6120TW	6T Axle Thrust Washer	2
6	AP6120	6T Lock Washer	2
7	AP6118	6T Inner Axle Nut	2
8	AP6117	6T Drum	2
9	AP6107	Bearing Cup & Cone Set	4
10	AP6104	6T Hub Assy	2
11	AP6111	Wheel Nut - M20 (suits 5T & 6T)	12
12	AP6108	Stud - M20 (suits 5T & 6T)	12

BOM ID	Part Number	Description	Qty
13	AP6113	Dual Wheel Nut Left Hand	12
14	AP6116	6T Hub Seal	2
15	AP6210	Camshaft - Left	1
16	AP6211	Camshaft - Right	1
17	AP6220	SCam Roller	4
18	AP6221	Roller Clip	4
19	AP6201	Brake Shoe Assy (311x100)	4
20	AP6224	Pin Return Spring	4
21	AP6205	Return Spring	2
22	AP6207	Anchor Pin Bush	4
23	AP6206	Anchor Pin Assy	4
24	AP6102	Brake Spider	2

BOM ID	Part Number	Description	Qty
25	AP6212	Camshaft Bush	2
26	AP6213	Camshaft Seal	4
27	AP6215	Camshaft Washer	8
28	AP6214	Camshaft Circlip	6
29	AP6217	Camshaft Mounting Bracket	2
30	AP6216	Cam Shaft Bush Mounting Kit	2
31	AP6219A	Auto Slack Adjuster	2
32	AP6225	Slack Adjuster Return Spring	2
33	AP6124	Brake Booster Mounting Bracket - 95mm	2
34	BC1216	Brake Booster 12/16	2
35	AP6100	Brake Shoe Replacement Kit (17, 18, 19, 20, 21, 22, 23)	2