



**Transport Equipment Australia**

58-62 Nissan Drive  
 Dandenong Vic 3175  
 Phone: 03 9791 4350  
 Fax: 03 9791 4354

<b>DAILY CHECKS</b>				
Drain water and condensation from the air system Ensure the air reservoirs have reached their operating pressure Check air bags have pressurised				
<b>MAINTENANCE</b>		ON DELIVERY	AFTER 1st TRIP	EVERY 6 MONTHS
Visual inspection of all components for damage and wear		●	●	●
Check condition of air bags		●	●	●
Check shock absorber mounting bolts for correct torque Torque setting is M16 - 200Nm		●	●	●
Check U Bolts for correct torque Torque setting is M16 - 350Nm		●	●	●
Check pivot bolts for correct torque Torque setting is M27 - 1,000Nm		●	●	●
When mounting a new trailing arm M27 - 200Nm PLUS 270				
Check airbag mounting Torque setting is M12 - 66Nm M16 - 200Nm		●	●	●