



Side by Side


WSE6670BA/SA
WSE6630SA/WA
WSE6640BA





Minimum Recommended Airspaces



Please note: Doors are designed to sit proud of cabinetry (not flush).



When positioned in a corner area, spacing of at least 350mm on the fridge side, 350mm on the freezer side will allow the doors to open enough to enable the removal of bins and shelves.



Front face of bench aligned to front corner edge of cabinet.

Front face of bench aligned to front corner edge of cabinet.

Dimensions	Product Height (H)	Product Width (W)	Product Depth (D)
WSE6670BA	1780	911	746
WSE6670SA	1780	911	746
WSE6630SA	1780	911	746
WSE6630WA	1780	911	746
WSE6640BA	1780	911	746

Airspace	Side - both	Top	Behind
WSE6670BA	10	10	50
WSE6670SA	10	10	50
WSE6630SA	10	10	50
WSE6630WA	10	10	50
WSE6640BA	10	10	50

IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm). For complete installation instructions, refer to the manual provided with product.
© 2021 Electrolux Home Products Pty Ltd. ABN 51 004 762 341. W_DIM_SxS_WSE6670-30-40_Oct21