



DECORATO A MANO  
HAND DECORATED

# LABIRINTO



NERO



ZAFFIRO



SCARLATTO



SMERALDO

LABIRINTO NERO - TABLEWARE



PIATTO PANE | BREAD PLATE  
004RG00 FPT110 01 0160 G00125100  
CM 16 IN. 6 1/2



PIATTO DESSERT | DESSERT PLATE  
004RG00 FPT110 01 0220 G00125100  
CM 22 IN. 7 3/4



PIATTO PIANO | FLAT PLATE  
004RG00 FPT110 01 0280 G00125100  
CM 28 IN. 11



PIATTO FONDO | SOUP PLATE  
004RG00 FPT210 01 0245 G00125100  
CM 24,5 IN. 9 1/2



SEGNAPOSTO | CHARGER PLATE  
044RG00 FPT100 01 0310 G00125100  
CM 31 IN. 12 1/4



COPPETTA | FRUIT BOWL  
004RG00 FCP000 01 0140 G00125100  
CM 14 IN. 5 1/2



TAZZA CAFFÈ | COFFEE CUP  
004RG00 FTZ301 01 0800 G00125100  
CC 80 OZ. 2 3/4



PIATTO CAFFÈ | COFFEE SAUCER  
004RG00 FPT301 01 0110 G00125100  
CM 11 IN. 2 3/4



TAZZA TÈ | TEA CUP  
004RG00 FTZ401 01 0220 G00125100  
CC 220 OZ. 7 3/4

LABIRINTO COLLECTION



PIATTO TÈ | TEA SAUCER  
004RG00 FPT401 01 0135 G00125100  
CM 13,5 IN. 5 1/4

LABIRINTO NERO - GIFTWARE



MUG  
004RG00 FTZ701 01 0400 G00125100  
CC 400 OZ. 13 1/2



TAZZA CAFFÈ CON PIATTO E COPERCHIO,  
SET PER 2 | TÊTE À TÊTE COFFEE SET  
004RG00 FX9176 01 G00125100



PIATTO CENTROTAVOLA | PLATE  
140RG00 FPT110 01 0310 G00125100  
CM 31 IN. 12 1/4



PIATTO SVUOTASCHE QUADRATO |  
VIDE POCHES SQUARED PLATE  
172RG01 FVS121 01 30X G00125100  
CM 30 IN. 12



COPPA QUADRATA BASSA |  
LOW SQUARED CUP  
172RG01 FCP220 01 13X G00125100  
CM 13,5 IN. 5 1/4



COPPA GIO PONTI | GIO PONTI BOWL  
020RG00 FG6499 01 G00125100  
H CM 11 IN. 4 1/4

LABIRINTO NERO - GIFTWARE



SCATOLA TALCO CON COPERCHIO I  
ROUND BOX WITH COVER  
017RG02 FX5080 01 G00125100  
CM 13 IN 5

LABIRINTO NERO - TABLEWARE



VASSOIO ROTONDO I ROUND FLAT PLATTER  
004RG00 FPT110 01 0305 G00125100  
CM 30,5 IN. 12



VASSOIO OVALE PIANO I  
FLAT OVAL PLATTER  
004RG00 FVS130 01 0340 G00125100  
CM 34 IN. 13 1/4



VASSOIO OVALE PIANO I  
FLAT OVAL PLATTER  
004RG00 FVS130 01 0400 G00125100  
CM 40 IN. 15 1/2



RAVIERA I PICKLE DISH  
004RG00 FRV000 01 0235 G00125100  
CM 23,5 IN. 9 1/4



INSALATIERA I SALAD BOWL  
004RG00 FIN000 01 0265 G00125100  
CM 26,5 IN. 10 1/2

LABIRINTO NERO - GIFTWARE



MUG CON COPERCHIO | MUG WITH COVER  
004RG00 FTZ703 01 0400 G00125100  
CC 400 OZ. 13 1/2



TEIERA PER 6 CON COPERCHIO |  
TEAPOT WITH COVER FOR 6  
004RG00 FTE400 01 0900 G00125100  
LT 0,90 OZ. 30 1/2



LATTIERA PER 2 | MILK JUG FOR 2  
004RG00 FLT000 01 0135 G00125100  
CC 135 OZ. 4 1/2



ZUCCHERIERA PER 2 | SUGAR BOWL FOR 2  
004RG00 FZU000 01 0150 G00125100  
CC 150 OZ. 5

LABIRINTO NERO - TABLEWARE



ZUPPIERA OVALE | TUREEN WITH COVER  
004RG00 FZP030 01 0400 G00125100  
LT 4 OZ. 141



SALSIERA | GRAVY BOAT  
004RG00 FSA010 01 0300 G00125100  
CC 300 OZ. 11

*Anteprima non disponibile*  
Preview not available

CUCCHIAIO SALSIERA | GRAVY BOAT SPOON  
004RG00 FSA003 01 GEN G00125100

LABIRINTO NERO - GIFTWARE



VASO CACHEPOT | CACHEPOT VASE  
020RG00 FA6467 01 0190 G00125100  
H CM 19 IN. 7 1/2

LABIRINTO ZAFFIRO - TABLEWARE



PIATTO PANE | BREAD PLATE  
004RG00 FPT110 01 0160 G00125200  
CM 16 IN. 6 1/2



PIATTO DESSERT | DESSERT PLATE  
004RG00 FPT110 01 0220 G00125200  
CM 22 IN. 7 3/4



PIATTO PIANO | FLAT PLATE  
004RG00 FPT110 01 0280 G00125200  
CM 28 IN. 11



PIATTO FONDO | SOUP PLATE  
004RG00 FPT210 01 0245 G00125200  
CM 24,5 IN. 9 1/2



SEGNAPOSTO | CHARGER PLATE  
044RG00 FPT100 01 0310 G00125200  
CM 31 IN. 12 1/4



VASSOIO ROTONDO | ROUND FLAT PLATTER  
004RG00 FPT110 01 0305 G00125200  
CM 30,5 IN. 12



VASSOIO OVALE PIANO |  
FLAT OVAL PLATTER  
004RG00 FVS130 01 0340 G00125200  
CM 34 IN. 13 1/4



VASSOIO OVALE PIANO |  
FLAT OVAL PLATTER  
004RG00 FVS130 01 0400 G00125200  
CM 40 IN. 15 1/2



RAVIERA | PICKLE DISH  
004RG00 FRV000 01 0235 G00125200  
CM 23,5 IN. 9 1/4





INSALATIERA | SALAD BOWL  
004RG00 FIN000 01 0265 G00125200  
CM 26,5 IN. 10 1/2



COPPETTA | FRUIT BOWL  
004RG00 FCP000 01 0140 G00125200  
CM 14 IN. 5 1/2



TAZZA CAFFÈ | COFFEE CUP  
004RG00 FTZ301 01 0800 G00125200  
CC 80 OZ. 2 3/4



PIATTO CAFFÈ | COFFEE SAUCER  
004RG00 FPT301 01 0110 G00125200  
CM 11 IN. 2 3/4



TAZZA TÈ | TEA CUP  
004RG00 FTZ401 01 0220 G00125200  
CC 220 OZ. 7 3/4



PIATTO TÈ | TEA SAUCER  
004RG00 FPT401 01 0135 G00125200  
CM 13,5 IN. 5 1/4

## LABIRINTO ZAFFIRO - GIFTWARE



MUG  
004RG00 FTZ701 01 0400 G00125200  
CC 400 OZ. 13 1/2



MUG CON COPERCHIO | MUG WITH COVER  
004RG00 FTZ703 01 0400 G00125200  
CC 400 OZ. 13 1/2

LABIRINTO COLLECTION



TEIERA PER 6 CON COPERCHIO |  
TEAPOT WITH COVER FOR 6  
004RG00 FTE400 01 0900 G00125200  
LT 0,90 OZ. 30 1/2



LATTIERA PER 2 | MILK JUG FOR 2  
004RG00 FLT000 01 0135 G00125200  
CC 135 OZ. 4 1/2



ZUCCHERIERA PER 2 | SUGAR BOWL FOR 2  
004RG00 FZU000 01 0150 G00125200  
CC 150 OZ. 5



PIATTO CENTROTAVOLA | PLATE  
140RG00 FPT110 01 0310 G00125200  
CM 31 IN. 12 1/4



PIATTO SVUOTATASCHE QUADRATO |  
VIDE POCHE SQUARED PLATE  
172RG01 FVS121 01 30X G00125200  
CM 30 IN. 12



COPPA QUADRATA BASSA |  
LOW SQUARED CUP  
172RG01 FCP220 01 13X G00125200  
CM 13,5 IN. 5 1/4



COPPA GIO PONTI | GIO PONTI BOWL  
020RG00 FG6499 01 G00125200  
H CM 11 IN. 4 1/4

## LABIRINTO COLLECTION



SCATOLA TALCO CON COPERCHIO |  
ROUND BOX WITH COVER  
017RG02 FX5080 01 G00125200  
CM 13 IN 5

## LABIRINTO ZAFFIRO - TABLEWARE



ZUPPIERA OVALE | TUREEN WITH COVER  
004RG00 FZP030 01 0400 G00125200  
LT 4 OZ. 141



SALSIERA | GRAVY BOAT  
004RG00 FSA010 01 0300 G00125200  
CC 300 OZ. 11

## LABIRINTO ZAFFIRO - GIFTWARE



TAZZA CAFFÈ CON PIATTO E COPERCHIO,  
SET PER 2 | TÊTE À TÊTE COFFEE SET  
004RG00 FX9176 01 G00125200



VASO CACHEPOT | CACHEPOT VASE  
020RG00 FA6467 01 0190 G00125200  
H CM 19 IN. 7 1/2



LABIRINTO SCARLATTO - TABLEWARE



PIATTO PANE | BREAD PLATE  
004RG00 FPT110 01 0160 G00125300  
CM 16 IN. 6 1/2



PIATTO DESSERT | DESSERT PLATE  
004RG00 FPT110 01 0220 G00125300  
CM 22 IN. 7 3/4



PIATTO PIANO | FLAT PLATE  
004RG00 FPT110 01 0280 G00125300  
CM 28 IN. 11



PIATTO FONDO | SOUP PLATE  
004RG00 FPT210 01 0245 G00125300  
CM 24,5 IN. 9 1/2



SEGNAPOSTO | CHARGER PLATE  
044RG00 FPT100 01 0310 G00125300  
CM 31 IN. 12 1/4



COPPETTA | FRUIT BOWL  
004RG00 FCP000 01 0140 G00125300  
CM 14 IN. 5 1/2



TAZZA CAFFÈ | COFFEE CUP  
004RG00 FTZ301 01 0800 G00125300  
CC 80 OZ. 2 3/4



PIATTO CAFFÈ | COFFEE SAUCER  
004RG00 FPT301 01 0110 G00125300  
CM 11 IN. 2 3/4



TAZZA TÈ | TEA CUP  
004RG00 FTZ401 01 0220 G00125300  
CC 220 OZ. 7 3/4

LABIRINTO COLLECTION



PIATTO TÈ | TEA SAUCER  
004RG00 FPT401 01 0135 G00125300  
CM 13,5 IN. 5 1/4

LABIRINTO SCARLATTO - GIFTWARE



MUG  
004RG00 FTZ701 01 0400 G00125300  
CC 400 OZ. 13 1/2



TAZZA CAFFÈ CON PIATTO E COPERCHIO,  
SET PER 2 | TÊTE À TÊTE COFFEE SET  
004RG00 FX9176 01 G00125300



PIATTO CENTROTAVOLA | PLATE  
140RG00 FPT110 01 0310 G00125300  
CM 31 IN. 12 1/4



PIATTO SVUOTATASCHE QUADRATO |  
VIDE POCHE SQUARED PLATE  
172RG01 FVS121 01 30X G00125300  
CM 30 IN. 12



COPPA QUADRATA BASSA |  
LOW SQUARED CUP  
172RG01 FCP220 01 13X G00125300  
CM 13,5 IN. 5 1/4



COPPA GIO PONTI | GIO PONTI BOWL  
020RG00 FG6499 01 G00125300  
H CM 11 IN. 4 1/4

LABIRINTO COLLECTION



SCATOLA TALCO CON COPERCHIO I  
ROUND BOX WITH COVER  
017RG02 FX5080 01 G00125300  
CM 13 IN 5

LABIRINTO SCARLATTO - TABLEWARE



VASSOIO ROTONDO I ROUND FLAT PLATTER  
004RG00 FPT110 01 0305 G00125300  
CM 30,5 IN. 12



VASSOIO OVALE PIANO I  
FLAT OVAL PLATTER  
004RG00 FVS130 01 0340 G00125300  
CM 34 IN. 13 1/4



VASSOIO OVALE PIANO I  
FLAT OVAL PLATTER  
004RG00 FVS130 01 0400 G00125300  
CM 40 IN. 15 1/2



RAVIERA I PICKLE DISH  
004RG00 FRV000 01 0235 G00125300  
CM 23,5 IN. 9 1/4



INSALATIERA I SALAD BOWL  
004RG00 FIN000 01 0265 G00125300  
CM 26,5 IN. 10 1/2

LABIRINTO SCARLATTO - GIFTWARE



MUG CON COPERCHIO | MUG WITH COVER  
004RG00 FTZ703 01 0400 G00125300  
CC 400 OZ. 13 1/2



TEIERA PER 6 CON COPERCHIO |  
TEAPOT WITH COVER FOR 6  
004RG00 FTE400 01 0900 G00125300  
LT 0,90 OZ. 30 1/2



LATTIERA PER 2 | MILK JUG FOR 2  
004RG00 FLT000 01 0135 G00125300  
CC 135 OZ. 4 1/2



ZUCCHERIERA PER 2 | SUGAR BOWL FOR 2  
004RG00 FZU000 01 0150 G00125300  
CC 150 OZ. 5



LABIRINTO SCARLATTO - TABLEWARE



ZUPPIERA OVALE | TUREEN WITH COVER  
004RG00 FZP030 01 0400 G00125300  
LT 4 OZ. 141



SALSIERA | GRAVY BOAT  
004RG00 FSA010 01 0300 G00125300  
CC 300 OZ. 11

LABIRINTO SCARLATTO - GIFTWARE



VASO CACHEPOT | CACHEPOT VASE  
020RG00 FA6467 01 0190 G00125300  
H CM 19 IN. 7 1/2

LABIRINTO SMERALDO - TABLEWARE



PIATTO DESSERT | DESSERT PLATE  
004RG00 FPT110 01 0220 G00125400  
CM 22 IN. 7 3/4



PIATTO PIANO | FLAT PLATE  
004RG00 FPT110 01 0280 G00125400  
CM 28 IN. 11



PIATTO FONDO | SOUP PLATE  
004RG00 FPT210 01 0245 G00125400  
CM 24,5 IN. 9 1/2



COPPETTA | FRUIT BOWL  
004RG00 FCP000 01 0140 G00125400  
CM 14 IN. 5 1/2



TAZZA CAFFÈ | COFFEE CUP  
004RG00 FTZ301 01 0800 G00125400  
CC 80 OZ. 2 3/4



PIATTO CAFFÈ | COFFEE SAUCER  
004RG00 FPT301 01 0110 G00125400  
CM 11 IN. 2 3/4



TAZZA TÈ | TEA CUP  
004RG00 FTZ401 01 0220 G00125400  
CC 220 OZ. 7 3/4



PIATTO TÈ | TEA SAUCER  
004RG00 FPT401 01 0135 G00125400  
CM 13,5 IN. 5 1/4

LABIRINTO SMERALDO - GIFTWARE



COPPA GIO PONTI | GIO PONTI BOWL  
020RG00 FG6499 01 G00125400  
H CM 11 IN. 4 1/4

LABIRINTO SMERALDO - TABLEWARE



PIATTO PANE | BREAD PLATE  
004RG00 FPT110 01 0160 G00125400  
CM 16 IN. 6 1/2

LABIRINTO SMERALDO - GIFTWARE



MUG  
004RG00 FTZ701 01 0400 G00125400  
CC 400 OZ. 13 1/2