





**Warning**

- Not a toy, do not climb on net
- Keep fingers away from hinges and joints
- Must be used with adult supervision




**Assembly Instructions for  
12' and 18' Nets**




1. With center hinge on the ground. Extend frame to 6'. (1 click) for 12' net . and 9' (2 clicks) for 18' net Repeat for Other side of net




2. Twist Frame over and swing both sides open




3. Open to full width, laying both hinges on the ground.




4. Depress buttons located in hinges and swing legs out to locked position.



5. Repeat with all four legs



6. Take a black pole and slide it down the orange net sleeve. Placing the end into the frame tube. Loop the cord over the rod top (A) Repeat using remaining pole thru other sleeve.



7. Grip Rod pushing direction (C) whilst pulling Orange sleeve up and looping Cord over Pole Top

1 year limited Manufactures Warranty on Manufacturing defects only. 30 day money back guarantee. For a full description of Warranty-Guarantee-Terms & Conditions. See [www.thebownet.com](http://www.thebownet.com)

Triad Sports Group LLC. 4690 Calle Quetzal Camarillo, California 93012 866.950.NETS