## **IMPORTANT**

## Do Not Return To The Place Of Purchase

If there is a problem or question about your net contact BOWNET directly

## Warning:

NOTICE

- · Only use and set up with adult supervision.
- · Don't drag. Use two people to move net.
- Don't leave net 'set up' unatended, overnight or for extended.periods in inclement weather.
- · Keep fingers away from hinges and joints
- · Only use a flat thumb to depress buttons
- Net must only be used for the Sport for which it was designed.
- Replace damaged or missing parts IMMEDIATELY
- · Never climb or hang on net or framework. .




1. With center hinge on the ground.Extend frame to 6'.(1 click) for 12'net.
And to 9' (2 clicks) for 18' net




Assembly Instructions for 12' and 18' Nets




Twist Frame over and swing both sides open




3. Open to full width, laying both hinges on the ground.



4. Depress buttons located in hinges and swing legs out to locked position.



5. Repeat with all four legs



6. Take a black pole and slide it down the orange net sleeve. Placing the end into the frame tube. Loop the cord over the rod top (A) Repeat using remaining pole thru other sleeve.

7. Grip Rod pushing direction (C)
whilst pulling Orange sleeve up
and looping Cord over Poll Top

1 year limited Manufactures Warranty on Manufacturing defects only.
For a full description of Warranty-Guarantee-Terms & Conditions.
See www.bownet.net/pages/warranty-page

## CA PROPOSITION 65 WARNING

WARNING: This product is fabricated from materials which may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Triad Sports Group LLC. 912 Pancho Rd. Camarillo California 93012
Phone 805 322 8844 - Visit www.bownet.net - E-mail cs@bownet.net