IMPORTANT NOTICE

Do Not Return To The Place Of Purchase

If there is a problem or question about your net contact BOWNET directly


Warning:

- · Only use and set up with adult supervision.
- · Don't drag. Use two people to move net.
- Don't leave net 'set up' unatended, overnight or for extended periods in inclement weather.
- · Keep fingers away from hinges and joints
- · Only use a flat thumb to depress buttons
- Net must only be used for the Sport for which it was designed.
- · Replace damaged or missing parts IMMEDIATELY
- Never climb or hang on net or framework. Always keep net securely anchored with stakes or sandbags. Unsecured net can fall over causing serious injury or death.










 Swing net open and place one hinge on the ground then open to full width, and lay both hinges on the ground



2. Hold legs and swing them out to the locked position.



3. Repeat with all four legs



4. Take a black pole (with silver coupling) and slide it down the orange net sleeve. Placing the end into the frame tube.



5. Slot pole (with groved top) into silver coupling of lower pole and slide orange sleeve up



6. Loop the cord over the rod top



7. Insert pole on other side



8. Finally loop cord over rod top

1 year limited Manufactures Warranty on Manufacturing defects only. For a full description of Warranty- Guarantee-Terms & Conditions. See www.bownet.net/pages/warranty-page

CA PROPOSITION 65 WARNING

WARNING: This product is fabricated from materials which may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Triad Sports Group LLC. 912 Pancho Rd. Camarillo California 93012 Phone 805 322 8844 - Visit www.bownet.net - E-mail cs@bownet.net