

JOSÉ EBER

Infrared Blow Dryer

For virtual salon instructions or
to shop the José Eber store please visit
www.joseeberhair.com
www.joseeberhair.eu

© 2013 TOL, Inc. José Eber is a registered trademark of José Eber, Inc. José Eber name, signature, likeness and logo are used under license. All rights reserved.

FEATURES & INSTRUCTIONS

FEATURES

- True far-infrared heating core for healthier hair
- Professional AC motor, 1800 watts
- Low noise fan
- 2 speed, 2 heat setting and cool shot functions
- Antimicrobial UV light for the cleanest hair possible


INSTRUCTIONS AND STYLING TIPS

After shampooing and conditioning hair, towel-dry hair to remove any excess moisture.

1. Section hair appropriate for your hair type. Thicker hair will require smaller sections.
2. Use the heat and fan speed controls to adjust the blow dryer to the desired setting.
3. With the dryer and your styling brush, direct the air in a downward motion from root to tip continuously moving the dryer down each section allowing the air to pass through each section evenly. Do not concentrate heat in one location for any length of time to prevent burning or damaging hair or scalp.
4. For added volume lift hair at the root while shooting a blast of cool air upward toward the roots / scalp by using the cool shot button.

For quick touch up, dampen hair slightly and style with the dryer.

Attach one of the two included concentrator nozzles when you need to focus drying power to specific areas. Use the concentrator for more control while you style.




FEATURES & INSTRUCTIONS

NORTH AMERICAN CUSTOMER ONLY

CHECK ALCI SAFETY FEATURE EVERY TIME YOU USE APPLIANCE.

This appliance is equipped with an Appliance Leakage Circuit Interrupter (ALCI), a safety feature that renders it inoperable under some abnormal conditions, such as immersion in water. To make sure the ALCI is functioning properly, perform the following test. The purpose of this test is to allow you to make sure the water sensing system (ALCI) is working.

1. Plug in the appliance and press test button on plug (See appropriate diagram below).
 2. The appliance will stop working. There will be an audible click and reset button will pop out.
 3. To reset ALCI with a reset button, unit should be unplugged. Then push reset button in, and reinsert plug into outlet.
 4. If ALCI is not functioning properly, return appliance to nearest service center.
 5. Be sure to repeat test every time you use the unit, to confirm ALCI is operational.
- Should the appliance go off and the reset button pop up during use, this could indicate a malfunction in the unit. Remove plug from outlet and allow the appliance to cool. Reinsert plug into outlet.



SAFETY

USER MAINTENANCE INSTRUCTIONS

- Your appliance is virtually maintenance free.
- Keep parts & surfaces clean and free from dust, dirt and chemicals (such as hair spray).
- If cleaning becomes necessary, remember to disconnect the appliance from the power supply and allow to cool, then wipe the exterior with a damp (never wet) cloth. If the cord becomes twisted or tangled, untangle it before use.

STORAGE

- Before storing the appliance, let it cool down first.
- Appliance should be kept in a place which is safe, dry and out of reach of children.
- Never wrap the cord around the appliance or the cord will wear and break prematurely. Avoid jerking, bending sharply, twisting or straining the cord or plug.

For questions regarding this product, please contact:

TOL, Inc.: support@tolproducts.com
26570 Agoura Rd. Suite #180, Calabasas, CA 91302

READ ALL INSTRUCTIONS BEFORE USING.

WARNING: If any malfunction occurs, DO NOT attempt to repair it. There are no user-serviceable parts.

KEEP THE UNIT AWAY FROM WATER.

DANGER: As for most electrical appliances, electrical parts are electrically live even if the unit is turned off.

Always hold the blow dryer by the handle only!

Do not focus the heat on one area for too long.

When using electrical appliances, especially when children are present, please always follow the basic safety precautions as listed in this manual.

LIFETIME WARRANTY

TOL, Inc. and Buzz Beauty Ltd. provide a limited lifetime replacement warranty on this appliance, covering any breakage, failure to heat, or other malfunction due to design or manufacturing defect, for as long as you own the product. This warranty does not apply to problems which are the result of misuse, or normal wear and tear. To invoke the warranty, send the appliance with all its parts to the address below. Include your name, address, telephone number, email address, and a brief explanation of the problem. You must also include a copy of your sales receipt, and payment in the amount of US\$24.95, or UK£19.95 to cover the cost of shipping and handling of your replacement product. No refunds will be issued. Canadian customers: money orders are accepted only from a U.S. bank. The manufacturer's lifetime warranty is not applicable to any purchases made from any unauthorized dealers or unauthorized resellers of José Eber hair appliances and will not be honored. You may confirm that a reseller is authorized to sell José Eber hair appliances by contacting customer service directly at the respective address below. For questions regarding this warranty, please contact:

For warranties in North America:

TOL, Inc.: support@tolproducts.com
26570 Agoura Rd. Suite #180
Calabasas, CA 91302

For warranties in United Kingdom and Europe:

Buzz Beauty Limited : cs@buzzretail.co.uk
Suites 1-3, SweetSpace (802)
Highgate Studios, 53/79 Highgate Road
London NW5 1TL

JOSÉ EBER

Infrared Blow Dryer

For virtual salon instructions or
to shop the José Eber store please visit
www.joseeberhair.com
www.joseeberhair.eu

SAFETY

For reducing fatal risk by electrocution:

- Always unplug the appliance immediately after using.
- Do not use while bathing or showering.
- Do not place or store the appliance where it can fall or be pulled into a water tub or sink.
- Do not place in or drop into water or other liquid.
- If the appliance falls into water, unplug it immediately. Do not reach into water.

To reduce the risk of burns, electrocution, fire or injury to any person:

- User should not leave an appliance unattended when it is plugged in.
- Extra care should be paid when appliance is used by, on, or near children or individuals with certain disabilities.
- Do not use any attachments which are not provided by the manufacturer. Follow all instructions mentioned in this manual when using.
- Never use the appliance when cord or plug are damaged. Also, if the appliance does not work properly or is dropped into water/fluid, do not use it and return the appliance to a service center for examination and repair.
- Keep the power cord away from heated surfaces. Do not wrap the cord around the appliance.
- Do not use outdoors and never use the appliance together with any aerosol (spray) products.
- Never use this appliance while oxygen is administered.
- Never use while sleeping.
- Do not use an extension cord with this appliance.
- Do not put hair care products or water directly on the blow dryer.

DANGER- ELECTROCUTION POSSIBLE IF USED OR DROPPED IN TUB. UNPLUG AFTER USING

DANGER- ELECTROCUTION UTILISE OU SI POSSIBLE EN BAISSE TUB, DEBRANCHER MOYEND, APRES.

WARNING- DO NOT IMMERSE IN WATER. HOUSEHOLD USE ONLY.

AVERTISSEMENT- NE PAS PLONGER DANS L'EAU. UTILISATION DE MENAGE SEULEMENT.



Made in China

SAVE THESE INSTRUCTIONS

BY MAIL

By returning your registration form you're actively registering your product. Complete the information below and mail with a copy of your receipt to "TOL Inc." or to "Buzz Beauty Ltd."

NAME _____

ADDRESS _____

CITY/STATE/ZIP _____

PHONE _____

EMAIL _____

PRODUCT NAME / MODEL / UPC OR EAN # _____

PURCHASED FROM _____

DATE OF PURCHASE _____

ONLINE

www.joseeberhair.com
www.joseeberhair.eu

To invoke your limited lifetime warranty, please take a moment to register within 90 days of purchase. A valid limited lifetime warranty requires that terms and conditions be followed.