

JOSÉ EBER

QuickShine Infrared Blow Dryer

For virtual salon instructions or
to shop the José Eber store please visit
www.joseeberhair.com
www.joseeberhair.eu

©2015 TOL, Inc. José Eber is a registered trademark
of José Eber, Inc. José Eber name, signature, likeness
and logos are used under license. All rights reserved.

FEATURES & INSTRUCTIONS

FEATURES

- True far-infrared heating core for healthier hair
- Professional DC motor
- Low noise fan
- 2 speed, 2 heat setting and cool shot functions


INSTRUCTIONS AND STYLING TIPS

After shampooing and conditioning hair, towel-dry hair to
remove any excess moisture.

1. Section hair appropriate for your hair type. Thicker hair will
require smaller sections.
2. Use the heat and fan speed controls to adjust the blow dryer
to the desired setting.
3. With the dryer and your styling brush, direct the air in a
downward motion from root to tip continuously moving the
dryer down each section allowing the air to pass through each
section evenly. Do not concentrate heat in one location for any
length of time to prevent burning or damaging hair or scalp.
4. For added volume lift hair at the root while shooting a blast
of cool air upward toward the roots / scalp by using the cool
shot button.

For quick touch up, dampen hair slightly and style with the
dryer.

Attach the included concentrator nozzle when you need to
focus drying power to specific areas. Use the concentrator for
more control while you style.



SAFETY

USER MAINTENANCE INSTRUCTIONS

- Your appliance is virtually maintenance free.
- Keep parts & surfaces clean and free from dust, dirt and
chemicals (such as hair spray).
- If cleaning becomes necessary, remember to disconnect
the appliance from the power supply and allow to cool, then
wipe the exterior with a damp (never wet) cloth. If the cord
becomes twisted or tangled, untangle it before use.

STORAGE

- Before storing the appliance, let it cool down first.
- Appliance should be kept in a place which is safe, dry and out of
reach children.
- Never wrap the cord around the appliance or the cord will wear
and break prematurely. Avoid jerking, bending sharply, twisting or
straining the cord or plug.

For questions regarding this product, please contact:

TOL, Inc.: support@tolproducts.com
26570 Agoura Rd. Suite #180, Calabasas, CA 91302

READ ALL INSTRUCTIONS BEFORE USING.

**WARNING: If any malfunction occurs, DO NOT
attempt to repair it. There are no user-serviceable
parts.**

KEEP THE UNIT AWAY FROM WATER.

**DANGER: As for most electrical appliances,
electrical parts are electrically live even if the unit
is turned off.**

Always hold the blow dryer by the handle only!

Do not focus the heat on one area for too long.


When using electrical appliances, especially when
children are present, please always follow the
basic safety precautions as listed in this manual.

SAFETY

IN NORTH AMERICA CHECK ALCI SAFETY FEATURE EVERY TIME YOU USE APPLIANCE.

This appliance is equipped with an Appliance
Leakage Circuit Interrupter (ALCI), a safety
feature that renders it inoperable under some
abnormal conditions, such as immersion in
water. To make sure the ALCI is functioning
properly, perform the following test. The pur-
pose of this test is to allow you to make sure
the water sensing system (ALCI) is working.

1. Plug in the appliance and press test button
on plug (See appropriate diagram below).
 2. The appliance will stop working. There will be
an audible click and reset button will pop out.
 3. To reset ALCI with a reset button, unit
should be unplugged. Then push reset button
in, and reinsert plug into outlet.
 4. If ALCI is not functioning properly, return
appliance to nearest service center.
 5. Be sure to repeat test every time you use
the unit, to confirm ALCI is operational.
- Should the appliance go off and the reset button
pop up during use, this could indicate a
malfunction in the unit. Remove plug from
outlet and allow the appliance to cool.
Reinsert plug into outlet.



LIFETIME WARRANTY

TOL, Inc. and Buzz Beauty LLC, provide a limited lifetime
replacement warranty on this appliance, covering any
breakage, failure to heat, or other malfunction due to design
or manufacturing defect. This warranty does not apply to
problems which are the result of misuse, or normal wear and
tear. To invoke the warranty, send the appliance with all its
parts to the address below. Include your name, address,
telephone number, email address, and a brief explanation of
the problem. You must also include a copy of your sales
receipt, and payment in the amount of US\$19.95, or
UK£19.95 to cover the cost of shipping and handling of your
replacement product. No refunds will be issued. Canadian
customers: money orders are accepted only from a U.S.
bank. The manufacturer's lifetime warranty is not applicable
to any purchases made from any unauthorized dealers or
unauthorized resellers of José Eber hair appliances and will
not be honored. You may confirm that a reseller is
authorized to sell José Eber hair appliances by contacting
customer service directly at the respective address below.
For questions regarding this warranty, please contact:

For warranties in North America:

TOL, Inc.: cs@tolproducts.com
26570 Agoura Rd. Suite #180
Calabasas, CA 91302

For warranties in United Kingdom and Europe:

Buzz Beauty Limited : cs@buzzretail.co.uk
Suites 1-3, Sweetspace (802)
Highgate Studios, 53/79 Highgate Road
London NW5 1TL

JOSÉ EBER

QuickShine Infrared Blow Dryer

For virtual salon instructions or
to shop the José Eber store please visit
www.joseeberhair.com
www.joseeberhair.eu


IMPORTANT SAFETY INSTRUCTIONS

For reducing fatal risk by electrocution:

- Always unplug the appliance immediately after using.
- Do not use while bathing or showering.
- Do not place or store the appliance where it can fall or be
pulled into a water tub or sink.
- Do not place in or drop into water or other liquid.
- If the appliance falls into water, unplug it immediately. Do
not reach into water.

To reduce the risk of burns, electrocution, fire or injury to any person:

- User should not leave an appliance unattended when it is
plugged in.
- Extra care should be paid when appliance is used by, on, or
near children or individuals with certain disabilities.
- Do not use any attachments which are not provided by the
manufacturer. Follow all instructions mentioned in this
manual when using.
- Never use the appliance when cord or plug are damaged.
Also, if the appliance does not work properly or is dropped
into water/fluid, do not use it and return the appliance to a
service center for examination and repair.
- Keep the power cord away from heated surfaces. Do not
wrap the cord around the appliance.
- Do not use outdoors and never use the appliance together
with aerosol (spray) products.
- Never use this appliance while oxygen is administered.
- Never use while sleeping.
- Do not use an extension cord with this appliance.
- Do not put hair care products or water directly on the
appliance.



**WARNING - DO NOT IMMERSER IN WATER,
HOUSEHOLD USE ONLY.**
**AVERTISSEMENT - NE PAS PLONGER DANS L'EAU,
UTILISATION DE MENAGE SEULEMENT.**

SAVE THESE INSTRUCTIONS

BY MAIL

By returning your registration form, you're actively registering your
product. Complete the information below and mail with a copy of
your receipt to TOL, Inc. or Buzz Beauty LLC.

NAME _____

ADDRESS _____

CITY/STATE/ZIP _____

PHONE _____

EMAIL _____

PRODUCT NAME / MODEL / UPC OR EAN # _____

PURCHASED FROM _____

DATE OF PURCHASE _____

ONLINE

www.joseeberhair.com
www.joseeberhair.eu

To invoke your limited lifetime warranty, please take a moment to
register within 90 days of purchase. A valid limited lifetime warranty
requires that terms and conditions be followed.