










Please read this document in its entirety prior to fitting the seat cover. If you have any specific questions or troubles fitting the seat cover, please contact us first, as we are more than willing to assist with any enquiry.


	<p>Step 1) Push the front seats as far forward to the front of the vehicle, to ensure an easier fitment of the rear seat cover.</p>
	<p>Step 2) Remove all 3 headrests by pressing the button on the side and lifting the headrest out completely.</p>
	<p>Step 3) Turn the neoprene headrest cover inside out and place on the headrest.</p>
<div style="display: flex; justify-content: space-around;"> <div data-bbox="236 1554 483 1861"> <p>'Rolling on'</p>  </div> <div data-bbox="563 1554 826 1861"> <p>Front View</p>  </div> </div>	<p>Step 4) Roll the headrest cover onto the headrest (the headrest cover should no longer be inside out). The 'Feature thread' should be facing the front of the vehicle. The back sewn thread facing the rear – As per the photos to the left.</p> <p>Please Note: The Centre headrest is a different size, please refer to Step 6.</p>

<p>Rear View</p> 	
	<p>Step 5) Secure the touch tape tabs</p>
<p>Pre Fitment</p>  <p>How Fitment should look underneath</p> 	<p>Step 6 – Centre Headrest instructions - As per the pictures to the left, fit the headrest cover by placing the headrest into the headrest cover. Squeeze the foam in the headrest to make it easier to fit the headrest cover. Note: Please be gentle when fitting the headrest cover, as it is a tight, custom-fit design.</p> <p>How Fitment should look once the headrest is re-fitted – The photo below is an example of the Toyota HiLux (however it is similar in nature)</p> 
	<p>Step 7) Place the headrests safely to one side, as they will be re-fitted in Step 9</p>

	<p>Step 8) Backrest Fitment – Lower the backrest by pulling the tag in the middle. For the easiest fitment of the backrest seat cover, lower the backrest to a 45-degree angle.</p>
	<p>Step 9) Place the backrest cover over the seat back. To ensure the easiest possible fitment, you should re-fit one headrest at a time through the eyelets. This will act as a locking mechanism for the seat cover, so that it can be fitted much easier in the later steps. Note: Ensure that the covers is fitted underneath the seat belt (not over the top of it). Once fitted, ensure that the tag, which is used to lower the backrest, are lined up and gently pulled through the slits.</p>
	<p>Step 10) Carefully tuck the neoprene between the gap of the backrest and the cushion. This will be used to join the velcro to the carpet on the other side of the backrest.</p>
	<p>Step 11) In this step you will fit the velcro to the carpet, which is located on the back of the backrest. In order to do this lower the backrest section (as per Step 8) to a flat position. Pull the neoprene through the gap as far as possible (as per Step 10) to ensure that the backrest cover has a tight snug fit. Once pulled through sufficiently, remove the protective touch tape and affix to the carpet on the back of the backrest. Note: Please don't throw away the removed protective touch tape, as it will be necessary to keep in the event that you remove the seat covers – Further details included in 'Removal of the Seat Cover'</p>



Step 11) Ensure that it is a tight and snug fit. Re-align the Velcro where necessary. The photo to the left indicates how it should look once the backrest cover is fitted. When the armrest is not in use, simply leave it zipped up.



Step 13) **Cushion Fitment** – Note: The cushion doesn't lift, it is always in a fixed position. Roughly place the cover over the entire cushion section. It isn't necessary to have this perfect at this stage.




Step 14) Push Velcro at the back of the seat cover through the gap of the cushion and the backrest section. This is done easiest when the backrest is folded to a 45 degree angle or more (**See Step 8**). Be careful not to jam your hands.



Step 15) Once pulled all the way through, remove the protective touch tape and affix to the carpet on the back of the seat. Ensure it is tight enough and doesn't impede the isofix bars or points (see photos to the left).





Step 16) At the front of the cushion cover – start from the drivers side and work your way around the entire cushion section. Removing the touch tape as you go, gently lift the cushion ever so slightly so there’s a small gap for you to affix the Velcro to the carpet. This can be a little bit tricky as the cushion section doesn’t lift, however a gap can be created between the carpet and the floor purely by lifting it up with a bit of gentle force. The photos to the left indicate how the cushion fitment should look. If the cover doesn’t appear to look as tight as it should, it means that the cover should be pushed inwards more and affixed to the carpet further back.

Removal of the Seat Cover – Special Considerations

- 1) Removal of the headrest covers – Carefully remove the headrest from the base of the backrest. Once the headrest cover has been removed, please ensure that touch tape tabs are then secured together – This will prevent any damage / fraying of threads, as a result of the touch tape sticking to the threads on the seat cover.
- 2) Removal of the backrest and cushion cover – Once completely removed, re-attach protective touch tape tabs that were removed. This will prevent any damage / fraying of threads, as a result of the touch tape sticking to the threads on the seat cover.

On-going Maintenance / Care Instructions

- 1) Please use a warm cloth to remove any dirt or grime from the seat cover. Please then allow the seat cover to naturally dry.
- 2) Although our seat covers are incredibly durable, Global Automotive Accessories does not recommend that you vacuum your seat covers. Regular vacuuming over time, may compromise the strength of the seat cover. Please use other suitable methods (such as a dustpan) to remove excessive dust, dog hair etc.

Warranty Claims

Warranty claims are valid for 6 months and will only be accepted if the material or sewing is found to be defective. Photographic evidence must be provided prior to any goods being returned to Global Automotive Accessories for a warranty claim. Failure to follow the fitting instructions will void any warranty claims. Although the material is durable and stretchable in nature, if the cover is fitted too aggressively, like all materials it can tear. Please ensure that the covers are fitted gently and with care.

Any further questions please contact:

Andrew Leask
Owner / Director

Global Automotive Accessories
PO Box 6195
Croydon North VIC 3136
M: 0413 438 874
E: andrew@globalautomotive.com.au

Thank-you for your purchase

From all at Global Automotive Accessories we would like to thank-you for purchasing the Mitsubishi Triton MQ & MR – Rear Neoprene Seat Cover. Our success would not be possible without our loyal and valued customers. If you are satisfied with the quality of our products and services, we would greatly appreciate it if you could recommend our products to your family or friends.