



Samson XP310/XP312 Headset Sync Instructions

- Start with the speaker ON, and the headset OFF.
- On the rear of the speaker, hold down the DOWN arrow button for three seconds then release. The receiver will start scanning through the channels until it lands on a specific channel. Once it has chosen a channel, that channel will be flashing slowly on the display.
- Power the headset ON by holding down the power button for three seconds, then release. The light on the headset will turn green when it is ON.
- Quickly hold the back of the headset up to the receiver display for them to sync, hold there for 5-10 seconds.
- Once the headset is synced, the RF meter on the display will be lit up and you can control the headset volume with the knob labeled “wireless volume”.

*If you need to sync a second/backup headset to the speaker on the same channel, you will do the same steps as above except hold down the UP arrow instead.