


# MGI™ — ZIP SERIES —

## SEAT ASSEMBLY INSTRUCTION GUIDE



PART 1 SEAT

### PART 2 LEGS



PART 3 CROSSBAR

## ASSEMBLY

Requires Phillips Head screwdriver

1. Remove the 3 seat parts from the packaging and protective wrapping.
2. Open the seat compartment and remove the 2 bolts and nuts found inside.
3. Insert the legs into the slots underneath the seat compartment.  
*(See diagram 1)*
4. The seats Velcro tab should be the same side as the feet.
5. Insert the bolt from the outside of the leg and tighten the nut on the inside of the leg using a Phillips Head screwdriver.
6. Repeat for both sides.
7. Release the lever on the buggies undercarriage. *(See diagram 2)*
8. Insert the crossbar into the RIGHT HAND SIDE ONLY of the buggy.
9. The crossbar should protrude from both sides of the buggy evenly.  
*(See diagram 3)*
10. The crossbar sleeve should curve downwards towards the ground.  
(NB: If you have installed the crossbar upside down, the seat will not touch the ground when depressed)
11. Re-engage the lever on the buggies undercarriage to secure the crossbar.
12. Insert the seats male connection into the female sleeve. *(See diagram 4)*
13. Ensure the seat depresses correctly with your hand before sitting on it.
14. The seats feet should sit flush on the ground.



## SAFETY

Press down on seat before sitting to avoid applying uneven weight to the legs. Do not use the seat while buggy is moving.  
Ensure the legs are free of dirt and debris before depressing the seat.

For more information visit the [Zip Seat product page](#) on the MGI website or visit our [YouTube page](#) for instructional videos.

Follow us  /mgigolf  @mgigolf  
[www.mgigolf.com](http://www.mgigolf.com)