

RACKS BRAX.®

COMPATIBILITY POCKET GUIDE

FOR



RHINO-RACK®

MAKE SPACE FOR ADVENTURE

*FAST ON!
FAST OFF!*

AWNING AND ACCESSORY MODELS

CLICK OR TAP ON AN AWNING/ACCESSORY BELOW
TO TAKE YOU TO THE PAGE TO FIND OUT WHAT YOU NEED

RHINO-RACK® BATWING (*Left/Right*) 3

RHINO-RACK® BATWING COMPACT (*Left/Right*) 4

RHINO-RACK® SUNSEEKER 2.0m..... 5

RHINO-RACK® SUNSEEKER 2.5m..... 6



RHINO-RACK® BATWING *(Left/Right)*

HITCHES REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard*
ADAPTOR NEEDED	8192 – HD Awning Adaptor Plate (DOUBLE)*

*WILL ALSO WORK WITH THE TRIPLE VERSION.

BRACKETS OPTIONAL

MOUNTING POINTS	2
BRACKETS NEEDED	SUPPLIED BRACKETS FROM RHINO-RACK® WILL WORK WITH THE HD HITCH RANGE.
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*; OR
	8304 – HD Adjustable Brackets Short (DOUBLE)*; OR
<ul style="list-style-type: none"> ✓ FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP) 	8306 – HD Adjustable Brackets Long (DOUBLE)*.

*ROOF RACKS WITH PERIMETER LIPS REQUIRE **PACKERS** TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO [ROOF RACK GUIDE](#) FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.

WALL MOUNTS OPTIONAL

BENEFITS	ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.
SECURED LOCATION <ul style="list-style-type: none"> ✓ LOCKED GARAGES ✓ WORKSHOP WALLS 	8160 – HD Wall Mounts ⁺
UNSECURED LOCATION <ul style="list-style-type: none"> ✓ OPEN CARPORTS ✓ PUBLIC/SHARED GARAGE AREA 	8161 – HD Lockable Wall Mounts ⁺

⁺NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

RHINO-RACK® BATWING COMPACT *(Left/Right)*

HITCHES REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard*
ADAPTOR NEEDED	8192 – HD Awning Adaptor Plate (DOUBLE)*

*WILL ALSO WORK WITH THE TRIPLE VERSION.

BRACKETS OPTIONAL

MOUNTING POINTS	2
BRACKETS NEEDED	SUPPLIED BRACKETS FROM RHINO-RACK® WILL WORK WITH THE HD HITCH RANGE.
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*; OR 8304 – HD Adjustable Brackets Short (DOUBLE)*; OR
<ul style="list-style-type: none"> ✓ FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*; OR 8306 – HD Adjustable Brackets Long (DOUBLE)*.

*ROOF RACKS WITH PERIMETER LIPS REQUIRE **PACKERS** TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO [ROOF RACK GUIDE](#) FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.

WALL MOUNTS OPTIONAL

BENEFITS	ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.
SECURED LOCATION <ul style="list-style-type: none"> ✓ LOCKED GARAGES ✓ WORKSHOP WALLS 	8160 – HD Wall Mounts [†]
UNSECURED LOCATION <ul style="list-style-type: none"> ✓ OPEN CARPORTS ✓ PUBLIC/SHARED GARAGE AREA 	8161 – HD Lockable Wall Mounts [†]

[†]NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

RHINO-RACK® SUNSEEKER 2.0m

HITCHES REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard*

*WILL ALSO WORK WITH THE TRIPLE VERSION.

BRACKETS OPTIONAL

MOUNTING POINTS	2
BRACKETS NEEDED	SUPPLIED BRACKETS FROM RHINO-RACK® WILL WORK WITH THE HD HITCH RANGE.
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*; OR 8304 – HD Adjustable Brackets Short (DOUBLE)*; OR
<ul style="list-style-type: none"> ✓ FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*; OR 8306 – HD Adjustable Brackets Long (DOUBLE)*.

*ROOF RACKS WITH PERIMETER LIPS REQUIRE **PACKERS** TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO [ROOF RACK GUIDE](#) FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.

WALL MOUNTS OPTIONAL

BENEFITS	ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.
SECURED LOCATION <ul style="list-style-type: none"> ✓ LOCKED GARAGES ✓ WORKSHOP WALLS 	8160 – HD Wall Mounts ⁺
UNSECURED LOCATION <ul style="list-style-type: none"> ✓ OPEN CARPORTS ✓ PUBLIC/SHARED GARAGE AREA 	8161 – HD Lockable Wall Mounts ⁺

⁺NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

RHINO-RACK® SUNSEEKER 2.5m

HITCHES REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard*

*WILL ALSO WORK WITH THE TRIPLE VERSION.

BRACKETS OPTIONAL

MOUNTING POINTS	2
BRACKETS NEEDED	SUPPLIED BRACKETS FROM RHINO-RACK® WILL WORK WITH THE HD HITCH RANGE.
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*; OR 8304 – HD Adjustable Brackets Short (DOUBLE)*; OR
<ul style="list-style-type: none"> ✓ FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*; OR 8306 – HD Adjustable Brackets Long (DOUBLE)*.

*ROOF RACKS WITH PERIMETER LIPS REQUIRE **PACKERS** TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO [ROOF RACK GUIDE](#) FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.

WALL MOUNTS OPTIONAL

BENEFITS	ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.
SECURED LOCATION <ul style="list-style-type: none"> ✓ LOCKED GARAGES ✓ WORKSHOP WALLS 	8160 – HD Wall Mounts ⁺
UNSECURED LOCATION <ul style="list-style-type: none"> ✓ OPEN CARPORTS ✓ PUBLIC/SHARED GARAGE AREA 	8161 – HD Lockable Wall Mounts ⁺

⁺NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.