

RACKS BRAX.[®]

COMPATIBILITY POCKET GUIDE

FOR



MAXTRAX

**FAST ON!
FAST OFF!**

AWNING AND ACCESSORY MODELS

**CLICK OR TAP ON AN AWNING/ACCESSORY BELOW
TO TAKE YOU TO THE PAGE TO FIND OUT WHAT YOU NEED**

MAXTRAX® LITE 3

MAXTRAX® MINI 5

MAXTRAX® MKII 7

MAXTRAX® XTREME 9

MAXTRAX® JAXBASE 11



MAXTRAX® LITE

ITEMS REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard AND
ALSO REQUIRED	8173 – HD Accessory Bars

Where brackets can be located at 890mm centres (typically for platform racks with slats that run **LONGITUDINAL** (along the length of the vehicle).

BRACKETS REQUIRED FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
BRACKETS NEEDED	
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*

For vertical storage of recovery Boards on the side of vehicle.

*These Brackets can also mount to the underside of the Front Runner® Slimline II® platform (sides of the platform only-not rear) and are supplied with extra fasteners for this purpose.

Note: Some platform rack styles have limits on load carried on the outer perimeter slat/bars of North to South platforms, e.g. Rhino-Rack® Pioneer® Platform, Pioneer® Tradie and Pioneer Tray® and may require a bracket to bridge across to the inner or 2nd slat as well (see product 8306 below); **OR**

8304 – HD Adjustable Brackets Short (DOUBLE)**

For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical); **OR**

<ul style="list-style-type: none"> ✓ FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP) 	8306 – HD Adjustable Brackets Long (DOUBLE)**
--	---

For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical).

*ROOF RACKS WITH PERIMETER LIPS REQUIRE **PACKERS** TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO [ROOF RACK GUIDE](#) FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.

+ These brackets are both height and angle adjustable.

WALL MOUNTS OPTIONAL**BENEFITS**

ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.

SECURED LOCATION

8160 – HD Wall Mounts⁺

- ✓ **LOCKED GARAGES**
- ✓ **WORKSHOP WALLS**

UNSECURED LOCATION

8161 – HD Lockable Wall Mounts⁺

- ✓ **OPEN CARPORTS**
- ✓ **PUBLIC/SHARED GARAGE AREA**

⁺NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

MAXTRAX® MINI

ITEMS REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard AND
ALSO REQUIRED	8173 – HD Accessory Bars

Where brackets can be located at 890mm centres (typically for platform racks with slats that run **LONGITUDINAL** (along the length of the vehicle).

BRACKETS REQUIRED FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
BRACKETS NEEDED	
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	8300 – HD L50 L Brackets (DOUBLE)*

For vertical storage of recovery Boards on the side of vehicle.

*These Brackets can also mount to the underside of the Front Runner® Slimline II® platform (sides of the platform only-not rear) and are supplied with extra fasteners for this purpose.

Note: Some platform rack styles have limits on load carried on the outer perimeter slat/bars of North to South platforms, e.g. Rhino-Rack® Pioneer® Platform, Pioneer® Tradie and Pioneer Tray® and may require a bracket to bridge across to the inner or 2nd slat as well (see product 8306 below); **OR**

8304 – HD Adjustable Brackets Short (DOUBLE)**

For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical); **OR**

- ✓ **FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP)**

8306 – HD Adjustable Brackets Long (DOUBLE)**

For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical).

*ROOF RACKS WITH PERIMETER LIPS REQUIRE **PACKERS** TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO [ROOF RACK GUIDE](#) FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.

+ These brackets are both height and angle adjustable.

WALL MOUNTS OPTIONAL

BENEFITS

ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.

SECURED LOCATION

8160 – HD Wall Mounts⁺

- ✓ **LOCKED GARAGES**
- ✓ **WORKSHOP WALLS**

UNSECURED LOCATION

8161 – HD Lockable Wall Mounts⁺

- ✓ **OPEN CARPORTS**
- ✓ **PUBLIC/SHARED GARAGE AREA**

⁺NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

MAXTRAX® MKII

ITEMS REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard AND
ALSO REQUIRED	8174 – HD Accessory Plate; Where brackets cannot be located at 890mm centres, the distance between the centres of the recovery board mounting points. this is typical of roof rack bars or platform racks with slats/bars that run TRANSVERSE (across the width of the vehicle); OR 8173 – HD Accessory Bars Where brackets can be located at 890mm centres (typically for platform racks with slats that run LONGITUDINAL (along the length of the vehicle).

BRACKETS REQUIRED FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
BRACKETS NEEDED	
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	<p>8300 – HD L50 L Brackets (DOUBLE)*</p> <p>For vertical storage of recovery Boards on the side of vehicle.</p> <p>*These Brackets can also mount to the underside of the Front Runner® Slimline II® platform (sides of the platform only-not rear) and are supplied with extra fasteners for this purpose.</p> <p>Note: Some platform rack styles have limits on load carried on the outer perimeter slat/bars of North to South platforms, e.g. Rhino-Rack® Pioneer® Platform, Pioneer® Tradie and Pioneer Tray® and may require a bracket to bridge across to the inner or 2nd slat as well (see product 8306 below); OR</p> <p>8304 – HD Adjustable Brackets Short (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical); OR</p> <p>8306 – HD Adjustable Brackets Long (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical).</p>
<ul style="list-style-type: none"> ✓ FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP) 	<p>*ROOF RACKS WITH PERIMETER LIPS REQUIRE PACKERS TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO ROOF RACK GUIDE FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.</p> <p>+ These brackets are both height and angle adjustable.</p>

WALL MOUNTS OPTIONAL

BENEFITS

ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.

SECURED LOCATION

8160 – HD Wall Mounts⁺

- ✓ **LOCKED GARAGES**
- ✓ **WORKSHOP WALLS**

UNSECURED LOCATION

8161 – HD Lockable Wall Mounts⁺

- ✓ **OPEN CARPORTS**
- ✓ **PUBLIC/SHARED GARAGE AREA**

⁺NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

MAXTRAX® XTREME

ITEMS REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard AND
ALSO REQUIRED	8174 – HD Accessory Plate; Where brackets cannot be located at 890mm centres, the distance between the centres of the recovery board mounting points. this is typical of roof rack bars or platform racks with slats/bars that run TRANSVERSE (across the width of the vehicle); OR 8173 – HD Accessory Bars Where brackets can be located at 890mm centres (typically for platform racks with slats that run LONGITUDINAL (along the length of the vehicle).

BRACKETS REQUIRED FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
BRACKETS NEEDED	
<ul style="list-style-type: none"> ✓ FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP) 	<p>8300 – HD L50 L Brackets (DOUBLE)*</p> <p>For vertical storage of recovery Boards on the side of vehicle.</p> <p>*These Brackets can also mount to the underside of the Front Runner® Slimline II® platform (sides of the platform only-not rear) and are supplied with extra fasteners for this purpose.</p> <p>Note: Some platform rack styles have limits on load carried on the outer perimeter slat/bars of North to South platforms, e.g. Rhino-Rack® Pioneer® Platform, Pioneer® Tradie and Pioneer Tray® and may require a bracket to bridge across to the inner or 2nd slat as well (see product 8306 below); OR</p> <p>8304 – HD Adjustable Brackets Short (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical); OR</p> <p>8306 – HD Adjustable Brackets Long (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical).</p>
<ul style="list-style-type: none"> ✓ FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP) 	<p>*ROOF RACKS WITH PERIMETER LIPS REQUIRE PACKERS TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO ROOF RACK GUIDE FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.</p> <p>+ These brackets are both height and angle adjustable.</p>



WALL MOUNTS OPTIONAL

BENEFITS

ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.

SECURED LOCATION

8160 – HD Wall Mounts⁺

- ✓ **LOCKED GARAGES**
- ✓ **WORKSHOP WALLS**

UNSECURED LOCATION

8161 – HD Lockable Wall Mounts⁺

- ✓ **OPEN CARPORTS**
- ✓ **PUBLIC/SHARED GARAGE AREA**

⁺NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

MAXTRAX® JAXBASE

☹️ **SADLY NOT COMPATIBLE** ☹️