

PERLICK COLLECTION REFRIGERATION

SABBATH MODE

SABBATH MODE ON PERLICK COLUMNS

The following models may be used on the Jewish Sabbath or the Jewish Holidays (Yom Tov) when placed in the Sabbath mode.

COLUMN MODELS

Column Refrigerator	CR24R-1-2L, CR24R-1-2R
Column Freezer	CR24F-1-2L, CR24F-1-2R
Column Wine Reserve, Single Zone	CR24W-1-4L, CR24W-1-4R
Column Wine Reserve, Dual Zone	CR24D-1-4L, CR24D-1-4R



ACTIVATING/DEACTIVATING SABBATH MODE

To place the unit in the Sabbath mode, press the settings icon (⚙️) and then press the Star K icon (★).

To exit Sabbath mode, touch the Star K icon (★).



WHAT SABBATH MODE CONTROLS

- Disables user interface (Sabbath mode icon illuminated continuously).
- Disables lights (off while in Sabbath mode).
- Door open alarm disabled.
- Power interruption resumes in Sabbath mode.
- Defrost system is time dependent.
- Fan motors cycle with refrigeration system.
- Refrigeration system has built-in delay upon door opening.
- Variable speed compressor speed not affected by door openings.



LEARN MORE AT [STAR-K.ORG/APPLIANCES](https://star-k.org/appliances)
FOR MORE INFORMATION ON KOSHER APPLIANCES